

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31937	50704947 50707481 51787337 51746512	CONTROL ARM,LEFT,WITH BUSHINGS,ALUMINUM	ALFA ROMEO	
31938	50704948 50707480 51787336 71746513	CONTROL ARM,RIGHT,WITH BUSHINGS,ALUMINUM	ALFA ROMEO	
31940	50704307 50707317	CONTROL ARM,WITH BUSHINGS,ALUMINUM,RIGHT	ALFA ROMEO	
31942	60628295	CONTROL ARM,WITH BUSHINGS,ALUMINUM,RIGHT	ALFA ROMEO	
31939	50704306 50707316	CONTROL ARM,WITH BUSHINGS,ALUMINUM,LEFT	ALFA ROMEO	
31941	60628294	CONTROL ARM,WITH BUSHINGS,ALUMINUM,LEFT	ALFA ROMEO	
31287	60627605	CONTROL ARM,REAR LEFT	ALFA ROMEO	
31286	60627604	CONTROL ARM,REAR LEFT	ALFA ROMEO	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
30068	60652466 60678135 60686892 50509339	CONTROL ARM,FRONT RIGHT	ALFA ROMEO	HOH
30067	60652465 60678134 60686891 50509340	CONTROL ARM,FRONT LEFT	ALFA ROMEO	HOH
30070	51834094 60657246 60666789 60651940 51776326	CONTROL ARM,RIGHT	ALFA ROMEO	
31281	60665805 60627291	CONTROL ARM,RIGHT	ALFA ROMEO	
31285	60612318	CONTROL ARM,RIGHT	ALFA ROMEO	HOH
54747	60628307	CONTROL ARM,RIGHT	ALFA ROMEO	HOH
30069	60651939 51776327 51834093 60657245 60666787 60651941	CONTROL ARM,LEFT	ALFA ROMEO	
31280	60665804 60627290	CONTROL ARM,LEFT	ALFA ROMEO	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31284	60612317	CONTROL ARM,LEFT	ALFA ROMEO	HOH
54746	60628303	CONTROL ARM,LEFT	ALFA ROMEO	HOH
46830		CONTROL ARM KIT	ALFA ROMEO	
31283	60666020 60653552	CONTROL ARM,RIGHT,UPPER,ALUMINUM	ALFA ROMEO	HOH
31282	60666021 60653551	CONTROL ARM,LEFT,UPPER,ALUMINUM	ALFA ROMEO	HOH
53577	8K0 407 694 F 8K0 407 694 K 8K0 407 694 R 8K0 407 694 N	CONTROL ARM,RIGHT	AUDI	
53571	8K0 407 693 F 8K0 407 693 K 8K0 407 693 R 8K0 407 693 N	CONTROL ARM,LEFT	AUDI	
82456	8KD 407 151 A	CONTROL ARM,LEFT	AUDI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
83162	4E0 407 151	CONTROL ARM	AUDI	
82392	4H0 407 694 H	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI	
82391	4H0 407 693 H	CONTROL ARM,LEFT,UPPER,ALUMINUM	AUDI	
80550	4H0 407 506	CONTROL ARM,RIGHT	AUDI	
80549	4H0 407 505	CONTROL ARM,LEFT	AUDI	
80546	4E0 407 696	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI	
80548	4H0 407 156 A	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI	
80545	4E0 407 695	CONTROL ARM,LEFT,UPPER,ALUMINUM	AUDI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
80547	4H0 407 155 A	CONTROL ARM,LEFT,UPPER,ALUMINUM	AUDI	HOH
28804	8KD 407 510 8K0 407 510 A 8K0 407 510 B	CONTROL ARM,RIGHT	AUDI	
28808	8KD 407 506 8K0 407 506 A 8K0 407 506 B	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI	
28803	8KD 407 509 8K0 407 509 A 8K0 407 509 B	CONTROL ARM,LEFT	AUDI	
28807	8KD 407 505 8K0 407 505 A 8K0 407 505 B	CONTROL ARM,LEFT,UPPER,ALUMINUM	AUDI	
34389	8K0 505 324 F 8K0 505 324 D 8K0 505 324 H	CONTROL ARM,REAR RIGHT	AUDI	
34390	8K0 505 323 F 8K0 505 323 D 8K0 505 323 H	CONTROL ARM,REAR LEFT	AUDI	
28806	8K0 407 152 C 8K0 407 152 B 8K0 407 152 D 8KD 407 152	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
28805	8K0 407 151 C 8K0 407 151 D 8KD 407 151 8K0 407 151 B	CONTROL ARM,LEFT UPPER,ALUMINUM	AUDI	
92435	4M0 407 505 B	CONTROL ARM	AUDI	HOH
92436	4M0 407 506 B	CONTROL ARM	AUDI	HOH
92437	4M0 407 509 B	CONTROL ARM	AUDI	HOH
92438	4M0 407 510 B	CONTROL ARM	AUDI	HOH
92441	4M0 407 693 D	CONTROL ARM	AUDI	HOH
92442	4M0 407 694 D	CONTROL ARM	AUDI	HOH
92439	4M0 407 155 C	CONTROL ARM	AUDI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
92440	4M0 407 156 C	CONTROL ARM	AUDI	HOH
80542	4E0 407 510	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI	HOH
80544	4E0 407 506	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI	HOH
80541	4E0 407 509	CONTROL ARM,LEFT,UPPER,ALUMINUM	AUDI	HOH
80543	4E0 407 505	CONTROL ARM,LEFT,UPPER,ALUMINUM	AUDI	HOH
18081	4F0 407 694 4F0 407 694 B 4F0 407 694 C 4F0 407 694 G 4F0 407 694 H	CONTROL ARM,FRONT RIGHT,LOWER,ALUMINUM	AUDI	
18080	4F0 407 693 4F0 407 693 B 4F0 407 693 C 4F0 407 693 G 4F0 407 693 H	CONTROL ARM,LEFT,LOWER,ALUMINUM	AUDI	
18074	4F0 407 151 4F0 407 151 A 4FD 407 151 4FD 407 151 A	CONTROL ARM,FRONT,WITH BUSHING,LEFT/RIGHT,LOWER,ALUMINUM	AUDI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
82613	4GD 407 510 A 4GD 407 510	CONTROL ARM,RIGHT	AUDI	
82615	4GD 407 506 A 4GD 407 506	CONTROL ARM,RIGHT	AUDI	HOH
82612	4GD 407 509 A 4GD 407 509	CONTROL ARM,LEFT	AUDI	
82614	4GD 407 505 A 4GD 407 505	CONTROL ARM,LEFT	AUDI	HOH
82531	7L0 407 021 C	CONTROL ARM	AUDI	HOH
82532	7L0 407 022 C	CONTROL ARM	AUDI	HOH
83616	4C0 407 506 B	CONTROL ARM,RIGHT	AUDI	
83615	4C0 407 505 B	CONTROL ARM,LEFT	AUDI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
27518	8E0 498 998 8E0 498 998 S1	CONTROL ARM KIT,WITHOUT BOLT	AUDI	
39011	8E0 498 998 S2	CONTROL ARM KIT	AUDI	
43134	8K0 498 998	CONTROL ARM KIT	AUDI	
29833	4F0 498 998 8F0 498 998	CONTROL ARM KIT	AUDI	
53396	8D0407694H	CONTROL ARM,RIGHT	AUDI	HOH
53395	8D0 407 693 H	CONTROL ARM,LEFT	AUDI	HOH
19857	8E0 407 694 T 8E0 407 694 AC 8E0 407 694 AD 8E0 407 694 AJ 8E0 407 694 AK 8E0 407 694 AL 8E0 407 694 AM 8E0 407 694 AA 8E0 407 694 N	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
19856	8E0 407 693 T 8E0 407 693 AC 8E0 407 693 AD 8E0 407 693 AJ 8E0 407 693 AK 8E0 407 693 AL 8E0 407 693 AM 8E0 407 693 AA 8E0 407 693 N	CONTROL ARM,LEFT,UPPER,ALUMINUM	AUDI	
14330	8D0 501 530	CONTROL ARM,FRONT,WITH BUSHINGS	AUDI	
31288	8Z0 407 151 J	CONTROL ARM,LEFT	AUDI	
31289	8Z0 407 152 J	CONTROL ARM,RIGHT	AUDI	
43038	4F0 501 529 C 4F0 501 529 E	CONTROL ARM	AUDI	
43045	4D0 501 529 H 4D0 501 529 A 4D0 501 529 F	CONTROL ARM	AUDI	
31299	443 407 156 B	CONTROL ARM,RIGHT	AUDI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31301	441 407 152 A 441 407 152 C 441 407 156	CONTROL ARM,RIGHT	AUDI	
31298	443 407 155 B	CONTROL ARM,LEFT	AUDI	
31300	441 407 151 A 441 407 151 C 441 407 155	CONTROL ARM,LEFT	AUDI	
31296	8Z0 407 153 L	CONTROL ARM,LEFT/RIGHT	AUDI	HOH
31293	8Z0 407 152 P 8Z0 407 152 R	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI	
31295	8Z0 407 152 S 8Z0 407 152 Q	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI	
31292	8Z0 407 151 R 8Z0 407 151 P	CONTROL ARM,LEFT UPPER,ALUMINUM	AUDI	
31294	8Z0 407 151 S 8Z0 407 151 Q	CONTROL ARM,LEFT UPPER,ALUMINUM	AUDI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
28838	7L0 407 021 7L0 407 021 A 7L0 407 021 B 955 341 027 00 955 341 027 01 JTC1059	CONTROL ARM,WITH BUSHINGS,ALUMINUM	AUDI/PORSCHE/V W	
17933	8E0 407 151 M 8E0 407 151 E 8E0 407 151 L 8E0 407 151 N 8E0 407 151 K 8E0 407 151 R	CONTROL ARM,FRONT,LEFE/RIGHT	AUDI/SEAT	
43483	1K0 501 529 J	CONTROL ARM	AUDI/SEAT/SKOD A/VW	
46807		CONTROL ARM KIT	AUDI/SEAT/SKOD A/VW	
33280	1K0 505 323 D 1K0 505 323 G 1K0 505 323 H 1K0 505 323 N 1K0 505 323 M 5Q0 505 323 C 5Q0 505 323 D	CONTROL ARM,REAR	AUDI/SEAT/SKOD A/VW	
33282	1K0 505 224 K 1K0 505 224 E 1K0 505 224 H	CONTROL ARM,REAR RIGHT	AUDI/SEAT/SKOD A/VW	
32038	1K0 505 223 H 1K0 505 223 K 1K0 505 223 E	CONTROL ARM,RAER LEFT	AUDI/SEAT/SKOD A/VW	
24374	1K0 407 152 M 1K0 407 152 R 1K0 407 152 T 1K0 407 152 AC	CONTROL ARM,RIGHT	AUDI/SEAT/SKOD A/VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
26531	1K0 407 151 M 1K0 407 151 AC 1K0 407 151 T 1K0 407 151 R	CONTROL ARM,LEFT	AUDI/SEAT/SKOD A/VW	
30952	8D0 498 998 S1B 4B3 498 998 S 4B3 498 998 4B3 498 998 S1	CONTROL ARM KIT,WITH CONNECTING RODS,WITH BOLT KIT,WITH TOOLS	AUDI/VW	
18077	4E0 407 506 B 4E0 407 506 E	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI/VW	
18079	4E0 407 510 B 4E0 407 510 E 4E0 407 510 G 4E0 407 510 K	CONTROL ARM,RIGHT,UPPER,ALUMINUM	AUDI/VW	
18076	4E0 407 505 B 4E0 407 505 E	CONTROL ARM,LEFT,UPPER,ALUMINUM	AUDI/VW	
18078	4E0 407 509 B 4E0 407 509 E 4E0 407 509 G 4E0 407 509 K	CONTROL ARM,LEFT,UPPER,ALUMINUM	AUDI/VW	
36738	7L0 505 398	CONTROL ARM,REAR RIGHT	AUDI/VW	
36739	7L0 505 397	CONTROL ARM,REAR LEFT	AUDI/VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
32583	7L8 407 152 E 7L8 407 152 D 7L8 407 152 F 7P0 407 152 E 7P0 407 152 B	WISHBONE,RIGHT,ALUMINUM,FRONT RIGHT	AUDI/VW	
32582	7L8 407 151 E 7L8 407 151 D 7L8 407 151 F 7P0 407 151 E 7P0 407 151 B	WISHBONE,LEFT,ALUMINUM,FRONT LEFT	AUDI/VW	
1150	4B3 498 998 S1ALT	CONTROL ARM KIT,WITH CONNECTING RODS,WITHOUT BOLT KIT	AUDI/VW	
46809		CONTROL ARM KIT	AUDI/VW	
26635	7L0 505 323 A	CONTROL ARM,FRONT LEFT/RIGHT	AUDI/VW	
31767	4E0 501 529 D 4E0 501 529 G	CONTROL ARM	AUDI/VW	
6885	3B0 498 798 A	CONTROL ARM KIT WITH BOLT KIT	AUDI/VW	
7062	8D0 498 998 ALT	CONTROL ARM KIT,WITHOUT CONNECTING RODS,WITHOUT BOLT KIT	AUDI/VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
7063	8D0 498 998 S1ALT	CONTROL ARM KIT,WITH CONNECTING RODS,WITHOUT BOLT KIT	AUDI/VW	
23553	8D0 498 998 S1FALT	CONTROL ARM KIT,WITH CONNECTING RODS,WITHOUT BOLT KIT	AUDI/VW	
6879	8D0 498 998	CONTROL ARM KIT,WITHOUT CONNECTING RODS,WITH BOLT KIT	AUDI/VW	
6878	8D0 498 998 S1 8D0 498 998 B	CONTROL ARM KIT,WITH CONNECTING RODS,WITH BOLT KIT	AUDI/VW	
23547	8D0 498 998 S1F	CONTROL ARM KIT,WITH CONNECTING RODS,WITH BOLT KIT	AUDI/VW	
21549	893 407 147 G.OE 811 407 147 A.OE 811 407 147 B.OE 811 407 147.OE	CONTROL ARM,WITH BUSHINGS	AUDI/VW	
21548	893 407 148 CO 857 407 148 CO 893 407 148 AO	WISHBONE,WITH OE BUSHING,RIGHT	AUDI/VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31768	7L0 407 152 C 7L0 407 152 D 7L0 407 152 E 7L0 407 152 H 955 341 018 30 955 341 018 32 955 341 018 33 955 341 018 31 JTC1058	CONTROL ARM,RIGHT	AUDI/VW	
43908	33 32 6 770 813 33 32 1 092 237 33 32 1 138 380 33 30 3 411 651 33 32 6 760 675	CONTROL ARM,REAR	BMW	HOH
6368	33 32 1 090 745 33 32 1 097 264 33 32 6 768 791	CONTROL ARM,FRONT,WITH BUSHINGS,UPPER,ALUMINUM	BMW	
7178	33 32 1 090 906 33 32 6 770 060 JTC1027	CONTROL ARM,RIGHT,L=306MM	BMW	HOH
7177	33 32 1 090 905 33 32 6 770 059 JTC1026	CONTROL ARM,WITH BEARING AND JOINT,REAR AXLE STRUT,LEFT,BOTTOM REAR AXLE,L=306MM	BMW	HOH
9066	31 12 1 141 722 31 12 1 141 724	CONTROL ARM,FRONT,RIGHT,WITH BEARING AND JOINT	BMW	
9065	31 12 1 141 721 31 12 1 141 723	CONTROL ARM,FRONT,LEFT,WITH BEARING AND JOINT	BMW	
43925	33 32 1 140 569	CONTROL ARM,REAR	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
9055	31 12 1 142 088	CONTROL ARM, FRONT, RIGHT, LOWER, WITH BUSHINGS	BMW	
9054	31 12 1 142 087	CONTROL ARM, FRONT, LEFT, LOWER, WITH BUSHINGS	BMW	
25297	33 32 6 770 749 33 32 1 091 620 33 32 1 090 030	CONTROL ARM	BMW	
7126	31 12 1 141 718 31 12 1 092 024	CONTROL ARM, RIGHT, UPPER, ALUMINUM	BMW	
8117	31 12 1 094 234 31 12 1 093 450 1308702	CONTROL ARM, RIGHT, UPPER, ALUMINUM	BMW	
8116	31 12 1 094 233 31 12 1 093 449 1308602	CONTROL ARM, LEFT, UPPER, ALUMINUM	BMW	
8118	31 12 1 141 717 31 12 1 092 023 1308401 31 12 1 092 023 S1	CONTROL ARM, LEFT, UPPER, ALUMINUM	BMW	
9060	33 32 1 090 816 33 32 1 094 210 33 32 6 767 832 33 32 1 095 209	CONTROL ARM, REAR, WITH BUSHINGS, RIGHT, ALUMINUM	BMW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
9059	33 32 1 090 815 33 32 1 094 209 33 32 6 767 831	CONTROL ARM,REAR,WITH BUSHINGS,LEFT,ALUMINUM	BMW	
9062	31 12 1 094 466 31 12 6 751 318 31 12 6 752 718 31 12 6 758 520 31 12 6 770 248 31 12 6 774 820 31 12 6 777 852 31 12 1 096 986 31 12 6 750 224 1791901	CONTROL ARM, FRONT, RIGHT, ALUMINUM	BMW	
9061	31 12 1 094 465 31 12 6 751 317 31 12 6 752 717 31 12 6 758 519 31 12 6 770 247 31 12 6 774 819 31 12 6 777 851 31 12 1 096 985 31 12 6 750 223 1787501	CONTROL ARM, FRONT, LEFT, WITH BEARING AND JOINT	BMW	
12328	33 32 6 774 795 33 32 2 282 065 33 32 6 770 753 33 32 6 768 268 33 32 6 777 424 33 32 1 096 797 33 32 6 763 324 33 32 0 403 294 33 32 0 421 750 33 32 0 300 946 33 32 0 414 345 33 32 0 398 361 2585502	CONTROL ARM,REAR,WITH BUSHINGS,LEFT/RIGHT,UPPER,ALU MINUM	BMW	
12330	33 32 6 758 142 33 32 6 767 760 33 32 6 769 972 33 32 6 770 776 33 32 6 772 242 33 30 6 772 242 33 32 6 774 794 33 32 6 777 426	CONTROL ARM,RIGHT,UPPER,ALUMINUM	BMW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
12329	33 32 6 758 141 33 32 6 767 759 33 32 6 769 971 33 32 6 770 775 33 32 6 772 241 33 32 6 774 793 33 30 6 772 241 33 32 6 777 425	CONTROL ARM,LEFT,UPPER,ALUMINUM	BMW	
27368	31 12 6 774 826 31 12 6 760 184 31 12 6 765 996 31 12 4 046 438 31 10 4 026 720 2709702	CONTROL ARM,BACK ARTICULATION,FRONT RIGHT,L=423MM	BMW	
27369	31 12 6 774 825 31 12 6 760 183 31 12 6 765 995 31 12 4 046 437 31 10 4 026 719 2709602	CONTROL ARM,BACK ARTICULATION,FRONT LEFT,L=423MM	BMW	
43922	33 30 6 770 242	CONTROL ARM,REAR	BMW	HOH
12321	31 12 6 760 182 31 12 6 768 298 31 12 4 028 608	CONTROL ARM, RIGHT, UPPER, ALUMINUM	BMW	
12320	31 12 6 760 181 31 12 6 768 297 31 12 4 028 607	CONTROL ARM,LEFT,UPPER, ALUMINUM	BMW	
43951	31 12 6 774 829	CONTROL ARM,FRONT	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
12325	31 12 6 765 994 31 12 6 750 520 31 12 4 026 454 31 12 6 756 102 31 12 6 774 832 31 12 4 046 442 2589902	CONTROL ARM,RIGHT, UPPER, ALUMINUM	BMW	
12324	31 12 6 765 993 31 12 6 750 519 31 12 4 026 453 31 12 6 756 101 31 12 6 774 831 31 12 4 046 441 2589802	CONTROL ARM,LEFT, UPPER, ALUMINUM	BMW	
9058	31 12 6 755 836 31 12 6 770 122 31 12 6 770 772 31 12 6 770 838 31 12 6 777 938 31 12 6 777 940	CONTROL ARM, FRONT, RIGHT, LOWER, ALUMINUM, WITH BUSHINGS	BMW	
8155	31 12 6 755 835 31 12 6 770 121 31 12 6 770 771 31 12 6 770 837 31 12 6 777 937 31 12 6 777 939	CONTROL ARM, FRONT, LEFT, UPPER, ALUMINUM, WITH BUSHINGS	BMW	
12323	31 12 6 770 850 31 12 6 763 700 31 12 6 769 794 3034001 31 12 2 405 860	CONTROL ARM, RIGHT, UPPER, ALUMINUM	BMW	
14594	31 12 6 769 802 31 12 4 036 270 31 12 6 763 704 31 12 6 769 798 31 12 6 763 708 210962 3033301	CONTROL ARM, RIGHT, UPPER, ALUMINUM	BMW	
12322	31 12 6 770 849 31 12 6 763 699 31 12 6 769 793 3033801 31 12 2 405 859	CONTROL ARM,LEFT,UPPER, ALUMINUM	BMW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
14593	31 12 6 769 801 31 12 4 036 269 31 12 6 763 703 31 12 6 769 797 31 12 6 763 707 3033201	CONTROL ARM,LEFT,UPPER,ALUMINUM	BMW	
14608	33 32 6 763 471	CONTROL ARM,FRONT,WITH BUSHINGS	BMW	HOH
14609	33 32 6 765 425 3056501	CONTROL ARM,FRONT,WITH BUSHINGS	BMW	HOH
31302	33 32 6 763 473 33 32 6 777 980	CONTROL ARM	BMW	HOH
88772	33 32 6 763 477	CONTROL ARM	BMW	HOH
43914	33 32 6 782 238	CONTROL ARM,REAR	BMW	HOH
43915	33 32 6 782 237	CONTROL ARM,REAR	BMW	HOH
43929	31 12 6 798 107 31 12 6 775 963	CONTROL ARM,FRONT	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
43930	31 12 6 798 108 31 12 6 775 964	CONTROL ARM,FRONT	BMW	
43931	31 12 6 775 959	CONTROL ARM,FRONT	BMW	
43932	31 12 6 775 960	CONTROL ARM,FRONT	BMW	
43935	33 32 6 775 902	CONTROL ARM,REAR	BMW	
43936	33 32 6 782 131	CONTROL ARM,REAR	BMW	
43937	33 32 6 782 132	CONTROL ARM,REAR	BMW	
43933	31 12 6 775 967	CONTROL ARM,FRONT	BMW	
56990	31 12 6 775 972	CONTROL ARM,RIGHT	BMW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
56989	31 12 6 775 971	CONTROL ARM,LEFT	BMW	
56992	31 12 6 794 204	CONTROL ARM,RIGHT	BMW	
56991	31 12 6 794 203	CONTROL ARM,LEFT	BMW	
78313	31 12 6 852 992	CONTROL ARM,RIGHT	BMW	
78318	31 12 6 855 742 31 12 6 851 260	CONTROL ARM,RIGHT	BMW	
78312	31 12 6 852 991	CONTROL ARM,LEFT	BMW	
78317	31 12 6 855 741 31 12 6 851 259	CONTROL ARM,LEFT	BMW	
73611	31 12 6 787 669	CONTROL ARM	BMW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
73612	31 12 6 787 670	CONTROL ARM	BMW	HOH
14600	31 10 3 412 138 31 10 3 443 128 31 10 0 363 478	CONTROL ARM,FRONT,WITH BUSHINGS,RIGHT	BMW	
14599	31 10 3 412 137 31 10 3 443 127 31 10 0 363 477	CONTROL ARM,FRONT,WITH BUSHINGS,LEFT	BMW	
64025	31 10 3 451 882	CONTROL ARM	BMW	
64026	31 10 3 451 881	CONTROL ARM	BMW	
27349	33 32 1 095 412 33 32 6 770 860 33 32 6 768 274 33 32 6 770 748	CONTROL ARM,WITH BUSHINGS,REAR RIGHT	BMW	
14610	33 32 1 095 411 33 32 6 770 859 33 32 6 768 273 33 32 6 770 747	CONTROL ARM,WITH BUSHINGS,REAR,LEFT	BMW	
9068	31 12 1 096 316 31 12 6 760 276 3048701	CONTROL ARM,FRONT,RIGHT,WITH BEARING AND JOINT	BMW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
9073	31 12 1 096 170 31 12 6 769 718	CONTROL ARM, FRONT, RIGHT, WITH BEARING AND JOINT	BMW	
9067	31 12 1 096 315 31 12 6 760 275 3048601	CONTROL ARM,FRONT,LEFT,WITH BEARING AND JOINT	BMW	
9072	31 12 1 096 169 31 12 6 769 717	CONTROL ARM, FRONT, LEFT, WITH BUSHIN AND JOINT	BMW	
12331	33 32 6 774 796 33 32 6 768 269 33 32 6 770 742 33 32 1 095 414	CONTROL ARM,REAR,WITH BUSHINGS,LEFT/RIGHT,UPPER,ALU MINUM	BMW	
39392	31 12 6 773 949	CONTROL ARM	BMW	
45097	31 12 6 773 950	CONTROL ARM	BMW	
39391	31 12 6 771 894	CONTROL ARM,RIGHT	BMW	
39389	31 12 6 771 893	CONTROL ARM,LEFT	BMW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
34439	31 12 6 776 418 31 12 6 863 786	CONTROL ARM,RIGHT	BMW	
34441	33 32 6 779 388 33 32 4 046 918 33 32 6 770 964 33 32 6 795 048	CONTROL ARM,RIGHT	BMW	HOH
34443	33 32 6 770 970 33 32 6 796 002	CONTROL ARM,RIGHT	BMW	HOH
34438	31 12 6 776 417 31 12 6 863 785	CONTROL ARM,LEFT	BMW	
34440	33 32 6 779 387 33 32 4 046 917 33 32 6 770 963 33 32 6 795 047	CONTROL ARM,LEFT	BMW	HOH
34442	33 32 6 770 969 33 32 6 796 001	CONTROL ARM,LEFT	BMW	HOH
46821		CONTROL ARM KIT	BMW	
46818		CONTROL ARM KIT	BMW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46814		CONTROL ARM KIT	BMW	
46817		CONTROL ARM KIT	BMW	
46823		CONTROL ARM KIT	BMW	
46812		CONTROL ARM KIT	BMW	
46825		CONTROL ARM KIT	BMW	
46828		CONTROL ARM KIT	BMW	HOH
46811		CONTROL ARM KIT	BMW	
56994	31 10 6 787 674	CONTROL ARM,RIGHT	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
56993	31 10 6 787 673	CONTROL ARM,LEFT	BMW	HOH
52198	31 12 6 761 409 31 12 1 492 144 31 12 4 015 707 31 12 6 753 989	CONTROL ARM	BMW	HOH
52199	31 12 6 761 410 31 12 1 492 143 31 12 4 015 708 31 12 6 753 990	CONTROL ARM	BMW	HOH
46827		CONTROL ARM KIT	BMW	
31781	31 12 1 141 999	CONTROL ARM	BMW	HOH
31782	31 12 1 141 000	CONTROL ARM	BMW	HOH
31783	31 12 1 139 993	CONTROL ARM	BMW	HOH
31784	31 12 1 114 717	CONTROL ARM	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31785	31 12 1 114 718	CONTROL ARM	BMW	HOH
34400	31 21 6 773 783	CONTROL ARM	BMW	HOH
34401	31 21 6 773 784	CONTROL ARM	BMW	HOH
39387	31 12 1 442 087	CONTROL ARM	BMW	HOH
42397	31 12 2 282 122	CONTROL ARM	BMW	
42398	31 12 2 282 121	CONTROL ARM	BMW	
72694	33 32 1 490 085 33 32 6 768 726 33 32 6 760 054 33 32 6 769 020 33 32 6 769 023 33 32 6 768 724	CONTROL ARM	BMW	HOH
78314	33 32 6 775 683	CONTROL ARM	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
87157	33 32 6 779 851	CONTROL ARM	BMW	
88724	31 15 6 769 499	CONTROL ARM	BMW	
87164	33 32 6 782 136 33 32 4 069 284	CONTROL ARM,REAR RIGHT	BMW	
87163	33 32 6 782 135 33 32 4 069 283	CONTROL ARM,REAR LEFT	BMW	
34224	31 12 1 114 701	CONTROL ARM,FRONT RIGHT	BMW	
75830	31 10 6 770 686	CONTROL ARM,FRONT,RIGHT	BMW	
34223	31 12 1 114 700	CONTROL ARM,FRONT LEFT	BMW	
75829	31 10 6 770 685	CONTROL ARM,FRONT,LEFT	BMW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
7174	31 12 6 758 514 31 12 1 136 530 31 12 1 140 400 31 12 1 140 958	CONTROL ARM, RIGHT, WITHOUT BUSHING, WITH WITH JOINTS, BOTTOM FRONT AXLE	BMW	
7176	31 12 1 127 726 31 12 1 701 060	CONTROL ARM, RIGHT	BMW	
11110	31 12 1 108 385	CONTROL ARM,RIGHT	BMW	
14603	31 10 3 426 434 31 10 3 415 028 31 10 3 412 136 31 10 3 418 338	CONTROL ARM,FRONT,WITH BUSHINGS,RIGHT	BMW	HOH
29339	31 12 6 758 534 31 12 1 096 222	CONTROL ARM,REAR,RIGHT	BMW	HOH
31328	31 12 1 123 026	CONTROL ARM,RIGHT	BMW	HOH
34226	31 12 1 125 552 31 12 1 132 346 31 12 1 129 246 31 12 1 125 550 31 12 1 127 142 31 12 1 132 354	CONTROL ARM,RIGHT	BMW	HOH
34403	31 12 2 229 454	CONTROL ARM,RIGHT	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
34447	31 12 1 118 356	CONTROL ARM,RIGHT	BMW	HOH
48187	31 12 6 758 514 S1 31 12 1 136 530 S1 31 12 1 140 400 S1 31 12 1 140 958 S1	CONTROL ARM, RIGHT, WITHOUT BUSHING, WITH WITH JOINTS, BOTTOM FRONT AXLE	BMW	
78310	31 12 6 768 984	CONTROL ARM,RIGHT	BMW	HOH
78316	33 32 6 779 848	CONTROL ARM,RIGHT	BMW	HOH
80228	31 12 6 787 700	CONTROL ARM,RIGHT	BMW	HOH
80262	31 12 6 772 302 31 12 4 048 628	CONTROL ARM,RIGHT	BMW	HOH
92606	31 12 6 798 254	CONTROL ARM,RIGHT	BMW	HOH
92615	31 12 6 851 692	CONTROL ARM,RIGHT	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
7173	31 12 6 758 513 31 12 1 136 529 31 12 1 140 399 31 12 1 140 957	CONTROL ARM,LEFT,WITHOUT BUSHING, WITH WITH JOINTS, BOTTOM FRONT AXLE	BMW	
7175	31 12 1 127 725 31 12 1 701 059	CONTROL ARM,LEFT	BMW	
11227	31 12 1 108 384	CONTROL ARM,LEFT	BMW	
14602	31 10 3 418 337 31 12 0 360 275 31 10 3 412 135 31 10 3 426 433 31 10 3 415 027	CONTROL ARM,LEFT	BMW	HOH
31327	31 12 1 123 025	CONTROL ARM,LEFT	BMW	HOH
34225	31 12 1 127 141 31 12 1 125 551 31 12 1 132 345 31 12 1 132 353 31 12 1 129 245 31 12 1 125 549	CONTROL ARM,LEFT	BMW	HOH
34402	31 12 2 229 453	CONTROL ARM,LEFT	BMW	HOH
34446	31 12 1 118 355	CONTROL ARM,LEFT	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
34448	31 12 1 118 130 31 12 1 129 362	CONTROL ARM,LEFT	BMW	HOH
48191	31 12 6 758 513 S1 31 12 1 136 529 S1 31 12 1 140 399 S1 31 12 1 140 957 S1	CONTROL ARM,LEFT,WITHOUT BUSHING, WITH WITH JOINTS, BOTTOM FRONT AXLE	BMW	
78309	31 12 6 768 983	CONTROL ARM,LEFT	BMW	HOH
78315	33 32 6 779 847	CONTROL ARM,LEFT	BMW	HOH
80227	31 12 6 787 699	CONTROL ARM,LEFT	BMW	HOH
80263	31 12 6 772 301 31 12 4 048 627	CONTROL ARM,LEFT	BMW	HOH
92604	31 12 6 798 253	CONTROL ARM,LEFT	BMW	HOH
92614	31 12 6 851 691	CONTROL ARM,LEFT	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
3394	31 12 1 139 992 31 12 1 124 402 31 12 1 131 582 31 12 1 131 588	CONTROL ARM, FRONT, RIGHT, UPPER, ALUMINUM, WITH BUSHINGS	BMW	
8105	31 12 1 132 160 31 12 1 133 712 31 12 2 226 582 31 12 1 141 098	CONTROL ARM, FRONT, RIGHT, WITH BUSHING AND JOINT	BMW	
9064	31 12 1 130 090 31 12 1 130 598 31 12 1 140 000	CONTROL ARM, FRONT, RIGHT, WITH BUSH AND JOINT	BMW	
6479	31 12 1 139 991 31 12 1 124 401 31 12 1 139 581 31 12 1 131 587	CONTROL ARM, FRONT, LEFT, UPPER, ALUMINUM, WITH BUSHINGS	BMW	
7250	31 12 1 132 159 31 12 1 133 711 31 12 2 226 581 31 12 1 141 097	CONTROL ARM, FRONT, LEFT, WITH BUSHING AND JOINT	BMW	
9063	31 12 1 130 089 31 12 1 130 597 31 12 1 139 999	CONTROL ARM, FRONT, LEFT, WITH BEARING AND JOINT	BMW	
69984		CONTROL ARM KIT	BMW	HOH
69985		CONTROL ARM KIT	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
75511	31 12 6 758 624	CONTROL ARM KIT,RIGHT	BMW	
75510	31 12 6 758 623	CONTROL ARM KIT,LEFT	BMW	
43955	33 32 6 775 083	CONTROL ARM,REAR	BMW	HOH
43956	33 32 6 775 084	CONTROL ARM,REAR	BMW	HOH
6752	31 12 1 139 988 31 12 1 133 238	CONTROL ARM, RIGHT, UPPER, ALUMINUM	BMW	
12327	33 32 6 768 790 33 32 6 767 968 33 30 6 773 942 33 32 6 770 840 33 32 6 759 158 33 32 6 767 754	CONTROL ARM,RIGHT,UPPER,ALUMINUM	BMW	
14598	31 12 6 768 298	CONTROL ARM,RIGHT,UPPER,ALUMINUM	BMW	HOH
31213	31 12 1 092 610 31 12 1 092 820	CONTROL ARM, RIGHT, ALUMINUM, WITH BUSHINGS	BMW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
6757	31 12 1 139 987 31 12 1 133 237	CONTROL ARM,LEFT,UPPER, ALUMINUM	BMW	
12326	33 32 6 768 789 33 32 6 767 967 33 30 6 773 941 33 32 6 770 839 33 32 6 759 157	CONTROL ARM,LEFT,UPPER,ALUMINUM	BMW	
14597	31 12 6 768 297	CONTROL ARM,LEFT,UPPER,ALUMINUM	BMW	HOH
29338	31 12 6 758 533 31 12 1 096 221	CONTROL ARM,LEFT	BMW	HOH
31794	31 12 1 092 609 31 12 1 092 819	CONTROL ARM,LEFT,ALUMINUM, WITH BUSHINGS	BMW	
9057	31 12 1 141 962	CONTROL ARM, FRONT, RIGHT, UPPER, ALUMINUM, WITH BUSHINGS	BMW	
9056	31 12 1 141 961	CONTROL ARM, FRONT, LEFT, UPPER, ALUMINUM, WITH BUSHINGS	BMW	
43952	31 12 6 774 830	CONTROL ARM	BMW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
29635	T11-2909020	CONTROL ARM	CHERY	
29636	T11-2909010	CONTROL ARM	CHERY	
29637	A11-2810010BM	CONTROL ARM	CHERY	
29638	B11-2909010	CONTROL ARM	CHERY	
29639	B11-2909020	CONTROL ARM	CHERY	
29640	A21-2909010	CONTROL ARM	CHERY	
29641	A21-2909020	CONTROL ARM	CHERY	
29642	S21-2909010	CONTROL ARM	CHERY	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
29643	S21-2909020	CONTROL ARM	CHERY	
29644	S11-3301070	CONTROL ARM	CHERY	
29645	S21-3301070	CONTROL ARM	CHERY	
29646	S21-3301070B	CONTROL ARM	CHERY	
29647	A11-2909010	CONTROL ARM	CHERY	
49051	S11-2909010A	CONTROL ARM	CHERY	
55075	96819162 48 17 778 48 10 870 48 06 301	CONTROL ARM,RIGHT	CHEVROLET	
31584	22603946 22611125 22645739 22645740 22645743 22645801	CONTROL ARM,RIGHT	CHEVROLET	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31583	22603947 22611124 22637807 22645744 22645741 22649352 22650966	CONTROL ARM,LEFT	CHEVROLET	HOH
834	15787555	CONTROL ARM,RIGHT	CHEVROLET	
24061	13273604 13318884 03 52 869 03 52 050	CONTROL ARM,LEFT	CHEVROLET	HOH
37873	13 321 338 13 334 022 13 272 605 13 313 749 03 52 110 03 52 492 13 463 244	CONTROL ARM,LEFT	CHEVROLET	HOH
64284	12472817 12475479 15047209	CONTROL ARM	CHEVROLET	HOH
64286	12475480 15047210 12472818	CONTROL ARM	CHEVROLET	HOH
95747	54 97 127	CONTROL ARM	CHEVROLET	HOH
95748	54 97 128	CONTROL ARM	CHEVROLET	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
55404	95032441 95952783 4127	CONTROL ARM,RIGHT	CHEVROLET	HOH
92454	96440011 95225560	CONTROL ARM,RIGHT	CHEVROLET	HOH
55403	95032440 95952782 4128	CONTROL ARM,LEFT	CHEVROLET	HOH
24959	22730775 K620179	CONTROL ARM	CHEVROLET	HOH
24989	22730776 K620180	CONTROL ARM	CHEVROLET	HOH
25110	13272609	CONTROL ARM	CHEVROLET	
25171	13272610	CONTROL ARM	CHEVROLET	HOH
24986	13273605 13318885 03 52 071 03 52 870	CONTROL ARM,RIGHT	CHEVROLET	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
37874	13 321 339 13 334 023 13 272 606 03 52 493 03 52 115 13 313 750 13 347 446	CONTROL ARM,RIGHT	CHEVROLET	HOH
24932	15787556	CONTROL ARM,LEFT	CHEVROLET	
60961	95225559 96440010	CONTROL ARM, LEFT	CHEVROLET	HOH
82945	96378348 96423324	CONTROL ARM,RIGHT	CHEVROLET/DAE WOO	HOH
82944	96378347 96423220	CONTROL ARM,LEFT	CHEVROLET/DAE WOO	HOH
50465	4764409 4764409AC 4782975AB 4782975AE	CONTROL ARM	CHRYSLER	HOH
50466	4764408 4764408AC 4782974AB 4782974AE	CONTROL ARM	CHRYSLER	HOH
50467	4743835AA 4766623AA	CONTROL ARM	CHRYSLER	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
50468	4743834AA 4766622AA	CONTROL ARM	CHRYSLER	HOH
46849		CONTROL ARM KIT	CHRYSLER	
31329	46 56 731	CONTROL ARM	CHRYSLER	HOH
31330	46 56 730	CONTROL ARM	CHRYSLER	HOH
31331	46 16 403	CONTROL ARM	CHRYSLER	HOH
31332	46 16 402	CONTROL ARM	CHRYSLER	HOH
46661	4616578	CONTROL ARM	CHRYSLER	HOH
46662	4616579	CONTROL ARM	CHRYSLER	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46663	4509775	CONTROL ARM	CHRYSLER	
46664	4509776	CONTROL ARM	CHRYSLER	
56603	4782665AB K620177	CONTROL ARM	CHRYSLER	
56604	4782666AB K620178	CONTROL ARM	CHRYSLER	
56707	51 80 607 AA	CONTROL ARM	CHRYSLER	
56708	51 80 606 AA	CONTROL ARM	CHRYSLER	
61708	52106776AB	CONTROL ARM	CHRYSLER	
62249	4509774	CONTROL ARM	CHRYSLER	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
82921	4743376AD 4743376AC 4743376AA	CONTROL ARM	CHRYSLER	
36231	DA782561AE	CONTROL ARM,FRONT	CHRYSLER	
36230	DA782612AC	CONTROL ARM,FRONT RIGHT	CHRYSLER	
46797	DA782666AB 4782666AF	CONTROL ARM,FRONT RIGHT	CHRYSLER	
90350	4728884	CONTROL ARM,FRONT RIGHT	CHRYSLER	
36229	DA782613AC	CONTROL ARM,FRONT LEFT	CHRYSLER	
36232	DA782665AB 4782665AF	CONTROL ARM,FRONT LEFT	CHRYSLER	
90351	4728885	CONTROL ARM,FRONT LEFT	CHRYSLER	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31336	47 28 884	CONTROL ARM,RIGHT	CHRYSLER	
31590	4694760 4694760AC 4694761AC	CONTROL ARM,RIGHT	CHRYSLER	
42224	4616922 K7425 4764500AC	CONTROL ARM,RIGHT	CHRYSLER	
47379	4616402	CONTROL ARM,RIGHT	CHRYSLER	
53419	04616578RH	CONTROL ARM,RIGHT	CHRYSLER	
82937	4766542AA 4766542AC 4766542AD 04766542AD 04766542AC 04766542AA	CONTROL ARM,RIGHT	CHRYSLER	
82949	52088636AD 52088636AG	CONTROL ARM,RIGHT	CHRYSLER	
31335	47 28 885	CONTROL ARM,LEFT	CHRYSLER	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31589	4694761	CONTROL ARM,LEFT	CHRYSLER	
42223	4616923 K7427 4764501AC	CONTROL ARM,LEFT	CHRYSLER	
47378	4616403	CONTROL ARM,LEFT	CHRYSLER	
53418	04616579LH	CONTROL ARM,LEFT	CHRYSLER	
82925	4766543AD 4766543AA 4766543AC 04766543AD 04766543AC 04766543AA	CONTROL ARM,LEFT	CHRYSLER	
82948	52088637AG 52088637AD	CONTROL ARM,LEFT	CHRYSLER	
47380	52106577AA	CONTROL ARM	CHRYSLER	
66463	04782936AA 04782937AA	CONTROL ARM	CHRYSLER	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
83933	05105040AB 05105040AD 5105040AD 05105040AF 05105040AI 5105040AB 5105040AF 5105040AI 05105040AG 05105040AH 5105040AG 05105040AA 05105040AE 5105040AA 05105040AC 5105040AC 5105040AE 5105040AH	CONTROL ARM,RIGHT	CHRYSLER/DODGE/JEEP	
82943	52088355AB 52088355AD 52088355AC 52088355	CONTROL ARM	CHRYSLER/JEEP	
87876	68068615AB 52088632AA 52088632AB 52088632AC	CONTROL ARM	CHRYSLER/JEEP	
82910	52089980AI 52089980AD 52089980AF 52089980AG	CONTROL ARM,RIGHT	CHRYSLER/JEEP	
82909	52089981AI 52089981AD 52089981AG 52089981AF	CONTROL ARM,LEFT	CHRYSLER/JEEP	
31339	95 615 000	CONTROL ARM,RIGHT	CITROEN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31340	3521.G3	CONTROL ARM,RIGHT	CITROEN	
31338	95 614 999	CONTROL ARM,LEFT	CITROEN	
31341	3520.K3	CONTROL ARM,LEFT	CITROEN	
78295	3520.V2	CONTROL ARM,RIGHT	CITROEN/PEUGE OT	
78300	3521.N8 3521.S8	CONTROL ARM,RIGHT	CITROEN/PEUGE OT	
78296	3521.R3	CONTROL ARM,LEFT	CITROEN/PEUGE OT	
78298	3521.N9 3521.S0 1497407080 1401239480	CONTROL ARM,RIGHT	CITROEN/PEUGE OT/FIAT	
78297	3520.R8 3520.V8 1497408080 1401239580	CONTROL ARM,LEFT	CITROEN/PEUGE OT/FIAT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
82960	54 50 065 42R 54 50 015 35R	CONTROL ARM,FRONT RIGHT	DACIA/RENAULT	HOH
82959	54 50 167 46R 54 50 199 69R 54 50 116 97R 40 16 023 08R 54 50 001 38R	CONTROL ARM,FRONT LEFT	DACIA/RENAULT	HOH
25416	96611265	CONTROL ARM	DAEWOO	HOH
31411	45200A85000-000 94583538	CONTROL ARM	DAEWOO	
64841	45200A78B00-000	CONTROL ARM	DAEWOO	HOH
69207	96346531	CONTROL ARM	DAEWOO	
12402	96305975 96268438	CONTROL ARM,RIGHT	DAEWOO	HOH
21991	96535082 96815894 96870466 9008226	CONTROL ARM,RIGHT	DAEWOO	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25388	96268440 96268430	CONTROL ARM,RIGHT	DAEWOO	HOH
25393	96415064 96391851	CONTROL ARM,RIGHT	DAEWOO	
25415	96213118	CONTROL ARM,RIGHT	DAEWOO	HOH
31410	96389492	CONTROL ARM,RIGHT	DAEWOO	HOH
31417	96246430	CONTROL ARM,RIGHT	DAEWOO	HOH
31511	96178336	CONTROL ARM,RIGHT	DAEWOO	HOH
31516	96320681	CONTROL ARM,RIGHT	DAEWOO	HOH
31520	93213430	CONTROL ARM,RIGHT	DAEWOO	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
12403	96305974 96268439	CONTROL ARM,LEFT	DAEWOO	HOH
13893	96268454	CONTROL ARM,LEFT	DAEWOO	HOH
21990	96535081 96815893 96870465 9008225	CONTROL ARM,LEFT	DAEWOO	HOH
25392	96415063 96391850	CONTROL ARM,LEFT	DAEWOO	
25414	96213117	CONTROL ARM,LEFT	DAEWOO	HOH
31409	96389491	CONTROL ARM,LEFT	DAEWOO	HOH
31415	96246429	CONTROL ARM,LEFT	DAEWOO	HOH
31510	96178335	CONTROL ARM,LEFT	DAEWOO	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31515	96320680	CONTROL ARM,LEFT	DAEWOO	HOH
31519	93213429	CONTROL ARM,LEFT	DAEWOO	HOH
20257	96316765	CONTROL ARM	DAEWOO/CHEVR OLET	
61156	48068-87705 CJ-605R	CONTROL ARM	DAIHATSU	HOH
61640	48069-B4010 48069-B4011	CONTROL ARM	DAIHATSU	HOH
61641	48068-B4010 48068-B4011	CONTROL ARM	DAIHATSU	HOH
78334	48068-87208 48069-87208	CONTROL ARM,RIGHT	DAIHATSU	HOH
47829	48068-87512 ADD68620C	CONTROL ARM,RIGHT	DAIHATSU	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
60959	48069-87501-000	CONTROL ARM,RIGHT	DAIHATSU	HOH
62961	48068-87401 48068-87402 48068-87403 48068-87405	CONTROL ARM,RIGHT	DAIHATSU	HOH
71743	48610-0K010	CONTROL ARM,RIGHT	DAIHATSU	
94409	49068-97202	CONTROL ARM,RIGHT	DAIHATSU	HOH
25591	48069-87515	CONTROL ARM,LEFT	DAIHATSU	HOH
32360	48069-87507	CONTROL ARM,LEFT	DAIHATSU	HOH
47828	48069-87512	CONTROL ARM,LEFT	DAIHATSU	
60960	48068-87501-000	CONTROL ARM,LEFT	DAIHATSU	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
61642	48630-0K010	CONTROL ARM,LEFT	DAIHATSU	
62962	48069-87401 48069-87402 48069-87403 48069-87405	CONTROL ARM,LEFT	DAIHATSU	HOH
83932	5105041AE 05105041AB 05105041AI 05105041AA 5105041AA 5105041AC 5105041AH 05105041AE 05105041AF 05105041AD 05105041AH 5105041AI 05105041AC 5105041AG 5105041AD 05105041AG 5105041AB 5105041AF	CONTROL ARM,FRONT LEFT	DODGE/CHRYSLER/JEEP	HOH
24600	7674825 7591277	CONTROL ARM	FIAT	
27947	4225334	CONTROL ARM	FIAT	HOH
3292	7543760	CONTROL ARM	FIAT	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
9086	7705615 5939683	CONTROL ARM,RIGHT	FIAT	
31462	7626216	CONTROL ARM,LEFT/RIGHT	FIAT	
31545	7537989 5972145	CONTROL ARM,RIGHT	FIAT	
31786	4331252 4469175 2160503117 4468519	CONTROL ARM	FIAT	
53411	4364095 4332457 7536271	CONTROL ARM	FIAT	
53412	4362467	CONTROL ARM	FIAT	
53413	4402361 4402360 7558962	CONTROL ARM	FIAT	
62254	4 254 847	CONTROL ARM	FIAT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
67571	4327141	CONTROL ARM	FIAT	HOH
36235	7736515 7769901	CONTROL ARM,REAR RIGHT	FIAT	HOH
36234	7736514 7769900	CONTROL ARM,REAR LEFT	FIAT	HOH
30064	46454598 46539279	CONTROL ARM,FRONT RIGHT	FIAT	HOH
18755	46456050 46474557 60809814 46462627 7780444 60564479	CONTROL ARM,RIGHT	FIAT	
18757	46423823 82461082 71747916 7777240	CONTROL ARM,RIGHT	FIAT	
24631	46402682 46430003 46402684 7750978	CONTROL ARM,RIGHT	FIAT	
24633	46545661	CONTROL ARM,RIGHT	FIAT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
24634	46777741 46813841 51712407 51769073 46539000 46794065	CONTROL ARM,RIGHT	FIAT	HOH
31278	60501401	CONTROL ARM,RIGHT	FIAT	HOH
31419	7636996	CONTROL ARM,RIGHT	FIAT	
31426	50703129	CONTROL ARM,RIGHT	FIAT	
31466	7576422	CONTROL ARM,RIGHT	FIAT	HOH
31491	98810139 51727863	CONTROL ARM,RIGHT	FIAT	HOH
31493	50703231	CONTROL ARM,RIGHT	FIAT	HOH
31494	46454596 46546776	CONTROL ARM,RIGHT	FIAT	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31498	46779302	CONTROL ARM,RIGHT	FIAT	HOH
31500	46407373 93501181 7601062	CONTROL ARM,RIGHT	FIAT	HOH
31502	93501486 50700779	CONTROL ARM,RIGHT	FIAT	
31504	46764747 46522142 51832938	CONTROL ARM,RIGHT	FIAT	
42207	51834373	CONTROL ARM,RIGHT	FIAT	HOH
42222	55703627 51783056 3521.S6 3521.V5 51839039 55703231	CONTROL ARM,RIGHT	FIAT	HOH
47324	46177742	CONTROL ARM,RIGHT	FIAT	HOH
53415	46456189 98845032 46745365	CONTROL ARM,RIGHT	FIAT	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
7646	7705616 5939685	CONTROL ARM,LEFT	FIAT	HOH
18754	46456049 46474556 60809813 93501144 7780443 60564478 46462626	CONTROL ARM,LEFT	FIAT	
18756	46423822 82461081 71747915 7777239	CONTROL ARM,LEFT	FIAT	
24630	46402681 46430002 46402683 7750977	CONTROL ARM,LEFT	FIAT	
24632	46545660	CONTROL ARM,LEFT	FIAT	
24635	46777742 46813842 51712408 46539001 51747324 51769074 46794066	CONTROL ARM,LEFT	FIAT	
30063	46454597 46539278	CONTROL ARM,LEFT	FIAT	HOH
31277	60501402	CONTROL ARM,LEFT	FIAT	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31418	7636995	CONTROL ARM,LEFT	FIAT	
31424	50703128	CONTROL ARM,LEFT	FIAT	
31432	4356872 7576423	CONTROL ARM,LEFT	FIAT	HOH
31490	98810140 51727865	CONTROL ARM,LEFT	FIAT	HOH
31492	50703232	CONTROL ARM,LEFT	FIAT	HOH
31497	46779303	CONTROL ARM,LEFT	FIAT	HOH
31499	46407372 93501180 7601057	CONTROL ARM,LEFT	FIAT	HOH
31501	93501485 50700797	CONTROL ARM,LEFT	FIAT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31503	46764746 46525407 51832937	CONTROL ARM,LEFT	FIAT	
42132	46454595 46454062	CONTROL ARM,LEFT	FIAT	HOH
42206	51834375	CONTROL ARM,LEFT	FIAT	HOH
42220	51783057 55703629 518995367 3520.Y4 3520.W3 51839040 51874462	CONTROL ARM,LEFT	FIAT	HOH
53414	46456660 98845031	CONTROL ARM,LEFT	FIAT	HOH
12681	48530-31G25 1 954 600	CONTROL ARM	FORD	HOH
30065	1 214 912 1 207 448 1 146 131 1 212 808 1 436 095 1 436 170 2N11 3051 AE 2N11 3051 AH 2S61 3051 AD 2S61 3051 AH 2S61 3051 AJ 2S61 3051 DA DD32-34-300 2S613051AF	CONTROL ARM	FORD	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
30066	1 214 911 1 207 447 1 146 130 1 212 807 1 436 169 2N11 3042 AE 2N11 3042 AH 2S61 3042 AD 2S61 3042 AH 2S61 3042 AJ 2S61 3042 DA DD32-34-350 2S613042AF	CONTROL ARM	FORD	HOH
35892	1 061 659 1 317 609 1 136 072 1 329 730 1M51 5500 AB 98AG 5500 AG 1M51 5500 AA BP4K-28-C10B 31277305 31212503 8671921	CONTROL ARM	FORD	
79194	4 484 853 4 631 878 4 763 905 3L84 3A424 AC 4L84 3A424 AA 4L84 3A424 AB EC01-34-350F EC01-34-350G EC01-34-350H EC01-34-350J EC01-34-350K EC01-34-350L EC01-34-350M EC01-34-350N	CONTROL ARM,FRONT LEFT	FORD	HOH
79195	4 484 852 4 631 871 4 763 903 3L84 3A423 AC 4L84 3A423 AA 4L84 3A423 AB EC01-34-300F EC01-34-300G EC01-34-300H EC01-34-300J EC01-34-300K EC01-34-300L EC01-34-300M EC01-34-300N	CONTROL ARM,FRONT RIGHT	FORD	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
82958	1 532 421 1 540 724 1 737 309 1 712 696 1 518 904 1 708 222 1 520 778 1 700 809 8V51 3042 BA 8V51 3042 BF 8V51 3042 BG D651-34-300C D651-34-300 D651-34-300D	CONTROL ARM,FRONT RIGHT	FORD	HOH
82957	1 712 697 1 540 725 1 708 226 1 521 773 1 532 433 1 700 810 8V51 3051 BB 8V51 3051 BG D651-34-350D D651-34-350 D651-34-350C	CONTROL ARM,FRONT LEFT	FORD	HOH
34454	6W4Z 3084 AA 4W4Z 3084 AA XR8 56012 XR8 52090 XR8 1763	CONTROL ARM,RIGHT	FORD	
46710	1 469 024 1 507 181 7G9N 3A052 BA 7G9N 3A052 BB 31277344 31317662 31200775 31212781 TG9N 3A052 BA 1 460 694	CONTROL ARM,RIGHT	FORD	HOH
34453	6W4Z 3085 AA 4W4Z 3085 AA XR8 56013 XR8 1764 XR8 52091	CONTROL ARM,LEFT	FORD	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46709	1 469 026 1 507 182 7G9N 3A053 BA 7G9N 3A053 BB 31200776 31212782 31200563 31200448 30760720 31317661 31277343 1 460 693 1 466 188 6G9N 3A053 DG 6G9N 3A053 DH	CONTROL ARM,LEFT	FORD	
46834		CONTROL ARM KIT	FORD	
46836		CONTROL ARM KIT	FORD	
46835		CONTROL ARM KIT	FORD	
46838		CONTROL ARM KIT	FORD	
46833		CONTROL ARM KIT	FORD	
6028	1 090 738 1 073 215 98AG 3051 AK 1 344 968	CONTROL ARM,WITH BUSHINGS	FORD	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
18760	1 054 989 1 111 413 6 193 086 6 645 156 7 152 281	CONTROL ARM,WITH BUSHINGS	FORD	
18761	1 054 988 1 111 411 6 193 085 7 152 278 6 645 154	CONTROL ARM,WITH BUSHINGS	FORD	
18762	1 063 986 1 046 455 1 032 101 1 448 622 97KB 3051 EB 97KB 3051 EC 97KB 3051 AD 97KB 3051 AC 5012545	CONTROL ARM,WITH BUSHINGS	FORD	
18763	1 063 985 1 046 444 1 032 099 1 448 621 97KB 3042 AC 97KB 3042 EC 97KB 3042 AD 97KB 3042 EB 5012546	CONTROL ARM,WITH BUSHINGS	FORD	
18764	1 063 988 1 111 412 1 046 458 1 032 102 97KB 3051 FB 97KB 3051 BC 97KB 3051 BD 94FX 3051 BC	CONTROL ARM,WITH BUSHINGS	FORD	
18765	1 063 987 1 032 100 1 111 410 1 046 445 97KB 3042 BD 97KB 3042 BC 94FX 3024 BC 97KB 3042 FB	CONTROL ARM,WITH BUSHINGS	FORD	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25518	1L2Z-3085-AA	CONTROL ARM	FORD	
25519	1L2Z-3084-AA	CONTROL ARM	FORD	
30060	XS61 3042 BE	CONTROL ARM	FORD	
30061	XS61 3041 BE	CONTROL ARM	FORD	
30385	YS4Z 3079 BA 1 207 974 2M51 3051 BD 98AG 3051 AJ	CONTROL ARM	FORD	
30390	LE1S 713051 AM	CONTROL ARM	FORD	
31659	F78Z 3078 CA	CONTROL ARM	FORD	
31660	F78Z 3079 CA	CONTROL ARM	FORD	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
32373	2L2Z 3078 BA	CONTROL ARM	FORD	
32374	2L2Z 3079 BA	CONTROL ARM	FORD	
32407	XS6 13051 CE	CONTROL ARM	FORD	
32408	XS6 13051 BE	CONTROL ARM	FORD	
32409	7S4Z 3078 A	CONTROL ARM	FORD	
32410	7S4Z 3079 A	CONTROL ARM	FORD	
35231	1 114 825 6 608 832 92VB 3A053 AC	CONTROL ARM	FORD	
35236	1 114 826 6 608 830 92VB 3A052 AC	CONTROL ARM	FORD	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
35939	1 118 921 1 117 859 1S715 K743 AB 1S715 K743 AC	CONTROL ARM	FORD	
35946	1 118 920 1 117 857 1S715 K652 AB 1S715 K652 AC	CONTROL ARM	FORD	
35948	1 124 242 1 206 474 1S71 5K898 AG 1S71 5K898 AF	CONTROL ARM	FORD	
46674	1 207 446	CONTROL ARM	FORD	
47383	F5TZ 3083 A 1F60 35211 A 6L5Z 3085 AA 3L5Z 3083 AA 2L5Z 3083 AA	CONTROL ARM	FORD	
47385	E95Z 3079 A E9SZ 3085 A	CONTROL ARM	FORD	
47387	F5SZ 307B A E9SZ 3084 A	CONTROL ARM	FORD	
47388	F5TZ 3082 A F77Z 3082 CA 3L5Z 3084 AA 6L5Z 3084 AA 1F20 34211 B	CONTROL ARM	FORD	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
49484	F3XY 3079 A	CONTROL ARM	FORD	HOH
50355	4L8Z 3079 L EC01 34350 N	CONTROL ARM	FORD	HOH
50473	1F2Z 3078 AA	CONTROL ARM	FORD	HOH
50474	1F2Z 3079 AA	CONTROL ARM	FORD	HOH
50475	5L3Z 3085 C	CONTROL ARM	FORD	HOH
50476	5L3Z 3084 C	CONTROL ARM	FORD	HOH
53011	2L5Z 3082 AA	CONTROL ARM	FORD	
56601	6L8Z 3079 AA K80400	CONTROL ARM	FORD	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
56602	6L8Z 3078 AA K80399	CONTROL ARM	FORD	HOH
65285	1 344 966	CONTROL ARM	FORD	HOH
79924	1 377 449 1 381 443 1 387 628 1 426 770 6G915 K743X AA	CONTROL ARM	FORD	HOH
90745	6 867 577 93BB 5K652 AC	CONTROL ARM	FORD	HOH
7241	5 021 460 6 114 616 6 149 939 880X 3B376 DA	CONTROL ARM,WITH BEARINGS AND JOINT,RIGHT,BOTTOM FRONT AXLE	FORD	HOH
7242	5 021 461 6 114 617 6 149 940 6 194 369 83BB 3A053 BC 83BB 3A053 BD 83BB 3A053 BB 880X 3B377 DA 6 114 615	CONTROL ARM,WITH BEARINGS AND JOINT,LEFT,BOTTOM FRONT AXLE	FORD	HOH
46794	1 061 666 1 064 128 98AG 5K652 BG 98AG 5K652 AK	CONTROL ARM,REAR LEFT/RIGHT	FORD	
87091	1 702 970 1 857 345 1 865 168 1 866 068 AV61 3A423 LB BV61 3A423 AAB	CONTROL ARM,FRONT,RIGHT	FORD	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
87089	1 702 983 1 709 466 1 742 266 1 857 346 1 865 175 1 866 073 AV61 3A424 LB BV61 3A424 AAB	CONTROL ARM,FRONT,LEFT	FORD	
6496	1 637 182 1 637 183 5 021 458 880X 3B376 CA EBJ20	CONTROL ARM,RIGHT	FORD	
6552	1 058 279 7 351 747 6 525 843 6 615 742 95AB 3042 AB 92AB 3042 AA 92AB 3042 BA 94AB 3042 AA 95AB 3042 AE 1 796 820	CONTROL ARM,RIGHT	FORD	
30062	94FB 3042 CB 7 152 276 1 054 984 94FB 3042 CA 6 645 155	CONTROL ARM,RIGHT	FORD	HOH
30391	4M51 3A423 AD 1 362 652 1 570 284 1 420 858 1 488 110 4M51 3A424 AE 4M51 3A424 AF	CONTROL ARM,RIGHT	FORD	
31521	1 054 986 6 705 519 7 152 277 94FB 3042 DA 94FB 3042 DB	CONTROL ARM,RIGHT	FORD	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31524	1 070 337 7 152 269 94FB 3042 AB 94FB 3042 AD	CONTROL ARM,RIGHT	FORD	
31526	7 152 270 94FB 3042 BA	CONTROL ARM,RIGHT	FORD	
31529	1 063 233 1 020 219 1 046 038 1 071 690 96FB 3042 AH 96FB 3042 AJ 98FB 3042 BD 98FB 3042 BC 1 058 326	CONTROL ARM,RIGHT	FORD	
31533	1 020 214 1 046 039 1 063 226 1 046 278	CONTROL ARM,RIGHT	FORD	
31537	1 130 576	CONTROL ARM,RIGHT	FORD	
31542	1 630 152 1 630 154 1 632 764 1 632 766 1 640 853 1 656 748 5 021 462 880X 3B376 EA V85G B3078 AA V85G B3078 AB V85G B3A052 AB	CONTROL ARM,RIGHT	FORD	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31544	1 141 293 1 102 948 YS71 3042 AB YS71 3042 AA	CONTROL ARM,RIGHT	FORD	
31547	1 149 802 1 139 926 1 128 483 1 203 923 1 311 416 1S71 3042 AH 1S71 3042 AN 1S71 3042 AL 1S71 3042 AK 1S71 3042 AM C2S 39661 1 522 081 1 131 386 LE1S 713042 AM	CONTROL ARM,RIGHT	FORD	
31549	7 312 345	CONTROL ARM,RIGHT	FORD	HOH
31551	6 087 888 90AU 3A052 AA K8421	CONTROL ARM,RIGHT	FORD	HOH
31554	4 540 774 4 372 130 4 042 022 YC15 3A052 AH YC15 3A052 AL YC15 3A052 AM 6C11 3A052 EA	CONTROL ARM,RIGHT	FORD	HOH
31560	1 332 454 4 366 973 1 355 048 2T14 3042 BF 4T16 3042 AA 2T14 3042 BJ	CONTROL ARM,RIGHT	FORD	HOH
31562	K8710T	CONTROL ARM,RIGHT	FORD	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31563	1 116 578	CONTROL ARM,RIGHT	FORD	
31565	K8724T	CONTROL ARM,RIGHT	FORD	HOH
31567	K8728T	CONTROL ARM,RIGHT	FORD	HOH
31586	F5RZ 3078 B	CONTROL ARM,RIGHT	FORD	HOH
32406	7G9N 3A052 B	CONTROL ARM,RIGHT	FORD	HOH
34449	6W4Z 3078 AA	CONTROL ARM,RIGHT	FORD	HOH
34452	5F2Z 3078 BA	CONTROL ARM,RIGHT	FORD	HOH
34455	5W1Z 3078 AA 6W1Z 3078 D	CONTROL ARM,RIGHT	FORD	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
34458	4L3Z 3078 CA	CONTROL ARM,RIGHT	FORD	
42205	F77A 3078 FA	CONTROL ARM,RIGHT	FORD	HOH
46708	1 495 683 1 371 231 1 438 253 1 553 239 6C11 3A052 BC 6C11 3A052 BA 6C11 3A052 BB 6C11 3A052 BD	CONTROL ARM,RIGHT	FORD	HOH
47382	F75Z 3084 BA XL3Z 2084 AA XL3Z 3084 BA 5L3Z 3084C	CONTROL ARM,RIGHT	FORD	HOH
47389	F65Z-3084-AB 5L3Z-3084-B	CONTROL ARM,RIGHT	FORD	HOH
6497	1 637 184 1 637 185 5 021 459 880X 3B377 CA EBJ21	CONTROL ARM,LEFT	FORD	
6551	1 058 280 7 351 748 6 525 844 6 615 743 6 770 225 95AB 3051 AB 91AB 3051 AD 92AB 3051 AA 92AB 3051 BA 95AB 3051 AE 1 796 823	CONTROL ARM,LEFT	FORD	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
30059	7 152 279 1 054 985 94FB 3051 CA 94FB 3051 CB	CONTROL ARM,LEFT	FORD	HOH
30392	4M51 3A424 AD 1 362 651 1 570 748 3M51 3K209 BA 30760280 31201181 31262039 31277463 1 570 285 1 488 111 1 420 795 4M51 3A423 AE 4M51 3A423 AF	CONTROL ARM,LEFT	FORD	
31522	1 054 987 6 705 520 7 152 280 94FB 3051 DA 94FB 3041 DB	CONTROL ARM,LEFT	FORD	HOH
31525	1 070 338 7 152 271 94FB 3051 AB 94FB 3051 AD	CONTROL ARM,LEFT	FORD	HOH
31527	7 152 272 94FB 3051 BA	CONTROL ARM,LEFT	FORD	HOH
31530	1 046 072 1 020 221 1 063 246 1 071 702 96FB 3051 AH 96FB 3051 AJ 98FB 3051 BD 98FB 3051 BC 1 058 332	CONTROL ARM,LEFT	FORD	HOH
31534	1 020 220 1 046 073 1 063 248	CONTROL ARM,LEFT	FORD	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31535	1 130 577	CONTROL ARM,LEFT	FORD	HOH
31539	81AB 3A053 AC 6 087 889 6 115 336	CONTROL ARM,LEFT	FORD	HOH
31541	1 630 153 1 630 155 1 632 765 1 632 767 1 640 854 1 656 749 5 021 463 880X 3B377 EA V85G B3079 AA V85G B3079 AB V85G B 3A053 AB	CONTROL ARM,LEFT	FORD	HOH
31543	1 141 294 1 209 949 YS71 3051 AB YS71 3051 AA	CONTROL ARM,LEFT	FORD	
31546	1 149 803 1 139 928 1 116 579 1 203 924 1 311 417 1S71 3051 AE 1S71 3051 AN 1S71 3051 AL 1S71 3051 AK 1S71 3051 AM C2 S39662 1 522 130	CONTROL ARM,LEFT	FORD	
31548	7 312 346	CONTROL ARM,LEFT	FORD	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31550	EIFZ 3079 A K8423	CONTROL ARM,LEFT	FORD	
31553	4 540 775 4 372 131 4 042 023 YC15 3A053 AL YC15 3A053 AH YC15 3A053 AM 6C11 3A053 EA	CONTROL ARM,LEFT	FORD	
31559	1 332 455 4 366 974 1 355 050 2T14 3051 BF 4T16 3051 AA 2T14 3051 BH	CONTROL ARM,LEFT	FORD	
31561	K8708T	CONTROL ARM,LEFT	FORD	
31564	K8722T	CONTROL ARM,LEFT	FORD	
31566	K8726T	CONTROL ARM,LEFT	FORD	
31585	F5RZ 3079 B	CONTROL ARM,LEFT	FORD	
32405		CONTROL ARM,LEFT	FORD	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
34450	6W4Z 3079 AA	CONTROL ARM,LEFT	FORD	HOH
34451	5F2Z 3079 BA	CONTROL ARM,LEFT	FORD	HOH
34456	5W1Z 3079 AA 6W1Z 3079 D	CONTROL ARM,LEFT	FORD	HOH
34457	4L3Z 3079 CA	CONTROL ARM,LEFT	FORD	
42204	F77A 3079 FA	CONTROL ARM,LEFT	FORD	HOH
46707	1 495 684 1 371 228 1 438 254 1 553 250 6C11 3A053 BC 6C11 3A053 BA 6C11 3A053 BB 6C11 3A053 BD	CONTROL ARM,LEFT	FORD	HOH
47381	F75Z 3085 BA XL3Z 3085 AA F65Z 3085 BA 5L3Z 3085C	CONTROL ARM,LEFT	FORD	HOH
47390	F65Z-3085-AB 5L3Z-3085B	CONTROL ARM,LEFT	FORD	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
76502	1 046 279	CONTROL ARM,LEFT	FORD	HOH
597	1 090 730 1 073 214 98AG 3042 AK	CONTROL ARM,LEFT RIGHT	FORD	HOH
6037	1 023 026 1 043 159 6 954 470 1 030 277 93BB 3042 BC 97BG 3042 CA 97BG 3042 AA	CONTROL ARM,RIGHT,WITH BALL JOINT	FORD	
6036	1 023 028 1 043 158 6 954 471 1 030 278 93BB 3051 BC 97BG 3051 CA 97BG 3051 AA	CONTROL ARM,LEFT,WITH BALL JOINT	FORD	
48936	1 201 383 C2S 37074	CONTROL ARM	FORD/JAGUAR	HOH
48941	1 201 384 C2S 39662	CONTROL ARM	FORD/JAGUAR	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
78332	2W4Z 3078 AA XR8 51824 XR8 22851 XR8 17609 XR8 46022 6W4Z-3078AA	CONTROL ARM,RIGHT	FORD/JAGUAR	
78333	2W4Z 3079 AA XR8 51825 XR8 17610 XR8 46023 XR8 22852 XR8 8758	CONTROL ARM,LEFT	FORD/JAGUAR	
47384	F77C 3082 CA 3L5Z 3078 AA 1F613-42-111	CONTROL ARM	FORD/MAZDA	
47386	1L5Z 3079 AA 1F61-35-211	CONTROL ARM	FORD/MAZDA	
18759	1 330 238 1 045 655 1 021 219 1 063 236 1 015 260 1 071 694 96FB 3042 BF 98FB 3042 CD 4S61 3042 CA 96FB 3042 BG 98FB 3042 CC 1E01-34-300E 1E01-34-300D 1E01-34-300B 1E01-34-300A 1E01-34-300F	CONTROL ARM,RIGHT	FORD/MAZDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
18758	1 330 239 1 063 255 1 072 279 1 021 220 1 045 656 96FB 3051 BG 98FB 3051 CD 4S61 3051 CA 96FB 3051 BF 98FB 3051 CC 1E01-34-350A 1E01-34-350D 1E01-34-350E 1E01-34-350B 1E01-34-350F	CONTROL ARM,LEFT	FORD/MAZDA	HOH
50470	XF5Z 3078 AA 54500-7B000	CONTROL ARM,RIGHT	FORD/NISSAN	HOH
50469	XF5Z 3079 AA 54501-7B000	CONTROL ARM,LEFT	FORD/NISSAN	HOH
25253	1 348 192 1 328 381 1 234 375 1 355 151 1 332 075 1 477 860 1 328 671 4M51 3A424 AB 3M51 3A424 AH 3M51 3A424 AF 4M51 3A424 AC 4M51 3A424 AA 4M51 3A424 BA 3M51 3A424 AG 3M51 3A424 AJ 30730829 30714422 31212979 30748231	CONTROL ARM,LEFT	FORD/VOLVO	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25258	1 332 074 1 328 670 1 348 191 1 355 149 1 328 380 1 234 371 1 362 650 1 477 858 3M51 3A423 AG 4M51 3A423 AA 4M51 3A423 AC 3M51 3A423 AJ 4M51 3A423 AB 3M51 3A423 AF 3M51 3A423 AH 4M51 3A423 BA 3074823-0 3121298-0 3073083-0 1 570 750 1 254 310 1 305 341 1 309 148	CONTROL ARM,RIGHT	FORD/VOLVO	
20124	1 105 524 1 061 668 98AG5 K743 AF YS415 K743 AB C236-28-500A BP4K-28-500C 30683067	CONTROL ARM,WITH BUSHINGS,L=280MM	FORD/VOLVO/MAZDA	
11837	7M0 407 152 B 1 012 632 95VW 3078 AC	CONTROL ARM,RIGHT	FORD/VW	
6498	5 021 464 880X 3B376 FA 6 194 368	CONTROL ARM,WITH BEARINGS AND JOINT,RIGHT,BOTTOM FRONT AXLE	FROD	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
6499	5 021 465 880X 3B377 FA 6 194 370	CONTROL ARM,WITH BEARINGS AND JOINT,LEFT,BOTTOM FRONT AXLE	FROD	
11691	03 52 170	CONTROL ARM,LEFT	GM	HOH
31532	10 420 753	CONTROL ARM,RIGHT	GM	HOH
44944	*275-11 10 420 754	CONTROL ARM,LEFT	GM	HOH
14520	13 318 885	CONTROL ARM	GM	HOH
50477	10 301 559 10 328 906	CONTROL ARM	GM	HOH
50478	10 301 560 10 328 905	CONTROL ARM	GM	HOH
46668	15 218 621	CONTROL ARM	GM	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46669	15 218 622	CONTROL ARM	GM	
50483	15 661 507 15 979 277 93 213 427	CONTROL ARM	GM	
50484	15 661 508 15 596 694 93 213 428	CONTROL ARM	GM	
57954	25 918 964	CONTROL ARM	GM	
57955	25 918 965	CONTROL ARM	GM	
64838	93 390 601	CONTROL ARM	GM	
64839	93 390 602	CONTROL ARM	GM	
67181	15 777 767 15 018 807 520-141	CONTROL ARM	GM	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
67182	15 777 768 15 018 808 520-142	CONTROL ARM	GM	
31214	10 344 931	CONTROL ARM,RIGHT	GM	
31588	14 026 582	CONTROL ARM,RIGHT	GM	
78615	22 981 337	CONTROL ARM,RIGHT	GM	
78616	20 759 935 20 768 758	CONTROL ARM,RIGHT	GM	
78619	23 121 591	CONTROL ARM,RIGHT	GM	
78623	22 979 576	CONTROL ARM,RIGHT	GM	
31587	14 026 581	CONTROL ARM,LEFT	GM	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
47132	10 344 930	CONTROL ARM,LEFT	GM	
78614	22 981 336	CONTROL ARM,LEFT	GM	
78617	20 759 936 20 768 759	CONTROL ARM,LEFT	GM	
78618	23 121 590	CONTROL ARM,LEFT	GM	
78622	22 979 575	CONTROL ARM,LEFT	GM	
52926	25 699 468 25 766 509 25 766 510 88 986 633	CONTROL ARM	GM	
50480	15 080 913 15 298 272 25 786 774 15 858 682 8-15858-682-0	CONTROL ARM	GM/ISUZU	
50481	15 080 914 15 298 273 25 786 775 15 858 683 8-15858-683-0	CONTROL ARM	GM/ISUZU	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31742	44 01 852 44 01 940 44 04 047 45 00 092 09 109 852 09 109 940 09 112 047 09 160 392 77 00 302 118 77 00 309 189 82 00 270 055 54501-00QAC 54501-00QAD 54501-00QAE	CONTROL ARM,LEFT	GM/NISSAN/RENAULT/OPEL	
73184	51350-SWA-E01	CONTROL ARM,RIGHT	HONDA	
82964	51360-SWA-E01	CONTROL ARM,LEFT	HONDA	
33320	51450-SFE-003	CONTROL ARM,RIGHT	HONDA	
33319	51460-SFE-003	CONTROL ARM,LEFT	HONDA	
6743	51360-S04-G00	CONTROL ARM	HONDA	
6744	51350-S04-G00	CONTROL ARM	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
29652	51360-5NA-A03	CONTROL ARM	HONDA	
29653	51450-5DA-A01	CONTROL ARM	HONDA	
29654	51360-SEN-003	CONTROL ARM	HONDA	
31391	52360-S04-000	CONTROL ARM	HONDA	
31392	52350-S04-000	CONTROL ARM	HONDA	
31573	51360-SA5-013 51360-SA5-003 51360-SA5-000	CONTROL ARM	HONDA	
32031	52930-SE0-000	CONTROL ARM	HONDA	
32032	52930-SE0-043	CONTROL ARM	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
32033	51350-SA0-030 51350-SA0-010	CONTROL ARM	HONDA	
32034	51360-SA0-010 51360-SA0-030	CONTROL ARM	HONDA	
32035	51460-SDA-A03	CONTROL ARM	HONDA	
32036	51450-SDA-A03	CONTROL ARM	HONDA	
39047	51360-SDA-A01	CONTROL ARM	HONDA	
39048	51350-SDA-A01	CONTROL ARM	HONDA	
46732	51350-TG0-T02 51350-TG5-C01	CONTROL ARM	HONDA	
56607	51350-S5A-306	CONTROL ARM	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
62273	51355-SH3-010	CONTROL ARM	HONDA	
62274	51365-SH3-010	CONTROL ARM	HONDA	
62972	52350-SO4-000	CONTROL ARM	HONDA	
75852	51360-SHJ-A03	CONTROL ARM	HONDA	
82941	51360-S5A-0A3	CONTROL ARM	HONDA	
83178	52390-SEA-013 52390-SEA-901	CONTROL ARM	HONDA	
89880	52341-S04-000 52341-S04-A00	CONTROL ARM	HONDA	
89881	52390-S9A-980 52390-S9A-981	CONTROL ARM	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31390	52390-SE0-023 52390-SE0-043 52390-SE0-033 52390-SE0-013	CONTROL ARM,REAR	HONDA	HOH
6740	51450-S04-013 51450-S04-023 51450-S01-023 51450-S01-A02 K90450	CONTROL ARM,RIGHT	HONDA	
12122	51450-SH3-A01 51450-SH3-A02 51450-SH3-A03 51450-SH3-003 51450-SH3-013 51450-SH3-030 51450-SH3-010 51450-SH3-020 51450-SK7-043 51450-SH3-023 51450-SH3-000	CONTROL ARM,RIGHT	HONDA	
12124	51450-SV4-000 51450-SV4-A00	CONTROL ARM,RIGHT	HONDA	
12127	51355-SV4-000 51355-SV7-A00	CONTROL ARM,RIGHT	HONDA	HOH
12128	51450-SM4-023 51450-SM4-A03 51450-SM4-013 51450-SM1-A03 51450-SM1-A02 51450-SM1-A01 K9815	CONTROL ARM,RIGHT	HONDA	
12130	51459-SE0-003 51459-SE0-000	CONTROL ARM,RIGHT	HONDA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
12135	53540-SM4-003	CONTROL ARM,RIGHT	HONDA	HOH
16802	51355-S1A-E00 51355-S84-A00	CONTROL ARM,FRONT,RIGHT,WITH BUSHINGS	HONDA	
16804	51450-S10-020 K80883	CONTROL ARM,RIGHT	HONDA	
16806	51450-S84-A01 K9672R	CONTROL ARM,RIGHT	HONDA	
16808	51450-SR3-013 51450-SR3-023 51450-SR3-A02 51450-SR3-003 51450-SR0-A02 K90448	CONTROL ARM,RIGHT	HONDA	
25170	51450-SP0-023 51450-SP0-033 51450-SP0-A01 51450-SP0-A02	CONTROL ARM,RIGHT	HONDA	HOH
25521	51450-SO4-023 51450-SO1-023 51450-SO4-013	CONTROL ARM,RIGHT	HONDA	HOH
25522	52390-SM4-043 52390-SM1-033 52390-SM4-033 52390-SM4-A04 52390-SM1-A03	CONTROL ARM,RIGHT	HONDA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25525	51350-671-003 51350-671-033	CONTROL ARM,RIGHT	HONDA	
25528	51459-SEO-000 51459-SEO-003	CONTROL ARM,RIGHT	HONDA	
25531	52390-SR3-A00 52390-SR0-A00 52390-SR3-023 52390-SR3-000	CONTROL ARM,RIGHT	HONDA	
25532	51450-SDA-A01 K620617	CONTROL ARM,RIGHT	HONDA	
31385	51350-S9A-A01 51350-SCA-S01 51350-SCA-A01 51350-S9A-020 51350-S9A-010	CONTROL ARM,RIGHT	HONDA	
31387	51350-SAA-E01 51350-SEL-T01 51350-SAA-013	CONTROL ARM,RIGHT	HONDA	
31389	51350-SX8-T01	CONTROL ARM,RIGHT	HONDA	
31591	51350-SA5-020	CONTROL ARM,RIGHT	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31595	51460-SX8-T01	CONTROL ARM,RIGHT	HONDA	
31597	51361-SB2-013 GSJ 228	CONTROL ARM,RIGHT	HONDA	
31599	51360-SDA-A03	CONTROL ARM,RIGHT	HONDA	
31601	51360-SAG-C01	CONTROL ARM,RIGHT	HONDA	
31602	51400-SR0-A00	CONTROL ARM,RIGHT	HONDA	
32004	51350-SEN-C01	CONTROL ARM,RIGHT	HONDA	
32075	51350-S9A-P01	CONTROL ARM,RIGHT	HONDA	
46728	51350-TA0-000	CONTROL ARM,RIGHT	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46730	51350-SNA-A03 51350-SNA-903	CONTROL ARM,RIGHT	HONDA	
46733	51350-SWA-A01	CONTROL ARM,RIGHT	HONDA	
46736	51510-TA0-A03	CONTROL ARM,RIGHT	HONDA	
50487	51350-S5A-A03 51350-S5A-A10 51350-S5A-E50	CONTROL ARM,RIGHT	HONDA	
62950	51350-S5A-030	CONTROL ARM,RIGHT	HONDA	
62951	51350-S10-020 51350-S10-A00 51350-S10-G00	CONTROL ARM,RIGHT	HONDA	
67578	51360-SFE-000	CONTROL ARM,RIGHT	HONDA	
76517	51360-T0A-T00	CONTROL ARM,RIGHT	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
76519	51360-S04-023	CONTROL ARM,RIGHT	HONDA	HOH
76521	51360-S10-023	CONTROL ARM,RIGHT	HONDA	HOH
76524	51360-S9A-023	CONTROL ARM,RIGHT	HONDA	HOH
76526	51360-S5A-023	CONTROL ARM,RIGHT	HONDA	HOH
82953	51350-TF0-030	CONTROL ARM,RIGHT	HONDA	HOH
82956	51450-584-A01 51450-S1A-E01	CONTROL ARM,RIGHT	HONDA	HOH
85906	51350-TR0-A01	CONTROL ARM,RIGHT	HONDA	HOH
6739	51460-S04-013 51460-S04-023 51460-S01-023 51460-S01-A02 K90451	CONTROL ARM,LEFT	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
12123	51460-SH3-A03 51460-SH3-A02 51460-SH3-A01 51460-SH3-003 51460-SH3-013 51460-SH3-030 51460-SH3-010 51460-SH3-020 51460-SK7-043 51460-SH3-023 51460-SH3-000	CONTROL ARM,LEFT	HONDA	
12125	51460-SV4-000 51460-SV4-A00	CONTROL ARM,LEFT	HONDA	
12126	51365-SV4-000 51365-SV7-A00	CONTROL ARM,LEFT	HONDA	HOH
12129	51460-SM4-013 51460-SM4-023 51460-SM4-A02 51460-SM4-A03 51460-SM1-A03 K9816	CONTROL ARM,LEFT	HONDA	
12131	51469-SE0-003 51469-SE0-000	CONTROL ARM,LEFT	HONDA	HOH
16803	51365-S1A-E00 51365-S84-A00	CONTROL ARM,FRONT,LEFT,WITH BUSHINGS	HONDA	
16805	51460-S10-020 K80884	CONTROL ARM,LEFT	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
16807	51460-S84-A01 K9673L	CONTROL ARM,LEFT	HONDA	
16809	51460-SR3-013 51460-SR3-023 51460-SR3-A02 51460-SR0-A02 51460-SR3-003 K90449	CONTROL ARM,LEFT	HONDA	
25169	51460-SP0-023 51460-SP0-033 51460-SP0-A01 51460-SP0-A02	CONTROL ARM,LEFT	HONDA	HOH
25520	51460-SO4-023 51460-SO1-023 51460-SO4-013	CONTROL ARM,LEFT	HONDA	HOH
25523	52400-SM4-043 52400-SM1-033 52400-SM4-033 52400-SM4-A04 52400-SM1-A03	CONTROL ARM,LEFT	HONDA	HOH
25526	51360-671-003	CONTROL ARM,LEFT	HONDA	HOH
25527	51469-SEO-000 51469-SEO-003	CONTROL ARM,LEFT	HONDA	HOH
25529	51360-671-033	CONTROL ARM,LEFT	HONDA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25530	52400-SR3-O23 52400-SR3-000 52400-SR0-A00	CONTROL ARM,LEFT	HONDA	
25533	51460-SDA-A01 K620616	CONTROL ARM,LEFT	HONDA	
31384	51360-S9A-A01 51360-SCA-S00 51360-S9A-A00 51360-SCA-A00 51360-S9A-010 51360-S9A-A02	CONTROL ARM,LEFT	HONDA	
31386	51360-SAA-E01 51360-SEL-T01 51360-SAA-013	CONTROL ARM,LEFT	HONDA	
31388	51360-SX8-T01	CONTROL ARM,LEFT	HONDA	
31394	52360-SH3-A12	CONTROL ARM,LEFT	HONDA	
31568	51350-SA5-000 51350-SA5-003 51350-SA5-013	CONTROL ARM,LEFT	HONDA	
31592	51360-SA5-020	CONTROL ARM,LEFT	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31593	51450-SX8-T01	CONTROL ARM,LEFT	HONDA	
31596	51351-SB2-013 GSJ 227	CONTROL ARM,LEFT	HONDA	
31598	51350-SDA-A03	CONTROL ARM,LEFT	HONDA	
31600	51350-SAG-C01	CONTROL ARM,LEFT	HONDA	
32076	51360-S9A-P01	CONTROL ARM,LEFT	HONDA	
44828	51360-S10-G00 51360-S10-A00 51360-S10-020	CONTROL ARM,LEFT	HONDA	
46727	51360-TA0-000	CONTROL ARM,LEFT	HONDA	
46729	51360-SNA-A03 51360-SNA-903	CONTROL ARM,LEFT	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46731	51360-TG0-T02 51360-TG5-C01	CONTROL ARM,LEFT	HONDA	
46734	51360-SWA-A01	CONTROL ARM,LEFT	HONDA	
46735	51520-TA0-A03	CONTROL ARM,LEFT	HONDA	
50488	51360-S5A-A03 51360-S5A-A10 51360-S5A-E50	CONTROL ARM,LEFT	HONDA	
62949	51360-S5A-030	CONTROL ARM,LEFT	HONDA	
67579	51350-SFE-000	CONTROL ARM,LEFT	HONDA	
73810	52400-SP0-013	CONTROL ARM,LEFT	HONDA	
76516	51360-SEN-C01	CONTROL ARM,LEFT	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
76518	51350-T0A-T00	CONTROL ARM,LEFT	HONDA	
76520	51350-S04-023	CONTROL ARM,LEFT	HONDA	
76522	51350-S10-023	CONTROL ARM,LEFT	HONDA	
76523	51350-S9A-023	CONTROL ARM,LEFT	HONDA	
76525	51350-S5A-023	CONTROL ARM,LEFT	HONDA	
82952	51360-TF0-030	CONTROL ARM,LEFT	HONDA	
82955	51460-584-A01 51460-S1A-E01	CONTROL ARM,LEFT	HONDA	
85905	51360-TR0-A01 51360-TS0-A01	CONTROL ARM,LEFT	HONDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25524	52390-SEO-043	CONTROL ARM,LEFT RIGHT	HONDA	HOH
21596	52390-S84-A01	CONTROL ARM,FRONT,WITH BEARING AND JOINT	HONDA	HOH
33318	51520-TAO-A03	CONTROL ARM	HONDA	HOH
19916	51350-SR3-020 51350-SR3-010 51350-SR3-A01 51350-ST3-G00 51350-ST7-010 GSJ835 RBJ102230 51350-ST3-E02	CONTROL ARM,RIGHT	HONDA/ROVER	
19917	51360-SR3-020 51360-SR3-010 51360-SR3-A02 51360-ST3-G00 51360-ST7-010 GSJ836 RBJ102220 51360-ST3-E02	CONTROL ARM,LEFT	HONDA/ROVER	
17561	24531-42880	CONTROL ARM,FRONT,WITH BUSHINGS	HYUNDAI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
20234	54430-4B000 54430-43000 54430-43001 54430-43002 54430-43003 54430-43004 54430-43005	CONTROL ARM,WITH BUSHINGS	HYUNDAI	
20235	55220-22000	CONTROL ARM	HYUNDAI	
20256	54410-4B000 54410-43000 54410-43001 54410-43002 54410-43003 54410-43004 54410-43005	CONTROL ARM,WITH BUSHINGS	HYUNDAI	
20259	55210-22000	CONTROL ARM	HYUNDAI	
25155	54501-38011 54501-38611 54501-38620	CONTROL ARM	HYUNDAI	
25156	54500-38011 54500-38611 54500-38620	CONTROL ARM	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31454	66133-03307	CONTROL ARM	HYUNDAI	
32361	54500-22500	CONTROL ARM	HYUNDAI	
32362	54501-22500	CONTROL ARM	HYUNDAI	
42197	54500-25500	CONTROL ARM	HYUNDAI	
42198	54501-25500	CONTROL ARM	HYUNDAI	
42200	55270-2H000	CONTROL ARM	HYUNDAI	
42201	55280-2H000	CONTROL ARM	HYUNDAI	
42202	55250-2H000	CONTROL ARM	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
43836	54500-0X000 54500-0X100 54500-0X200 54500-0X300	CONTROL ARM	HYUNDAI	
52045	54420-3F601 54420-3F602	CONTROL ARM	HYUNDAI	
60284	57724-2S000	CONTROL ARM	HYUNDAI	
61491	54501-0X200 54501-0X000 54501-0X300	CONTROL ARM	HYUNDAI	
62357	54501-3A201 54501-3A100	CONTROL ARM	HYUNDAI	
62382	54500-26000	CONTROL ARM	HYUNDAI	
64840	54503-24001T	CONTROL ARM	HYUNDAI	
66363	54400-H1150	CONTROL ARM	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
66364	54401-H1150	CONTROL ARM	HYUNDAI	
66366	54512-H1002 54502-H1002	CONTROL ARM	HYUNDAI	
66368	54503-H1002	CONTROL ARM	HYUNDAI	
66369	54500-2S000	CONTROL ARM	HYUNDAI	
66371	54501-2S000	CONTROL ARM	HYUNDAI	
66467	55201-25000 55201-25100	CONTROL ARM	HYUNDAI	
67809	54400-4A820	CONTROL ARM	HYUNDAI	
72914	MB109630A	CONTROL ARM	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
75849	54501-4D102 54501-4D100 54501-4D101	CONTROL ARM	HYUNDAI	HOH
75851	54500-4D102 54500-4D101 54500-4D100	CONTROL ARM	HYUNDAI	HOH
82664	55202-25000	CONTROL ARM	HYUNDAI	HOH
89601	54501-3Z000	CONTROL ARM	HYUNDAI	HOH
93639		CONTROL ARM	HYUNDAI	HOH
31605	55210-38000	CONTROL ARM,REAR	HYUNDAI	HOH
63921	54501-4L000 54501-1R000	CONTROL ARM,FRONT RIGHT	HYUNDAI	
75752	54501-2D002AS	CONTROL ARM,FRONT,RIGHT	HYUNDAI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
63920	54500-4L000 54500-1R000	CONTROL ARM,FORNT LEFT	HYUNDAI	
75754	54500-2D002AS	CONTROL ARM,FRONT,LEFT	HYUNDAI	HOH
21291	54501-02000 54501-02051 54501-02050 54501-02052	CONTROL ARM,RIGHT	HYUNDAI	HOH
22005	54503-24001 54503-24000	CONTROL ARM,RIGHT	HYUNDAI	HOH
22009	54501-25000	CONTROL ARM,RIGHT	HYUNDAI	HOH
25159	54501-2D000 54501-2D002 54501-2D500 54501-2D501	CONTROL ARM,RIGHT	HYUNDAI	HOH
25432	54501-1C000	CONTROL ARM,RIGHT	HYUNDAI	HOH
31450	54420-38000	CONTROL ARM,RIGHT	HYUNDAI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31453	54501-22000 54501-22100 54501-22200	CONTROL ARM,RIGHT	HYUNDAI	
31456	54501-2E000 54501-2E010 54501-2E030 54501-2E001 54501-1F000 54501-2E100	CONTROL ARM,RIGHT	HYUNDAI	
31506	54501-4A600 54501-4A000	CONTROL ARM,RIGHT	HYUNDAI	
31508	54401-H1100	CONTROL ARM,RIGHT	HYUNDAI	
31604	55120-38000	CONTROL ARM,RIGHT	HYUNDAI	
31608	54401-4A000	CONTROL ARM,RIGHT	HYUNDAI	
31610	54501-17000	CONTROL ARM,RIGHT	HYUNDAI	
31612	54501-2H000	CONTROL ARM,RIGHT	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31614	54501-3K000 54501-3K060 54501-3K500	CONTROL ARM,RIGHT	HYUNDAI	
43868	54502-26000	CONTROL ARM,RIGHT	HYUNDAI	
50922	54540-4B001 54540-4B000	CONTROL ARM,RIGHT	HYUNDAI	
52301	54501-2Y000	CONTROL ARM,RIGHT	HYUNDAI	
61490	54501-47000	CONTROL ARM,RIGHT	HYUNDAI	
61493	54501-1E100	CONTROL ARM,RIGHT	HYUNDAI	
62275	54501-26XXX	CONTROL ARM, RIGHT	HYUNDAI	
62276	54501-2EXXX	CONTROL ARM, RIGHT	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
62380	54501-38000 54501-38010	CONTROL ARM,RIGHT	HYUNDAI	
63204	54501-29500 54501-29000	CONTROL ARM,RIGHT	HYUNDAI	
66466	55220-25000	CONTROL ARM,RIGHT	HYUNDAI	
69550	54501-4H000	CONTROL ARM,RIGHT	HYUNDAI	
69553	54501-1Y000 54501-1Y100	CONTROL ARM	HYUNDAI	
78251	54501-0U000	CONTROL ARM,RIGHT	HYUNDAI	
82269	54420-3K000	CONTROL ARM,RIGHT	HYUNDAI	
82947	54501-1C010	CONTROL ARM,RIGHT	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
82966	54501-1J500 54501-1J700	CONTROL ARM,RIGHT	HYUNDAI	
84257	54500-B4000	CONTROL ARM,RIGHT	HYUNDAI	
88322	54501-07161 54501-07160	CONTROL ARM,RIGHT	HYUNDAI	
96405	54501-4A801	CONTROL ARM,RIGHT	HYUNDAI	
20255	54510-43150	CONTROL ARM,LEFT	HYUNDAI	
21989	54500-02050 54500-02051 54500-02052 54500-02000	CONTROL ARM,LEFT	HYUNDAI	
22003	54502-24001 54502-24000	CONTROL ARM,LEFT	HYUNDAI	
22007	54500-25000	CONTROL ARM,LEFT	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25173	54500-2D000 54500-2D002 54500-2D500 54500-2D501	CONTROL ARM,LEFT	HYUNDAI	
25431	54500-1C000	CONTROL ARM,LEFT	HYUNDAI	
31449	54410-38000	CONTROL ARM,LEFT	HYUNDAI	
31452	54500-22000 54500-22100 54500-22200	CONTROL ARM,LEFT	HYUNDAI	
31455	54500-2E000 54500-2E010 54500-2E030 54500-2E001 54500-1F000 54500-2E100	CONTROL ARM,LEFT	HYUNDAI	
31505	54500-4A600 54500-4A000	CONTROL ARM,LEFT	HYUNDAI	
31507	54400-H1100	CONTROL ARM,LEFT	HYUNDAI	
31603	55110-38000	CONTROL ARM,LEFT	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31606	54500-33010 54500-33020	CONTROL ARM,LEFT	HYUNDAI	
31607	54400-4A000	CONTROL ARM,LEFT	HYUNDAI	
31609	54500-17000	CONTROL ARM,LEFT	HYUNDAI	
31611	54500-2H000	CONTROL ARM,LEFT	HYUNDAI	
31613	54500-3K000 54500-3K060 54500-3K500	CONTROL ARM,LEFT	HYUNDAI	
50921	54510-4B001 54510-4B000	CONTROL ARM,LEFT	HYUNDAI	
52300	54500-2Y000	CONTROL ARM,LEFT	HYUNDAI	
61489	54500-47000	CONTROL ARM,LEFT	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
61492	54500-1E100	CONTROL ARM,LEFT	HYUNDAI	
62277	54500-2EXXX	CONTROL ARM,LEFT	HYUNDAI	
62278	54500-26XXX	CONTROL ARM,LEFT	HYUNDAI	
62379	54500-38000 54500-38010	CONTROL ARM,LEFT	HYUNDAI	
62384	54501-26000	CONTROL ARM,LEFT	HYUNDAI	
63203	54500-29500 54500-29000	CONTROL ARM,LEFT	HYUNDAI	
69549	54500-4H000	CONTROL ARM,LEFT	HYUNDAI	
78250	54500-0U000	CONTROL ARM,LEFT	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
82268	54410-3K000	CONTROL ARM,LEFT	HYUNDAI	
82665	55210-25000	CONTROL ARM,LEFT	HYUNDAI	
82946	54500-1C010 54500-S1010	CONTROL ARM,LEFT	HYUNDAI	
82965	54500-1J500 54500-1J700	CONTROL ARM,LEFT	HYUNDAI	
84256	54501-B4000	CONTROL ARM,LEFT	HYUNDAI	
88320	54500-1Y100 54500-1Y000	CONTROL ARM,LEFT	HYUNDAI	
88321	54500-07160 54500-07161	CONTROL ARM,LEFT	HYUNDAI	
96404	54500-4A801	CONTROL ARM,LEFT	HYUNDAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
52299	54501-1P100 54501-1P000	CONTROL ARM,RIGHT	HYUNDAI/KIA	
75855	54500-2K200	CONTROL ARM,RIGHT	HYUNDAI/KIA	
75854	54501-2K200	CONTROL ARM,LEFT	HYUNDAI/KIA	
62354	54501-FD000	CONTROL ARM	HYUNDAI/KIA	
25434	54501-1E000 54501-0J000	CONTROL ARM,RIGHT	HYUNDAI/KIA	
25433	54500-1E000 54500-0J000	CONTROL ARM,LEFT	HYUNDAI/KIA	
21733	8-94445-550-0	CONTROL ARM,WITH BUSHINGS	ISUZU	
31430	4-52008-1A0-0	CONTROL ARM	ISUZU	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31433	4-52007-6G2-0	CONTROL ARM	ISUZU	
31434	1-16306-0H0-0	CONTROL ARM	ISUZU	
31437	4-52005-2E0-0	CONTROL ARM	ISUZU	
31443	4-52027-750-0	CONTROL ARM	ISUZU	
31444	7-1100A-78B-01	CONTROL ARM	ISUZU	
42638	8-94459-460-0	CONTROL ARM	ISUZU	
42639	8-94243-232-0	CONTROL ARM	ISUZU	
48067	8-98005-832-0	CONTROL ARM	ISUZU	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
48068	8-98005-833-0	CONTROL ARM	ISUZU	
48069	8-98005-834-0	CONTROL ARM	ISUZU	
48070	8-98005-835-0	CONTROL ARM	ISUZU	
62954	8-94459-461-0	CONTROL ARM	ISUZU	
62955	8-94459-462-0	CONTROL ARM	ISUZU	
66453	8-94495-550-1	CONTROL ARM	ISUZU	
67179	8-15661-507-0 520-139	CONTROL ARM	ISUZU	
67180	8-15661-508-0 520-140	CONTROL ARM	ISUZU	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
88946	8-94223-222-2	CONTROL ARM	ISUZU	
88984	8-98005-831-0	CONTROL ARM	ISUZU	
25535	8-94459-460-2 8-94246-419-0	CONTROL ARM,RIGHT	ISUZU	
31431	4-52015-4G0-1	CONTROL ARM,RIGHT	ISUZU	
31436	4-52015-9J0-0	CONTROL ARM,RIGHT	ISUZU	
31442	4-52017-7A1-0 4-52017-7A0-1	CONTROL ARM,RIGHT	ISUZU	
31446	4-52016-3G0-1	CONTROL ARM,RIGHT	ISUZU	
31577	8-94445-550-1	CONTROL ARM,RIGHT	ISUZU	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
48065	8-98005-838-0 8-97365-012-0	CONTROL ARM,RIGHT	ISUZU	
62941	8-94445-551-1	CONTROL ARM,RIGHT	ISUZU	
70362	8-94323-562-1	CONTROL ARM,RIGHT	ISUZU	
73808	8-97365-010-0	CONTROL ARM,RIGHT	ISUZU	
88324	8-98005-836-0 98005836	CONTROL ARM,RIGHT	ISUZU	
25534	8-94459-461-2 8-94246-420-0	CONTROL ARM,LEFT	ISUZU	
25536	8-94445-551-0	CONTROL ARM,LEFT	ISUZU	
31435	4-52025-9J0-0	CONTROL ARM,LEFT	ISUZU	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31439	45202-62J00 45202-63J00	CONTROL ARM,LEFT	ISUZU	
31441	4-52027-7A1-0 4-52027-7A0-1	CONTROL ARM,LEFT	ISUZU	
31445	4-52026-3G0-1 4-50206-3G0-1	CONTROL ARM,LEFT	ISUZU	
48066	8-98005-839-0 8-97365-013-0	CONTROL ARM,LEFT	ISUZU	
70361	8-94323-563-1	CONTROL ARM,LEFT	ISUZU	
73809	8-97365-011-0	CONTROL ARM,LEFT	ISUZU	
88323	8-98005-837-0 98005837	CONTROL ARM,LEFT	ISUZU	
70364	8-97106-663-0	STEERING ARM	ISUZU	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
78329	C2S 50863 C2S 20741 C2S 25024 C2S 3602 C2S 36208 C2S 39585 C2S 46370	CONTROL ARM	JAGUAR	
25166	52088312	CONTROL ARM	JEEP	
82906	52090206AI 52090206AG 52090206AH 52090206AF	CONTROL ARM	JEEP	
88708	52088901AD	CONTROL ARM	JEEP	
89475	52000213 52002535 52038130 52087710 52087711	CONTROL ARM	JEEP	
25183	52088217AB	CONTROL ARM,LEFT RIGHT	JEEP	
17937	0K30B-34-300B 54500-FD000	CONTROL ARM,WITH BUSHINGS	KIA	
31615	0K72A-34-200A 0K72A-34-200	CONTROL ARM	KIA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31616	0K72A-34-300A 0K72A-34-300B	CONTROL ARM	KIA	
31617	0K2A1-34-350 0K9A6-34-350	CONTROL ARM	KIA	
31618	0K2A1-34-300 0K9A6-34-300	CONTROL ARM	KIA	
42199	55100-2G000	CONTROL ARM	KIA	
53400	0K011-34-200	CONTROL ARM	KIA	
88947	48610-0K011	CONTROL ARM	KIA	
25157	54520-3E001	CONTROL ARM,RIGHT	KIA	
25452	54501-07100 54501-07200	CONTROL ARM,RIGHT	KIA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31582	0K2FA-34-300	CONTROL ARM,RIGHT	KIA	
31620	0K30B-34-300	CONTROL ARM,RIGHT	KIA	
31622	0S617-34-350 0S083-34-300B	CONTROL ARM,RIGHT	KIA	
31624	0G030-28-550C	CONTROL ARM,RIGHT	KIA	
31626	0K552-34-300A 0K552-34-300B 0K552-34-300C	CONTROL ARM,RIGHT	KIA	
55402	54501-2K000	CONTROL ARM,RIGHT	KIA	
62349	54501-2F001 54501-2F000	CONTROL ARM, RIGHT	KIA	
71030	54420-3E100 54420-3E000 54420-3E001 54420-3E002	CONTROL ARM,RIGHT	KIA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
84255	54501-1W000	CONTROL ARM,RIGHT	KIA	
6129	0K2A1-34-300B	CONTROL ARM,WITH BALL JOINT	KIA	
25168	54510-3E001	CONTROL ARM,LEFT	KIA	
25450	54500-07100 54500-07200	CONTROL ARM,LEFT	KIA	
31581	0K2FA-34-350	CONTROL ARM,LEFT	KIA	
31619	0K30B-34-350	CONTROL ARM,LEFT	KIA	
31621	0S617-34-300 0S617-34-300A	CONTROL ARM,LEFT	KIA	
31623	0G030-28-500C	CONTROL ARM,LEFT	KIA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31625	0K552-34-350A 0K552-34-350B 0K552-34-350C	CONTROL ARM,LEFT	KIA	
55401	54500-2K300	CONTROL ARM,LEFT	KIA	
62347	54500-2F001 54500-2F000	CONTROL ARM,LEFT	KIA	
71031	54410-3E000 54410-3E001 54410-3E002 54410-3E100	CONTROL ARM,LEFT	KIA	
84254	54500-1W000	CONTROL ARM,LEFT	KIA	
6130	0K2A1-34-350B	CONTROL ARM,LEFT	KIA	
6132	OSE46-34-250	CONTROL ARM,UPPER,RIGHT	KIA	
6131	OSE46-34-200	CONTROL ARM,UPPER,LEFT	KIA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
6133	HE21-34-300A	CONTROL ARM,LOW,RIGHT	KIA	
6134	HE21-34-350A	CONTROL ARM,LOW,LEFT	KIA	
47832	54500-1P000 54500-1P100	CONTROL ARM,LEFT	KIA/HYUNDAI	
4528	KKY01-34-310A KKY01-34-310 D031-34-310A D031-34-320A	CONTROL ARM	KIA/MAZDA	
16500	KKY01-34-390A	CONTROL ARM,FRONT,WITH BUSHINGS	KIA/MAZDA	
31556	21012904011	CONTROL ARM,RIGHT	LADA	
31558	21012904096	CONTROL ARM,RIGHT	LADA	
47251	21011-2904101	CONTROL ARM,RIGHT	LADA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
47253	21011-2904021	CONTROL ARM,RIGHT	LADA	
31555	21012904010	CONTROL ARM,LEFT	LADA	
31557	21012904095	CONTROL ARM,LEFT	LADA	
47250	21010-2904101	CONTROL ARM,LEFT	LADA	
47252	21010-2904021	CONTROL ARM,LEFT	LADA	
80257	51 905 058 51 890 709	CONTROL ARM,RIGHT	LANCIA	
80256	51 956 709 51 905 057	CONTROL ARM,LEFT	LANCIA	
46848		CONTROL ARM KIT	LAND ROVER	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
43213	RBJ 500446 RBJ 501280 RBJ 501380	CONTROL ARM	LAND ROVER	HOH
43214	RBJ 500456 RBJ 501290 RBJ 501390	CONTROL ARM	LAND ROVER	HOH
43880	LR0 29304	CONTROL ARM	LAND ROVER	HOH
43881	LR0 29306	CONTROL ARM	LAND ROVER	HOH
54623	LRO 14133	CONTROL ARM	LAND ROVER	HOH
65333	RBJ 000062 RBJ 500710 RBJ 500920	CONTROL ARM	LAND ROVER	HOH
65349	LR0 28245 RBJ 500183	CONTROL ARM	LAND ROVER	
65351	LR0 28249 RBJ 500193	CONTROL ARM	LAND ROVER	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
65353	LR0 14132	CONTROL ARM	LAND ROVER	HOH
65355	LR0 24472	CONTROL ARM	LAND ROVER	HOH
65356	LR0 24473	CONTROL ARM	LAND ROVER	HOH
79510	LR0 37690	CONTROL ARM	LAND ROVER	HOH
89605	LR0 01175	CONTROL ARM	LAND ROVER	
89607	LR0 01176	CONTROL ARM	LAND ROVER	
91095	LR0 29301	CONTROL ARM	LAND ROVER	HOH
91096	LR0 29302	CONTROL ARM	LAND ROVER	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
91097	LR0 14133	CONTROL ARM	LAND ROVER	HOH
91098	C2P 24862	CONTROL ARM	LAND ROVER	HOH
91100	C2P 24863	CONTROL ARM	LAND ROVER	HOH
91473	RGD 000090	CONTROL ARM	LAND ROVER	HOH
87855	LR0 19977 RGG 500303 RGG 500304	CONTROL ARM,REAR RIGHT	LAND ROVER	HOH
87854	LR0 19978 RGG 500313 RGG 500314	CONTROL ARM,REAR LEFT	LAND ROVER	HOH
43212	LR0 07205 LR0 02624	CONTROL ARM,RIGHT	LAND ROVER	
46705	RBJ 102440 RBJ 102920 RBJ 500680	CONTROL ARM,RIGHT	LAND ROVER	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
78621	LR0 34218	CONTROL ARM,RIGHT	LAND ROVER	HOH
79506	LR0 34214	CONTROL ARM,RIGHT	LAND ROVER	HOH
79509	LR0 34220 LR0 72470	CONTROL ARM,RIGHT	LAND ROVER	HOH
81905	C2D 36804	CONTROL ARM,RIGHT	LAND ROVER	HOH
81907	C2Z 29115	CONTROL ARM,RIGHT	LAND ROVER	HOH
43218	LR0 07206 LR0 02625	CONTROL ARM,LEFT	LAND ROVER	
46706	RBJ 102930 RBJ 102450 RBJ 500690	CONTROL ARM,LEFT	LAND ROVER	HOH
78620	LR0 34217	CONTROL ARM,LEFT	LAND ROVER	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
79507	LR0 34211	CONTROL ARM,LEFT	LAND ROVER	HOH
79508	LR0 34219 LR0 72469	CONTROL ARM,LEFT	LAND ROVER	HOH
81904	C2D 36806	CONTROL ARM,LEFT	LAND ROVER	HOH
81906	C2Z 29117	CONTROL ARM,LEFT	LAND ROVER	HOH
32920		CONTROL ARM	MAZDA	HOH
16545	0662-99-356	CONTROL ARM,FRONT,WITH BUSHINGS	MAZDA	HOH
24112	UH71-34-260	CONTROL ARM	MAZDA	
25000	BP4K-28-500E	CONTROL ARM	MAZDA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25167	BR70-28-600	CONTROL ARM	MAZDA	HOH
26355	UH71-34-210	CONTROL ARM	MAZDA	
32000	GJ6A-34-3J50	CONTROL ARM	MAZDA	HOH
32001	GJ6A-34-300	CONTROL ARM	MAZDA	HOH
32002	GJ6A-34-250	CONTROL ARM	MAZDA	HOH
32003	GJ6A-34-200	CONTROL ARM	MAZDA	HOH
32336	1243-34-310C	CONTROL ARM	MAZDA	HOH
32337	1243-34-360C	CONTROL ARM	MAZDA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
32522	UE38-32-320	CONTROL ARM	MAZDA	
55406	UH75-34-210 UH74-34-210A UH75-34-210A UH75-34-210B ADM58685C	CONTROL ARM	MAZDA	
55407	UH75-34-260 UH74-34-260A UH75-34-260A UH75-34-260B ADM58684C	CONTROL ARM	MAZDA	
56600	YS4Z-5500-DA K660012	CONTROL ARM	MAZDA	
59127	UB39-32-320	CONTROL ARM	MAZDA	
62965	GJ6A-35-J00	CONTROL ARM	MAZDA	
65286	UJ06-32-320	CONTROL ARM	MAZDA	
75016	UB93-32-320 UB93-32-320A	CONTROL ARM	MAZDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
75017	UH71-32-320	CONTROL ARM	MAZDA	
75856	G26A-28-500B	CONTROL ARM	MAZDA	
79226	UA3N-32-320A	CONTROL ARM	MAZDA	
79227	UH71-32-220	CONTROL ARM	MAZDA	
89843	4AAA-34-011	CONTROL ARM	MAZDA	
89844	UC86-34-210 MZC4-30-122	CONTROL ARM	MAZDA	
89845	4AAA-34-010	CONTROL ARM	MAZDA	
89846	UC86-34-260 MZC4-03-121	CONTROL ARM	MAZDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31628	GJ6A-28-C10A GP9A-28-C10 G26A-28-C10	CONTROL ARM,REAR	MAZDA	HOH
25185	BR70-28-620	CONTROL ARM,REAR RIGHT	MAZDA	HOH
25184	BR70-28-630	CONTROL ARM,REAR LEFT	MAZDA	HOH
13321	GA6BE-34-300 GA2A-34-300 GA2B-34-300A GA6B-34-300E GA2A-34-300A 3 707 090	CONTROL ARM,RIGHT	MAZDA	
21597	AJ6A-34-J00C	CONTROL ARM,RIGHT	MAZDA	HOH
21599	GJ6A-34-200B	CONTROL ARM,RIGHT	MAZDA	
25174	BE7B-34-300A B02B-34-300E B01A-34-300E	CONTROL ARM,RIGHT	MAZDA	HOH
25181	LC62-34-300C	CONTROL ARM,RIGHT	MAZDA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31536	1 071 683 1 330 219 4S61 3042 AA 1E00-34-300A 1E00-34-300B 1E00-34-300D 1E00-34-300E 1E00-34-300F	CONTROL ARM,RIGHT	MAZDA	
31570	B092-28-550B BF67-28-630	CONTROL ARM,RIGHT	MAZDA	
31574	C100-34-300B C100-34-300A	CONTROL ARM,RIGHT	MAZDA	
31576	B455-34-300E B455-34-300 B530-34-300A BR70-34-300B	CONTROL ARM,RIGHT	MAZDA	
31631	GF22-34-300A GJ22-34-300A GJ22-34-300B GJ83-34-300B GN98-34-300A KA39-34-300A	CONTROL ARM,RIGHT	MAZDA	
31633	B32H-34-300 B32H-34-300A B32H-34-300D BP4K-34-300E B32H-34-300E K620040	CONTROL ARM,RIGHT	MAZDA	
31896	H380-34-300A	CONTROL ARM,RIGHT	MAZDA	
32007	B25D-34-300A B25D-34-300B B25D-34-300C B25D-34-300D	CONTROL ARM,RIGHT	MAZDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
32008	G030-34-300F	CONTROL ARM,RIGHT	MAZDA	
32335	B455-34-350B	CONTROL ARM,RIGHT	MAZDA	
32353	UB39-34-210A	CONTROL ARM,RIGHT	MAZDA	
46737	GD7A-34-300A GE4T-34-300B GE4T-34-300C GE4T-34-300D GE4T-34-300E	CONTROL ARM,RIGHT	MAZDA	
53403	H380-34-C00	CONTROL ARM,RIGHT	MAZDA	
65287	UR61-34-300	CONTROL ARM,RIGHT	MAZDA	
71107	UH74-34-310 UH74-34-310A	CONTROL ARM,RIGHT	MAZDA	
71705	GS1D-34-200	CONTROL ARM,RIGHT	MAZDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
88334	B39D-34-300 B39D-34-300A BBM2-34-300 BBM2-34-300A	CONTROL ARM,RIGHT	MAZDA	HOH
13322	GA2A-34-350 GA6BE-34-350 GA2A-34-350A	CONTROL ARM,LEFT	MAZDA	
15240	H001-49-320	CONTROL ARM,LEFT	MAZDA	HOH
21600	GJ6A-34-250B GJ6A-34-250A GP9A-34-250A GP9A-34-250B GP9A-34-250C	CONTROL ARM,LEFT	MAZDA	
25175	B01A-34-350E	CONTROL ARM,LEFT	MAZDA	HOH
25176	B25D-34-350A B25D-34-350B B25D-34-350C B25D-34-350D	CONTROL ARM,LEFT	MAZDA	HOH
25182	LC62-34-350C	CONTROL ARM,LEFT	MAZDA	HOH
31569	B092-28-500B BF67-28-620	CONTROL ARM,LEFT	MAZDA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31572	C100-34-350B C100-34-350A	CONTROL ARM,LEFT	MAZDA	
31575	B455-34-350E B455-34-350 B530-34-350A BR70-34-350B	CONTROL ARM,LEFT	MAZDA	
31630	GF22-34-350A GJ22-34-350A GJ22-34-350B	CONTROL ARM,LEFT	MAZDA	
31632	B32H-34-350 B32H-34-350A B32H-34-350D BP4K-34-350E B32H-34-350E K620041	CONTROL ARM,LEFT	MAZDA	
32009	G030-34-350F	CONTROL ARM,LEFT	MAZDA	
32334	B455-34-300B	CONTROL ARM,LEFT	MAZDA	
32354	UB39-34-260A	CONTROL ARM,LEFT	MAZDA	
37699	UR61-34-350	CONTROL ARM,LEFT	MAZDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46738	GD7A-34-350A GE4T-34-350B GE4T-34-350C GE4T-34-350D GE4T-34-350E	CONTROL ARM,LEFT	MAZDA	
46740	DG80-34-300	CONTROL ARM,LEFT	MAZDA	
46741	DG80-34-350	CONTROL ARM,LEFT	MAZDA	
53402	H380-34-C50	CONTROL ARM,LEFT	MAZDA	
53404	H380-34-350A-B	CONTROL ARM,LEFT	MAZDA	
71106	UH74-34-360 UH74-34-360A	CONTROL ARM,LEFT	MAZDA	
71706	GS1D-34-250	CONTROL ARM,LEFT	MAZDA	
88333	B39D-34-350 B39D-34-350A BBM2-34-350 BBM2-34-350A	CONTROL ARM,LEFT	MAZDA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31571	B092-28-600	CONTROL ARM,LEFT	MAZDA	HOH
31629	GA6A-34-300B GJ6A-34-300B GJ6A-34-300C GJ6A-34-300D GJ6A-34-300E	CONTROL ARM,LEFT RIGHT	MAZDA	
32355	LB82-34-300 LA01-34-300A	CONTROL ARM,LEFT	MAZDA	HOH
31627	GJ6A-34-J00B GJ6A-34-J00C GJ6A-34-J00D	CONTROL ARM,REAR RIGHT	MAZDA	HOH
21598	GJ6A-34-J50B GJ6A-34-J50D GJ6A-34-J50C	CONTROL ARM,FRONT,LEFT,WITH BEARING AND JOINT	MAZDA	HOH
15241	H001-49-310	CONTROL ARM,RIGHT	MAZDA	HOH
31895	H380-34-350A	CONTROL ARM,LEFT,UPPER,ALUMINUM	MAZDA	HOH
89802	UB39-32-32A	STEERING ARM	MAZDA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
89806	UR56-32-320A	STEERING ARM	MAZDA	HOH
43957	220 350 27 06 220 350 26 06	CONTROL ARM,FRONT	MERCEDES-BENZ	HOH
43969	163 350 09 06	CONTROL ARM,REAR	MERCEDES-BENZ	HOH
43974	164 330 35 07 164 330 30 07 164 330 26 07 164 330 18 07	CONTROL ARM,REAR RIGHT	MERCEDES-BENZ	
43971	164 330 29 07 164 330 34 07 164 330 25 07 164 330 17 07	CONTROL ARM,REAR LEFT	MERCEDES-BENZ	
78320	164 330 08 43	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
78319	164 330 07 43	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
61724	204 350 06 53	CONTROL ARM	MERCEDES-BENZ	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
27005	204 350 16 06	CONTROL ARM,REAR RIGHT	MERCEDES-BENZ	HOH
27007	204 350 22 06	CONTROL ARM,REAR RIGHT	MERCEDES-BENZ	HOH
27008	204 350 27 06	CONTROL ARM,REAR RIGHT	MERCEDES-BENZ	HOH
27006	204 350 21 06	CONTROL ARM,REAR LEFT,ALUMINUM	MERCEDES-BENZ	HOH
43912	204 350 05 53	CONTROL ARM,REAR LEFT	MERCEDES-BENZ	HOH
27004	204 350 15 06	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	HOH
43910	204 330 68 11 204 330 32 11	CONTROL ARM,FRONT RIGHT	MERCEDES-BENZ	
43909	204 330 67 11 204 330 31 11	CONTROL ARM,FRONT LEFT	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
10483	203 330 36 11 203 330 40 11 203 330 02 11 203 330 16 11 204 330 44 11 2963402	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
10482	203 330 35 11 203 330 39 11 203 330 01 11 203 330 17 11 204 330 43 11 2963302	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	
80271	205 330 16 05	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
80273	205 330 62 01	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
80270	205 330 15 05	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
80272	205 330 61 01	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
9887	211 330 82 07 211 330 92 07 2963901	CONTROL ARM,RIGHT	MERCEDES-BENZ	
10492	211 330 81 07 211 330 91 07	CONTROL ARM,LEFT	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
9889	211 330 44 11 211 330 12 11 211 330 16 11 211 330 30 11 230 330 18 11	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
52983	211 330 68 07 211 330 90 07 211 330 44 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	
9885	211 330 67 07 211 330 89 07 211 330 43 07 230 330 01 38 230 330 25 07 230 330 26 07 3194901	CONTROL ARM,LEFT	MERCEDES-BENZ	
9888	211 330 43 11 211 330 11 11 211 330 15 11 211 330 29 11 230 330 17 11	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	
43943	212 330 27 11	CONTROL ARM	MERCEDES-BENZ	HOH
43944	212 330 28 11	CONTROL ARM	MERCEDES-BENZ	HOH
43946	212 330 29 11 212 330 39 00	CONTROL ARM,FRONT	MERCEDES-BENZ	
43948	212 330 30 11	CONTROL ARM,FRONT	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
10487	220 330 90 07 220 330 44 07 220 330 78 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	
10486	220 330 89 07 220 330 43 07 220 330 77 07	CONTROL ARM,LEFT	MERCEDES-BENZ	
10470	220 350 24 06 220 352 10 05 2728101	CONTROL ARM,REAR,WITH BUSHINGS,LEFT/RIGHT,UPPER,ALU MINUM	MERCEDES-BENZ	
10471	220 350 22 06 2 728 001	CONTROL ARM,REAR,WITH BUSHINGS,LEFT/RIGHT,UPPER,ALU MINUM	MERCEDES-BENZ	
10478	220 330 15 07 220 330 84 07 220 330 94 07 2099302	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
10485	220 330 44 11 220 330 58 11 220 330 17 11 220 330 34 11	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
10477	220 330 14 07 220 330 83 07 220 330 93 07 2099202	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	
10484	220 330 43 11 220 330 57 11 220 330 18 11 220 330 33 11	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31799	221 350 08 06	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
34418	221 350 06 06	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
31798	221 350 07 06	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
14551	221 350 04 06	CONTROL ARM,LEFT,WITH BUSHINGS,UPPER,ALUMINUM	MERCEDES-BENZ	
31802	221 350 12 53	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
31801	221 350 11 53	CONTROL ARM,REAR LEFT	MERCEDES-BENZ	HOH
31216	221 330 82 07 221 330 68 07	CONTROL ARM,WITH BUSH,RIGHT	MERCEDES-BENZ	
26787	221 330 81 07 221 330 67 07	CONTROL ARM,WITH BUSH,LEFT	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
14550	221 350 02 06	CONTROL ARM,FRONT,WITH BUSHINGS,UPPER,ALUMINUM	MERCEDES-BENZ	
14552	221 350 10 06	CONTROL ARM,FRONT,WITH BUSHINGS,UPPER,ALUMINUM	MERCEDES-BENZ	
16252	221 330 24 11 221 330 64 11	CONTROL ARM,FRONT,WITH BUSHINGS,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
14549	221 330 23 11 221 330 63 11	CONTROL ARM,FRONT,WITH BUSHINGS,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	
12319	221 330 04 07 221 330 90 07	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
10472	221 330 03 07 221 330 89 07	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	
64283	221 330 77 07	CONTROL ARM,LEFT	MERCEDES-BENZ	
64281	221 330 78 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
75839	221 330 38 11 221 330 66 11	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
78650	222 830 33 07 222 330 02 07	CONTROL ARM	MERCEDES-BENZ	
88930	222 330 01 07	CONTROL ARM	MERCEDES-BENZ	
31846	251 330 08 07	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
31845	251 330 07 07	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	
43982	251 330 12 07 251 330 16 07 251 330 20 07 251 330 14 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	
43981	251 330 11 07 251 330 15 07 251 330 19 07 251 330 13 07	CONTROL ARM,LEFT	MERCEDES-BENZ	
64019	204 330 80 11	CONTROL ARM	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
78649	204 330 82 11	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
78648	204 330 81 11	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
46840		CONTROL ARM KIT	MERCEDES-BENZ	
46841		CONTROL ARM KIT	MERCEDES-BENZ	
46846		CONTROL ARM KIT	MERCEDES-BENZ	
43985	230 330 33 07	CONTROL ARM,FRONT	MERCEDES-BENZ	HOH
43986	230 330 34 07	CONTROL ARM,FRONT	MERCEDES-BENZ	HOH
47834	451 330 00 10	CONTROL ARM	MERCEDES-BENZ	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
47835	451 350 01 29	CONTROL ARM	MERCEDES-BENZ	HOH
43976	164 350 13 06	CONTROL ARM,REAR	MERCEDES-BENZ	HOH
43977	164 350 14 06	CONTROL ARM,REAR	MERCEDES-BENZ	HOH
43979	164 350 19 06	CONTROL ARM,REAR	MERCEDES-BENZ	HOH
43980	164 350 20 06	CONTROL ARM,REAR	MERCEDES-BENZ	HOH
46845		CONTROL ARM KIT	MERCEDES-BENZ	
43987	211 350 26 06	CONTROL ARM,REAR	MERCEDES-BENZ	HOH
43983	169 350 01 29	CONTROL ARM,REAR	MERCEDES-BENZ	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
43984	169 350 02 29	CONTROL ARM,REAR	MERCEDES-BENZ	
10936	140 350 34 53 140 350 30 53 140 350 18 53 140 350 34 53 S 140 350 30 53 S 140 350 18 53 S 140 350 31 53 140 350 24 53	CONTROL ARM	MERCEDES-BENZ	
29334	230 330 13 07	CONTROL ARM	MERCEDES-BENZ	
30389	Q0004879V004	CONTROL ARM	MERCEDES-BENZ	
31988	221 352 00 05	CONTROL ARM	MERCEDES-BENZ	
39383	203 350 06 53	CONTROL ARM	MERCEDES-BENZ	
64014	211 330 01 38	CONTROL ARM	MERCEDES-BENZ	
64015	164 350 16 06	CONTROL ARM	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
64016	163 350 10 06	CONTROL ARM	MERCEDES-BENZ	
64020	221 330 07 06	CONTROL ARM	MERCEDES-BENZ	
71698	639 330 14 01	CONTROL ARM	MERCEDES-BENZ	
71699	639 330 15 01	CONTROL ARM	MERCEDES-BENZ	
76557	415 330 03 00	CONTROL ARM	MERCEDES-BENZ	
76558	415 330 02 00	CONTROL ARM	MERCEDES-BENZ	
82864	Q0004880V004	CONTROL ARM	MERCEDES-BENZ	
29345	230 350 04 29	CONTROL ARM,REAR RIGHT	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
27000	163 330 04 07	CONTROL ARM,REAR LEFT	MERCEDES-BENZ	HOH
31795	163 352 04 01 163 352 00 01	CONTROL ARM,REAR LEFT,ALUMINUM	MERCEDES-BENZ	
34425	230 350 03 29 A 230 350 03 29 2 985 901	CONTROL ARM,REAR LEFT	MERCEDES-BENZ	HOH
34391	215 330 07 07	CONTROL ARM,REAR LEFT/RIGHT	MERCEDES-BENZ	HOH
87120	166 330 02 07	CONTROL ARM,FRONT,RIGHT	MERCEDES-BENZ	HOH
87144	222 330 06 07	CONTROL ARM,FRONT RIGHT	MERCEDES-BENZ	HOH
87121	166 330 01 07	CONTROL ARM,FRONT,LEFT	MERCEDES-BENZ	HOH
87143	222 330 05 07	CONTROL ARM,FRONT LEFT	MERCEDES-BENZ	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
10489	203 330 20 11 203 330 34 11 204 330 20 11	CONTROL ARM,RIGHT	MERCEDES-BENZ	
10494	202 330 20 07 202 330 31 07 202 330 49 07 208 330 05 07 208 330 14 07 210 330 23 07 210 330 26 07 210 330 51 07 210 330 88 07 202 330 37 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	
10612	638 330 01 10	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
25252	163 330 09 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
25264	203 330 04 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
27001	163 330 05 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
29120	124 330 31 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
29122	170 330 02 07 202 330 27 07 202 330 42 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
29124	210 330 62 07 210 330 91 07 210 330 35 07 210 330 45 07 210 330 77 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	
29126	210 330 41 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
29337	124 330 35 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
31635	169 330 08 07 169 330 06 07 169 330 10 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
31637	414 330 04 07 414 330 06 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
31639	124 330 39 07 201 330 39 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
31641	124 330 19 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31643	201 330 41 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
31645	107 330 15 07 115 330 37 07 115 330 39 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
31647	211 330 68 70	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
31651	163 330 01 01	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
31655	639 330 50 10	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
32375	140 330 43 07 140 330 65 07 140 330 71 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
34228	168 330 09 07 168 330 12 07 168 330 18 07 168 330 24 07 168 330 09 27	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
42239	163 350 04 53 163 350 06 53	CONTROL ARM,RIGHT	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
45261	639 330 09 10 639 330 05 10	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
64012	221 330 88 07 221 330 72 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	
78323	246 330 18 07 246 330 48 00	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
80261	166 330 18 07 A 166 330 18 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
80267	205 330 56 01	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
80269	205 323 07 17	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
92608	204 330 74 11	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
92611	212 330 32 11	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
92613	217 330 52 00	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
10488	203 330 19 11 203 330 33 11 204 330 19 11 2959301	CONTROL ARM,LEFT	MERCEDES-BENZ	
10493	202 330 30 07 202 330 36 07 202 330 48 07 208 330 13 07 210 330 22 07 210 330 25 07 210 330 50 07 210 330 87 07 202 330 19 07 202 330 04 07	CONTROL ARM,LEFT	MERCEDES-BENZ	
10611	638 330 00 10	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
25251	163 330 08 07	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
25263	203 330 03 07	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
29119	124 330 30 07	CONTROL ARM,LEFT	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
29121	170 330 01 07 202 330 26 07 202 330 41 07	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
29123	210 330 90 07 210 330 61 07 210 330 76 07 210 330 34 07 210 330 44 07	CONTROL ARM,LEFT	MERCEDES-BENZ	
29125	210 330 39 07	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
29336	124 330 34 07	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
29341	210 338 09 15	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
31634	169 330 05 07 169 330 07 07 169 330 09 07	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
31636	414 330 05 07 414 330 03 07	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
31638	124 330 38 07 201 330 38 07	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31640	124 330 18 07	CONTROL ARM,LEFT	MERCEDES-BENZ	
31642	201 330 40 07	CONTROL ARM,LEFT	MERCEDES-BENZ	
31644	107 330 14 07 115 330 36 07 115 330 38 07	CONTROL ARM,LEFT	MERCEDES-BENZ	
31646	211 330 67 70	CONTROL ARM,LEFT	MERCEDES-BENZ	
31650	163 330 00 01	CONTROL ARM,LEFT	MERCEDES-BENZ	
31654	639 330 40 10	CONTROL ARM,LEFT	MERCEDES-BENZ	
32376	140 330 70 07 140 330 64 07 140 330 42 07	CONTROL ARM,LEFT	MERCEDES-BENZ	
34227	168 330 17 07 168 330 23 07 168 330 11 07 168 330 08 07 168 330 08 27	CONTROL ARM,LEFT	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
39386	163 350 05 53 163 350 01 53	CONTROL ARM,LEFT	MERCEDES-BENZ	
45262	639 330 08 10 639 330 04 10	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
76039	221 330 71 07 221 330 87 07	CONTROL ARM,LEFT	MERCEDES-BENZ	
78322	246 330 17 07 246 330 47 00	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
80260	166 330 17 07 A 166 330 17 07	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
80266	205 330 55 01	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
80268	205 323 08 17	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
92607	204 330 73 11	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
92609	212 330 31 11	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
92612	217 330 51 00	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
17678	210 350 99 99 210 350 38 06 S	CONTROL ARM KIT	MERCEDES-BENZ	
94254	220 333 74 07	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
94257	220 333 24 02	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
94253	220 333 73 07	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
94255	220 333 23 02	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
5826	140 350 34 06	CONTROL ARM,REAR,WITH BUSHINGS,LEFT/RIGHT,ALUMINUM	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
5827	140 350 35 06	CONTROL ARM,REAR,WITH BUSHINGS,LEFT/RIGHT,ALUMINUM	MERCEDES-BENZ	
10476	140 350 36 06	CONTROL ARM,REAR,WITH BUSHINGS,LEFT/RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
10619	230 350 20 06	CONTROL ARM,FRONT,WITH BUSHINGS,UPPER,ALUMINUM	MERCEDES-BENZ	
53407	2203520305	CONTROL ARM	MERCEDES-BENZ	
31797	163 352 05 01 163 352 01 01	CONTROL ARM,REAR LEFT,ALUMINUM	MERCEDES-BENZ	
5821	123 330 47 07 123 330 53 07	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
10480	126 330 07 07	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
10496	163 333 01 01	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
10616	230 350 28 06 A 230 350 28 06 3048201	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
10618	230 350 36 06 A 230 350 36 06 3042901	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
24547	220 333 14 05	CONTROL ARM,WITH BUSHINGS,ALUMINUM,RIGHT	MERCEDES-BENZ	
31649	220 330 52 11	CONTROL ARM,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	HOH
53406	2203301305	CONTROL ARM,RIGHT	MERCEDES-BENZ	HOH
5820	123 330 46 07 123 330 52 07	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	
10479	126 330 06 07	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	
10495	163 333 00 01	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
10615	230 350 27 06 A 230 350 27 06 3048101	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	
10617	230 350 35 06 A 230 350 35 06 3042801	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	
31648	220 330 51 11	CONTROL ARM,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	HOH
31780	220 333 13 05	CONTROL ARM,WITH BUSHINGS,ALUMINUM,LEFT	MERCEDES-BENZ	HOH
53405	2203301405	CONTROL ARM,LEFT	MERCEDES-BENZ	HOH
10481	140 330 55 07 140 330 59 07 140 330 77 07	CONTROL ARM,FRONT,WITH BUSHINGS,RIGHT,UPPER,ALUMINUM	MERCEDES-BENZ	
8156	140 330 54 07 140 330 58 07 140 330 76 07	CONTROL ARM,FRONT,WITH BUSHINGS,LEFT,UPPER,ALUMINUM	MERCEDES-BENZ	
13275	210 350 33 06 201 350 56 06 201 350 47 06 201 350 43 06 124 350 42 06 201 350 39 06 201 350 53 06	CONTROL ARM,REAR LEFT/RIGHT,L=245MM	MERCEDES- BENZ/CHRYSLER	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31653	2D0 407 022 2D0 407 022 B 901 330 17 07 901 330 19 07 901 330 25 07	CONTROL ARM,RIGHT	MERCEDES-BENZ/VW	
31652	2D0 407 021 2D0 407 021 B 901 330 16 07 901 330 18 07 901 330 24 07	CONTROL ARM,LEFT	MERCEDES-BENZ/VW	
76487	2E0 407 151 M 2E0 407 151 L 906 330 40 07	CONTROL ARM,LEFT	MERCEDES-BENZ/VW	
19921	MB 831036 MR 124880 MR 296094 MR 296096 MR 296296 MR 124878	CONTROL ARM,RIGHT	MITSUBISHI	
76323	4013A009 4013A281 4013A217 4013A279 3520.V0 3520.X9	CONTROL ARM,FRONT LEFT	MITSUBISHI	
12725	MB 831040 MR 592811	CONTROL ARM,FRONT,WITH BUSHINGS	MITSUBISHI	
12726	MB 166423	CONTROL ARM,FRONT,WITH BUSHINGS	MITSUBISHI	
12728	MB 831042	CONTROL ARM	MITSUBISHI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
12729	MB 192297 MB 241495	CONTROL ARM	MITSUBISHI	
12730	MB 241830	CONTROL ARM	MITSUBISHI	
12736	MB 518807	CONTROL ARM,WITH BUSHINGS	MITSUBISHI	
12737	MB 518806	CONTROL ARM,WITH BUSHINGS	MITSUBISHI	
12738	MB 907116 MB 912078 MB 907164 MB 907166	CONTROL ARM,WITH BUSHINGS	MITSUBISHI	
12739	MB 907115 MB 912077 MB 907163 MB 907165	CONTROL ARM,WITH BUSHINGS	MITSUBISHI	
12742	MR 241341 MR 439701	CONTROL ARM,WITH BUSHINGS	MITSUBISHI	
12743	MR 241342 MR 439702	CONTROL ARM,WITH BUSHINGS	MITSUBISHI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
21721	MB 527159	CONTROL ARM,WITH BUSHINGS	MITSUBISHI	HOH
23888	MB 527228	CONTROL ARM	MITSUBISHI	HOH
31408	MR 210442	CONTROL ARM	MITSUBISHI	HOH
31414	MR 508134	CONTROL ARM	MITSUBISHI	HOH
31416	MB 109893 MB 175545	CONTROL ARM	MITSUBISHI	HOH
47886	MR 241023	CONTROL ARM	MITSUBISHI	
55408	MR 418558 MR 418670 ADC48683 *CJ-517	CONTROL ARM	MITSUBISHI	HOH
59126	MR 344654 MR 296272	CONTROL ARM	MITSUBISHI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
59571	MR 491346	CONTROL ARM	MITSUBISHI	HOH
62942	MB 860408	CONTROL ARM	MITSUBISHI	HOH
63387	MR 241024	CONTROL ARM	MITSUBISHI	
76510	MR 589378	CONTROL ARM	MITSUBISHI	HOH
88987	4010A102 4010A018	CONTROL ARM	MITSUBISHI	HOH
88988	4010A017 4010A101	CONTROL ARM	MITSUBISHI	HOH
88989	4013A381 4013A091	CONTROL ARM	MITSUBISHI	HOH
88990	4013A092 4013A382	CONTROL ARM	MITSUBISHI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
88991	MB 491962	CONTROL ARM	MITSUBISHI	
90361	4013A209	CONTROL ARM,LEFT	MITSUBISHI	
90362	4013A210	CONTROL ARM,RIGHT	MITSUBISHI	
90363	MB 109647	CONTROL ARM,LEFT	MITSUBISHI	
90364	MB 109648	CONTROL ARM,RIGHT	MITSUBISHI	
90365	MB 527160	CONTROL ARM,RIGHT	MITSUBISHI	
90366	MN 150411	CONTROL ARM,LEFT	MITSUBISHI	
90367	MN 150412	CONTROL ARM,RIGHT	MITSUBISHI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
62958	4013A010 4013A218 4013A280 4013A282 3521.R1 3521.V0	CONTROL ARM,FRONT RIGHT	MITSUBISHI	HOH
11669	MB 809223 MR 491348	CONTROL ARM,RIGHT	MITSUBISHI	HOH
15236	MR 241026 MR 296028	CONTROL ARM,RIGHT	MITSUBISHI	
19923	MB 527162 MB 527512	CONTROL ARM,RIGHT	MITSUBISHI	HOH
21855	MB 109512	CONTROL ARM,RIGHT	MITSUBISHI	HOH
25538	MB 349944	CONTROL ARM,RIGHT	MITSUBISHI	HOH
25543	MB 809221	CONTROL ARM,RIGHT	MITSUBISHI	HOH
25587	MR 403420	CONTROL ARM,RIGHT	MITSUBISHI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25588	MB 912506 MR 162804	CONTROL ARM,RIGHT	MITSUBISHI	
31397	MR 210431	CONTROL ARM,RIGHT	MITSUBISHI	
31400	MR 297388	CONTROL ARM,RIGHT	MITSUBISHI	
31402	MR 527384 MR 598018	CONTROL ARM,RIGHT	MITSUBISHI	
31405	MR 197284	CONTROL ARM,RIGHT	MITSUBISHI	
31407	MB 598546 MB 598088	CONTROL ARM,RIGHT	MITSUBISHI	
31413	MB 860832 MN 161354	CONTROL ARM,RIGHT	MITSUBISHI	
31421	MB 831556	CONTROL ARM,RIGHT	MITSUBISHI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31423	MB 910842	CONTROL ARM,RIGHT	MITSUBISHI	
31428	MT 141193	CONTROL ARM,RIGHT	MITSUBISHI	
31657	MB 124880	CONTROL ARM,RIGHT	MITSUBISHI	
32350	MB 349444	CONTROL ARM,RIGHT	MITSUBISHI	
32351	MR 972469 MB 912509 MR 325577	CONTROL ARM,RIGHT	MITSUBISHI	
46743	MB 403420	CONTROL ARM,RIGHT	MITSUBISHI	
46744	CW 741148	CONTROL ARM,RIGHT	MITSUBISHI	
46746	CW 731604	CONTROL ARM,RIGHT	MITSUBISHI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
59570	MB 809231	CONTROL ARM,RIGHT	MITSUBISHI	HOH
62945	MR 911569 MR 916134	CONTROL ARM,RIGHT	MITSUBISHI	HOH
62960	MR 414940	CONTROL ARM,RIGHT	MITSUBISHI	HOH
63206	MR 496794 4010A038	CONTROL ARM,RIGHT	MITSUBISHI	HOH
63208	MR 961392	CONTROL ARM,RIGHT	MITSUBISHI	
63210	MR 496796 4013A214	CONTROL ARM,RIGHT	MITSUBISHI	HOH
76505	MR 995264	CONTROL ARM,RIGHT	MITSUBISHI	HOH
76507	PW 550296	CONTROL ARM,RIGHT	MITSUBISHI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
76509	MN 101262	CONTROL ARM,RIGHT	MITSUBISHI	
76511	MB 864728	CONTROL ARM,RIGHT	MITSUBISHI	
76513	MR 589506	CONTROL ARM,RIGHT	MITSUBISHI	
80224	PW 861012	CONTROL ARM,RIGHT	MITSUBISHI	
82914	MB 860382	CONTROL ARM,RIGHT	MITSUBISHI	
85904	MN 101742 4013A132	CONTROL ARM,RIGHT	MITSUBISHI	
88332	4010A118 4010A104 4010A014	CONTROL ARM,RIGHT	MITSUBISHI	
88336	4013A330 4013A364 4013A088	CONTROL ARM,RIGHT	MITSUBISHI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
96403	MB 831558	CONTROL ARM,RIGHT	MITSUBISHI	HOH
11667	MB 809220 MR 491345	CONTROL ARM,LEFT	MITSUBISHI	
11668	MB 809222 MR 491347	CONTROL ARM,LEFT	MITSUBISHI	HOH
15239	MR 241025 MR 296027	CONTROL ARM,LEFT	MITSUBISHI	
19920	MB 831035 MR 124879 MR 296093 MR 296095 MR 296295 MR 124877	CONTROL ARM,LEFT	MITSUBISHI	
19922	MB 527161 MB 527157 MB 527511	CONTROL ARM,LEFT	MITSUBISHI	HOH
21737	MB 109513	CONTROL ARM,LEFT	MITSUBISHI	HOH
25537	MB 349943	CONTROL ARM,LEFT	MITSUBISHI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25586	MR 403419	CONTROL ARM,LEFT	MITSUBISHI	
25589	MB 912505 MR 162803	CONTROL ARM,LEFT	MITSUBISHI	
31396	MR 210430	CONTROL ARM,LEFT	MITSUBISHI	
31399	MR 297387	CONTROL ARM,LEFT	MITSUBISHI	
31401	MR 527383 MR 598017	CONTROL ARM,LEFT	MITSUBISHI	
31404	MR 197283	CONTROL ARM,LEFT	MITSUBISHI	
31406	MB 598545 MB 598087	CONTROL ARM,LEFT	MITSUBISHI	
31412	MB 860831 MN 161353	CONTROL ARM,LEFT	MITSUBISHI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31420	MB 831555	CONTROL ARM,LEFT	MITSUBISHI	
31422	MB 910841	CONTROL ARM,LEFT	MITSUBISHI	
31425	MB 109343 MB 303856	CONTROL ARM,LEFT	MITSUBISHI	
31427	MT 141192	CONTROL ARM,LEFT	MITSUBISHI	
31656	MB 124879	CONTROL ARM,LEFT	MITSUBISHI	
32349	MB 349443	CONTROL ARM,LEFT	MITSUBISHI	
32352	MB 912510 MR 325776 MR 972470 MR 325576 MR 972466 MR 162580	CONTROL ARM,LEFT	MITSUBISHI	
46742	MB 403419	CONTROL ARM,LEFT	MITSUBISHI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46745	CW 741149	CONTROL ARM,LEFT	MITSUBISHI	HOH
46747	CW 731605	CONTROL ARM,LEFT	MITSUBISHI	HOH
59569	MB 809230	CONTROL ARM,LEFT	MITSUBISHI	HOH
62946	MR 916133 MR 911570	CONTROL ARM,LEFT	MITSUBISHI	HOH
62959	MR 414939	CONTROL ARM,LEFT	MITSUBISHI	HOH
63205	MR 496793 4010A037	CONTROL ARM,LEFT	MITSUBISHI	HOH
63207	MR 961391	CONTROL ARM,LEFT	MITSUBISHI	
63209	MR 496795 4013A213	CONTROL ARM,LEFT	MITSUBISHI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
76504	MR 995263	CONTROL ARM,LEFT	MITSUBISHI	
76506	PW 550295	CONTROL ARM,LEFT	MITSUBISHI	
76508	MN 101261	CONTROL ARM,LEFT	MITSUBISHI	
76512	MR 589505	CONTROL ARM,LEFT	MITSUBISHI	
80223	PW 861011	CONTROL ARM,LEFT	MITSUBISHI	
82913	MB 860381	CONTROL ARM,LEFT	MITSUBISHI	
85903	4013A131 MN 101741	CONTROL ARM,LEFT	MITSUBISHI	
88331	4010A117 4010A103 4010A013	CONTROL ARM,LEFT	MITSUBISHI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
88335	4013A363 4013A329 4013A087	CONTROL ARM,LEFT	MITSUBISHI	
21602	MB 912512 MR 296320 MR 162582 MR 162584 MR 296288 MR 296290 MB 162580	CONTROL ARM,FRONT,RIGHT,WITH BEARING AND JOINT	MITSUBISHI	
21601	MB 912511 MR 162581 MR 162583 MR 296287 MR 296289 MR 972465 MR 162579	CONTROL ARM,FRONT,LEFT,WITH BEARING AND JOINT	MITSUBISHI	
89803	MB 166425	STEERING ARM	MITSUBISHI	
89805	MR 241030	STEERING ARM	MITSUBISHI	
12741	MB 430112 MB 527383 MB 598017 54540-43152 54540-43151 54540-43150	CONTROL ARM,RIGHT	MITSUBISHI/HYUN DAI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
12740	MB 430113 MB 527384 MB 598018 54510-43152	CONTROL ARM,WITH BUSHINGS	MITSUBISHI/HYUNDAI	
62180	MN 186218 4013A136 4013A150 454 330 08 07	CONTROL ARM,RIGHT	MITSUBISHI/MERCEDES-BENZ	
89116	4013A135 MN 186217 454 330 07 07	CONTROL ARM,LEFT	MITSUBISHI/MERCEDES-BENZ	
12133	51500-52Y10	CONTROL ARM,FRONT,WITH BUSHINGS UPPER,ALUMINUM	NISSAN	
12134	51501-52Y10	CONTROL ARM,FRONT,WITH BUSHINGS UPPER,ALUMINUM	NISSAN	
4562	54501-35F11	CONTROL ARM	NISSAN	
12683	54500-85E01 54500-85E11	CONTROL ARM,WITH BUSHINGS	NISSAN	
12684	54501-85E01 54501-85E11	CONTROL ARM,WITH BUSHINGS	NISSAN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
15962	48530-H6100	CONTROL ARM	NISSAN	HOH
16107	48530-03W05 48530-03W06 48530-03W07	CONTROL ARM	NISSAN	HOH
16113	48530-B2000 48530-20600	CONTROL ARM	NISSAN	HOH
21613	54500-9E000	CONTROL ARM,WITH BUSHINGS	NISSAN	HOH
21614	54501-9E000	CONTROL ARM,WITH BUSHINGS	NISSAN	HOH
26342	54524-VW000	CONTROL ARM	NISSAN	
28542	54501-EB70D	CONTROL ARM	NISSAN	HOH
29505	54524-3J201	CONTROL ARM	NISSAN	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31349	55121-50Y00 55121-62C00	CONTROL ARM	NISSAN	
31350	55120-50C00 55120-50Y00	CONTROL ARM	NISSAN	
31351	55121-50A01 55121-50A10	CONTROL ARM	NISSAN	
31352	55120-50A01 55120-50A10	CONTROL ARM	NISSAN	
31353	54527-92G10	CONTROL ARM	NISSAN	
31354	54526-92G10	CONTROL ARM	NISSAN	
32026	54500-51E05	CONTROL ARM	NISSAN	
32077	54500-52Y210	CONTROL ARM	NISSAN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
32078	54501-52Y210	CONTROL ARM	NISSAN	
32079	54501-ZY470 54501-ZY412	CONTROL ARM	NISSAN	
32080	54500-ZY470 54500-ZY412	CONTROL ARM	NISSAN	
32081	54501-01E05 54501-01E00 54571-01E01	CONTROL ARM	NISSAN	
32513	48530-3S185	CONTROL ARM	NISSAN	
38406	54525-VW000	CONTROL ARM	NISSAN	
41609	54501-CK000 54501-EK000	CONTROL ARM	NISSAN	
41610	54500-CK000 54500-EK000	CONTROL ARM	NISSAN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
43208	54500-CC40E 54500-CA010 54500-CC40B 54500-CC40A	CONTROL ARM	NISSAN	
43209	54501-CC40E 54501-CA010 54501-CC40A 54501-CC40B	CONTROL ARM	NISSAN	HOH
47042	54500-EB70D	CONTROL ARM	NISSAN	HOH
60247	54501-EW000 54500-EW000 40160-ED000 54501-ET000 54500-1JY0A	CONTROL ARM	NISSAN	HOH
61646	54525-EA000 54525-EB70A 54525-EB70D	CONTROL ARM	NISSAN	HOH
61647	54524-EB70A 54524-EA000 54524-EB70D	CONTROL ARM	NISSAN	HOH
62356	54500-3A100	CONTROL ARM	NISSAN	HOH
62398	54501-EW001	CONTROL ARM	NISSAN	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
62973	54500-EA000	CONTROL ARM	NISSAN	
62974	54501-EA000	CONTROL ARM	NISSAN	
75018	48530-35G25	CONTROL ARM	NISSAN	
85061	54502-7F000	CONTROL ARM	NISSAN	
88910	54503-7F000	CONTROL ARM	NISSAN	
88983	54500-B9500 54500-04W00 54500-01W00	CONTROL ARM	NISSAN	
88992	54499-01W00 54499-04W00 54499-B9500	CONTROL ARM	NISSAN	
93010	54501-1HA6A 54501-1HA5D 54501-1HA5A 54501-1HA0C	CONTROL ARM	NISSAN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
93009	54500-1HA6A 54500-1HA0C 54500-1HA5D 54500-1HA5A	CONTROL ARM	NISSAN	HOH
87878	54500-1AT0B 54500-1AT0A 54500-1AA0A 54500-1AA1A	CONTROL ARM,FRONT RIGHT	NISSAN	HOH
87879	54500-VB200 54500-VC300	CONTROL ARM,FRONT RIGHT	NISSAN	HOH
87877	54501-1AT0A 54501-1AT0B 54501-1AA0A 54501-1AA1A	CONTROL ARM,FRONT LEFT	NISSAN	HOH
87880	54501-VB200 54501-VC300	CONTROL ARM,FRONT LEFT	NISSAN	HOH
12685	54500-0M010 54500-0M020 54500-0M060 54500-4B000 54500-F4300	CONTROL ARM,RIGHT	NISSAN	HOH
12688	54524-2F010 54524-86J01 54524-86J10 54524-2J001	CONTROL ARM,RIGHT	NISSAN	
12689	54500-50A00	CONTROL ARM,RIGHT	NISSAN	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
12691	54500-52Y10 54500-52Y60 54500-52Y70 54500-52Y15 54500-69Y10	CONTROL ARM,RIGHT	NISSAN	
18652	54500-4Z005	CONTROL ARM,RIGHT	NISSAN	HOH
19846	54524-2S485 54524-2S486 54524-2S400 54524-VK085	CONTROL ARM,RIGHT	NISSAN	
19848	54526-01G00 54526-92G00	CONTROL ARM,RIGHT	NISSAN	HOH
21605	54500-0W000 54500-0W001	CONTROL ARM,RIGHT	NISSAN	
21607	54500-39U01 54500-41U00 54500-41U01 54500-41U02 54500-40U00	CONTROL ARM,RIGHT	NISSAN	
21610	54501-2B000 54501-2B010	CONTROL ARM,RIGHT	NISSAN	HOH
21611	54500-5Y720 54500-2Y411 54500-2Y412 54500-2Y470	CONTROL ARM,RIGHT	NISSAN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25165	54500-52F00	CONTROL ARM,RIGHT	NISSAN	HOH
25544	54500-4M410 54500-5M300 54500-AV605 54500-4M400 54500-4M411 54500-BM410 54500-5M000 54500-F4600	CONTROL ARM,RIGHT	NISSAN	
25574	54500-OE001	CONTROL ARM,RIGHT	NISSAN	HOH
25577	54500-18V01	CONTROL ARM,RIGHT	NISSAN	HOH
25579	54500-67L00 54500-41L00	CONTROL ARM,RIGHT	NISSAN	HOH
29548	54524-2S685 54524-2S686 54524-2S600 E4524-VK385 54524-VK385	CONTROL ARM,RIGHT	NISSAN	
29550	54500-50J00 54500-50J10 54500-50J25	CONTROL ARM,RIGHT	NISSAN	HOH
29552	54500-ED50A	CONTROL ARM,RIGHT	NISSAN	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
29554	54000-9W200	CONTROL ARM,RIGHT	NISSAN	HOH
29556	54500-0E010	CONTROL ARM,RIGHT	NISSAN	HOH
29558	54500-0E001	CONTROL ARM,RIGHT	NISSAN	HOH
31344	54501-VW000	CONTROL ARM,RIGHT	NISSAN	HOH
31347	54524-VW100	CONTROL ARM,RIGHT	NISSAN	
31357	54502-01G90 54502-01G50 54502-01G00 54502-55G90	CONTROL ARM,RIGHT	NISSAN	HOH
31359	54529-01A00 54529-04A00	CONTROL ARM,RIGHT	NISSAN	HOH
31361	54500-AX600 54500-BC41A 54500-BC42A 54560-AX600	CONTROL ARM,RIGHT	NISSAN	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31363	54500-9W200	CONTROL ARM,RIGHT	NISSAN	HOH
31365	54210-01G10	CONTROL ARM,RIGHT	NISSAN	HOH
31658	54500-AV606 54500-AV600	CONTROL ARM,RIGHT	NISSAN	HOH
31662	54500-55G90	CONTROL ARM,RIGHT	NISSAN	HOH
31663	54502-2S485	CONTROL ARM,RIGHT	NISSAN	HOH
31900	55501-9Y000	CONTROL ARM,RIGHT	NISSAN	HOH
31901	54500-7Y000	CONTROL ARM,RIGHT	NISSAN	HOH
32029	54500-2S685 54500-2S601 54500-2S686 54500-VK300 54500-VK325 54500-VK385 E4500-VK385	CONTROL ARM,RIGHT	NISSAN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
36239	54500-8J000 54500-7Y00A	CONTROL ARM,RIGHT	NISSAN	
36240	54500-JN01A	CONTROL ARM,RIGHT	NISSAN	HOH
60246	54500-EL000	CONTROL ARM,RIGHT	NISSAN	
61644	54500-JD000 54500-JG000 54500-BB00A 54500-BR30A 54500-JG00B 54500-JG00A	CONTROL ARM,RIHJT	NISSAN	HOH
62944	54500-JA00B	CONTROL ARM,RIGHT	NISSAN	HOH
69827	54500-EB70A	CONTROL ARM,RIGHT	NISSAN	HOH
70113	54500-EB31A 54500-EB300	CONTROL ARM	NISSAN	HOH
78338	55501-CA00A 55501-CA000	CONTROL ARM,RIGHT	NISSAN	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
78652	54500-AM601	CONTROL ARM,RIGHT	NISSAN	HOH
80226	54501-3TS0A	CONTROL ARM,RIGHT	NISSAN	HOH
88982	54500-ED00A	CONTROL ARM,RIGHT	NISSAN	HOH
91055	54500-3XA0A	CONTROL ARM,WITH BUSHINGS, RIGHT	NISSAN	HOH
12686	54501-0M010 54501-0M020 54501-0M060 54501-4B000 54501-F4300	CONTROL ARM,LEFT	NISSAN	HOH
12687	54525-2F010 54525-86J01 54525-86J10 54525-2J001	CONTROL ARM,LEFT	NISSAN	
12690	54501-50A00	CONTROL ARM,LEFT	NISSAN	HOH
12692	54501-52Y10 54501-52Y60 54501-52Y70 54501-52Y15 54501-69Y10	CONTROL ARM,LEFT	NISSAN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
18656	54501-4Z005	CONTROL ARM,LEFT	NISSAN	HOH
19847	54525-2S485 54525-2S486 54525-2S400 54525-VK085	CONTROL ARM,LEFT	NISSAN	
21606	54501-0W000 54501-0W001	CONTROL ARM,LEFT	NISSAN	
21608	54501-39U01 54501-41U00 54501-41U01 54501-41U02	CONTROL ARM,LEFT	NISSAN	
21609	54500-2B000 54500-2B010	CONTROL ARM,LEFT	NISSAN	HOH
21612	54501-5Y720 54501-2Y411 54501-2Y412 54501-2Y470	CONTROL ARM,LEFT	NISSAN	
25154	54503-01G90 54503-92G90 54503-55G90	CONTROL ARM,LEFT	NISSAN	HOH
25164	54501-52F00	CONTROL ARM,LEFT	NISSAN	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25545	54501-4M410 54501-5M300 54501-AV605 54501-4M400 54501-4M411 54501-BM410 54501-BM300	CONTROL ARM,LEFT	NISSAN	
25578	54501-67L00 54501-41L00	CONTROL ARM,LEFT	NISSAN	HOH
29549	54525-2S685 54525-2S686 54525-2S600 E4525-VK385 54525-VK385	CONTROL ARM,LEFT	NISSAN	
29551	54501-50J00 54501-50J10 54501-50J25	CONTROL ARM,LEFT	NISSAN	HOH
29553	54501-ED50A	CONTROL ARM,LEFT	NISSAN	HOH
29555	54001-9W200	CONTROL ARM,LEFT	NISSAN	HOH
29557	54501-0E010	CONTROL ARM,LEFT	NISSAN	HOH
29559	54501-0E001	CONTROL ARM,LEFT	NISSAN	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31345	54500-VW000	CONTROL ARM,LEFT	NISSAN	
31346	54525-VW100 54525-VX100	CONTROL ARM,LEFT	NISSAN	
31358	54530-01A00 54530-04A00	CONTROL ARM,LEFT	NISSAN	
31360	54501-AX600 54501-BC41A 54501-BC42A 54570-AX600	CONTROL ARM,LEFT	NISSAN	
31362	54501-9W200	CONTROL ARM,LEFT	NISSAN	
31364	54211-01G10	CONTROL ARM,LEFT	NISSAN	
31447	48069-87706	CONTROL ARM,LEFT	NISSAN	
31578	54501-AV606 54501-AV600	CONTROL ARM,LEFT	NISSAN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31661	54501-55G90 54501-01G50 54501-01G00 54501-01G90	CONTROL ARM,LEFT	NISSAN	HOH
31664	54503-2S485	CONTROL ARM,LEFT	NISSAN	HOH
31899	55502-9Y000	CONTROL ARM,LEFT	NISSAN	HOH
31902	54501-7Y000	CONTROL ARM,LEFT	NISSAN	HOH
32022	54501-51E05	CONTROL ARM,LEFT	NISSAN	HOH
32030	54501-2S686 54501-2S685 54501-VK300 54501-VK325 54501-VK385 E4501-VK385	CONTROL ARM,LEFT	NISSAN	HOH
36238	54501-8J000 54501-7Y00A	CONTROL ARM,LEFT	NISSAN	
36241	54501-JN01A	CONTROL ARM,LEFT	NISSAN	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
52721	54501-EB300 54501-EB31A	CONTROL ARM,LEFT	NISSAN	HOH
60251	54501-EL000	CONTROL ARM,LEFT	NISSAN	
61643	54501-JG000 54501-JD000 54501-BB00A 54501-BR30A 54501-JG00B 54501-JG00A	CONTROL ARM,LEFT	NISSAN	HOH
62943	54501-JA00B	CONTROL ARM,LEFT	NISSAN	HOH
69826	54501-EB70A	CONTROL ARM,LEFT	NISSAN	HOH
70112	54525-EB300 54525-EB30A	CONTROL ARM	NISSAN	HOH
78339	55502-CA00A 55502-CA000	CONTROL ARM,LEFT	NISSAN	HOH
78651	54501-AM601	CONTROL ARM,LEFT	NISSAN	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
80225	54500-3TS0A	CONTROL ARM,LEFT	NISSAN	
88980	54501-ED00A	CONTROL ARM,LEFT	NISSAN	
91069	54501-3XA0A	CONTROL ARM,WITH BUSHINGS, LIFTER	NISSAN	
12682	48530-01G00 48530-01G25	CONTROL ARM	NISSAN	
48197	48503-04C00	CONTROL ARM,WITH BALL JOINT	NISSAN	
48198	48503-31G25	CONTROL ARM,WITH BALL JOINT	NISSAN	
48199	48503-35G25	CONTROL ARM,WITH BALL JOINT	NISSAN	
48200	48530-18V00 48530-20V00	CONTROL ARM,WITH BALL JOINT	NISSAN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
48201	48530-15G25	CONTROL ARM,WITH BALL JOINT	NISSAN	HOH
48202	48530-50W10	CONTROL ARM,WITH BALL JOINT	NISSAN	HOH
48203	48530-21L00	CONTROL ARM,WITH BALL JOINT	NISSAN	HOH
48205	48530-N8500	CONTROL ARM,WITH BALL JOINT	NISSAN	HOH
48206	48530-V0100 48530-V0125	CONTROL ARM,WITH BALL JOINT	NISSAN	HOH
48207	48530-S2103 48530-S2102	CONTROL ARM,WITH BALL JOINT	NISSAN	HOH
48208	48530-G2701	CONTROL ARM,WITH BALL JOINT	NISSAN	HOH
48209	48530-09W10	CONTROL ARM,WITH BALL JOINT	NISSAN	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
48210	48530-09W00	CONTROL ARM,WITH BALL JOINT	NISSAN	
48211	48530-U8701 48530-P7100	CONTROL ARM,WITH BALL JOINT	NISSAN	
48212	48530-H5000 48530-H5025	CONTROL ARM,WITH BALL JOINT	NISSAN	
48213	48530-B9510	CONTROL ARM,WITH BALL JOINT	NISSAN	
48214	48530-B9500 48530-B9525	CONTROL ARM,WITH BALL JOINT	NISSAN	
48215	48530-H1600	CONTROL ARM,WITH BALL JOINT	NISSAN	
48216	48530-H1000	CONTROL ARM,WITH BALL JOINT	NISSAN	
48217	48530-20500 48530-B0105	CONTROL ARM,WITH BALL JOINT	NISSAN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
48218	48530-21000	CONTROL ARM,WITH BALL JOINT	NISSAN	HOH
48222	48510-41L25	CONTROL ARM,WITH BALL JOINT	NISSAN	HOH
31898	54500-8H310 54500-8H31A	CONTROL ARM,RIGHT,UPPER,ALUMINUM	NISSAN	HOH
31897	54501-8H310 54501-8H31A	CONTROL ARM,LEFT,UPPER,ALUMINUM	NISSAN	HOH
21191	54501-2F500	CONTROL ARM,WITH BUSHINGS	NISSAN/HYUNDAI	
21192	54500-2F500	CONTROL ARM,WITH BUSHINGS	NISSAN/HYUNDAI	
31741	54502-00QAA 54502-00QAB 82 00 054 006 82 00 247 900 44 12 936 93851118 91166461	CONTROL ARM,RIGHT	NISSAN/RENAULT /OPEL	HOH
31740	54503-00QAA 54503-00QAB 82 00 054 003 82 00 247 898 44 12 934 91166462 93851117	CONTROL ARM,LEFT	NISSAN/RENAULT /OPEL	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
62948	54530-4A00D 45201-M68K00	CONTROL ARM,RIGHT	NISSAN/SUZUKI	HOH
62947	54529-4A00D 45202-M68K00	CONTROL ARM,LEFT	NISSAN/SUZUKI	HOH
46831		CONTROL ARM KIT	OPEL	
46832		CONTROL ARM KIT	OPEL	
22548	04 23 033 04 23 035 04 23 008 13 105 744 13 204 115 13 230 274	CONTROL ARM	OPEL	HOH
45233	44 08 958	CONTROL ARM	OPEL	HOH
78328	3 52 511 3 52 512 13 371 819 13 371 818	CONTROL ARM	OPEL	HOH
79936	04 23 046	CONTROL ARM	OPEL	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
89849	90895159	CONTROL ARM	OPEL	HOH
89850	90895160	CONTROL ARM	OPEL	HOH
5953	03 52 192 03 52 076 90 495 160 90 473 227	CONTROL ARM,RIGHT	OPEL	
5998	53 52 004 90496040 03 52 030 09 228 477	CONTROL ARM,RIGHT	OPEL	HOH
6009	53 52 017 90498736	CONTROL ARM,RIGHT	OPEL	
6012	03 52 044 90166391	CONTROL ARM,RIGHT	OPEL	HOH
6017	03 52 028 03 52 196 53 52 008 90497308 90576789	CONTROL ARM,RIGHT	OPEL	
11010	03 52 164	CONTROL ARM,RIGHT	OPEL	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
11011	03 52 136 03 52 134 90288388	CONTROL ARM,RIGHT	OPEL	
11676	03 52 042 03 52 063 13 140 038 24 428 978	CONTROL ARM,RIGHT	OPEL	
11695	03 52 182 03 52 002 90445119 90511261	CONTROL ARM,RIGHT	OPEL	
14660	03 52 012 53 52 012 90 542 573	CONTROL ARM,RIGHT	OPEL	HOH
22427	53 52 000 90 495 104	CONTROL ARM,RIGHT	OPEL	HOH
31699	53 52 028 93 388 569	CONTROL ARM,RIGHT	OPEL	HOH
31704	53 52 030 24 454 478	CONTROL ARM,RIGHT	OPEL	
53420	4404048	CONTROL ARM,RIGHT	OPEL	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
64601	53 52 038	CONTROL ARM,RIGHT	OPEL	HOH
78327	3 52 510 13 371 817	CONTROL ARM,RIGHT	OPEL	HOH
5952	03 52 193 03 52 128 03 52 077 90473226 90495159	CONTROL ARM,LEFT	OPEL	
5997	53 52 005 90496039	CONTROL ARM,LEFT	OPEL	HOH
6008	53 52 016 90498735	CONTROL ARM,LEFT	OPEL	
6016	03 52 029 03 52 197 53 52 007 90497307 90576788	CONTROL ARM,LEFT	OPEL	
11012	03 52 135 03 52 132 90288387	CONTROL ARM,LEFT	OPEL	
11675	03 52 041 03 52 061 13 140 037 24 428 977	CONTROL ARM,LEFT	OPEL	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
11688	03 52 189	CONTROL ARM,LEFT	OPEL	HOH
11694	03 52 181 03 52 003 90511260 90445118	CONTROL ARM,LEFT	OPEL	
12965	03 52 043 90166390	CONTROL ARM,LEFT	OPEL	HOH
14659	03 52 011 53 52 011 90 542 572	CONTROL ARM,LEFT	OPEL	HOH
22428	53 52 001 90 495 103	CONTROL ARM,LEFT	OPEL	HOH
31698	53 52 027 93 388 568	CONTROL ARM,LEFT	OPEL	HOH
31703	53 52 029 24 454 477	CONTROL ARM,LEFT	OPEL	
64602	53 52 039	CONTROL ARM,LEFT	OPEL	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
78326	3 52 509 13 371 816	CONTROL ARM,LEFT	OPEL	HOH
11008	03 52 052 12 796 014 12 799 200 24 413 016 51748652 13225799	CONTROL ARM,RIGHT,ALUMINUM	OPEL	
46726	96819161 96626235 48 10 831 48 06 300 48 17 777	CONTROL ARM,LEFT	OPEL/CHEVROLET	HOH
11009	96445372 03 52 148 03 52 172 90 375 506 96185970 96218398 03 52 124	CONTROL ARM,RIGHT	OPEL/DAEWOO	HOH
11690	96445371 03 52 059 03 52 147 03 52 169 90 375 505 96185969 96185971 96218397 96445374 53 52 014 03 52 123	CONTROL ARM,LEFT	OPEL/DAEWOO	HOH
11007	03 52 051 24 413 015 12 796 013 12 799 199 51748653 13225798	CONTROL ARM,LEFT,ALUMINUM	OPEL/FIAT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31743	44 01 853 44 01 941 44 00 048 45 00 093 09 109 853 09 109 941 09 112 048 09 160 393 77 00 302 119 77 00 309 190 82 00 270 058 54500-00QAD 54500-00QAE	CONTROL ARM,RIGHT	OPEL/NISSAN/RENAULT	
78624	13 258 056 324000	CONTROL ARM	OPEL/SAAB	
11693	47 05 172 92 08 987 45200-75F00 45200-75F20	CONTROL ARM	OPEL/SUZUKI	
31697	45200-76G20 45200-83E00 45200-84E00 45200-85E00 45200-76G00	CONTROL ARM	OPEL/SUZUKI	
79937	04 23 062 13 332 257 13 262 449	CONTROL ARM	OPEL/VAUXHALL	
78646	48069-BZ261	CONTROL ARM	PERODUA	
78647	48068-BZ260	CONTROL ARM	PERODUA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
11692	3521.71 3521.A5 3521.A6	CONTROL ARM,RIGHT	PEUGEOT	HOH
8399	3521.34 3521.31 3521.33 91 516 337	CONTROL ARM,RIGHT	PEUGEOT	
8408	3521.C8 3521.S5 3521.H9 3521.S1 3521.P5	CONTROL ARM,BACK ARTICULATION,RIGHT	PEUGEOT	
13503	3521.E7 3521.K2 3521.R7	CONTROL ARM,RIGHT	PEUGEOT	HOH
8326	3520.48 3520.50 3520.51 91 516 336 3520.49	CONTROL ARM,LEFT	PEUGEOT	
8407	3520.G8 3520.W0 3520.H7 3520.L8 3520.P2 3520.V7 3520.V6	CONTROL ARM,BACK ARTICULATION,LEFT	PEUGEOT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
22310	3521.G0	CONTROL ARM,RIGHT	PEUGEOT	HOH
8412	3520.H3 3520.H5 3520.H6 3520.99 3520.98 3520.C6 3520.F5 3520.F6 3520.E6 3520.E8 3520.F2 3520.F1 3520.E0 3520.E7 3520.A8 3520.A9 3520.C7 3520.E4 3520.F3 3520.F8 3520.E1 3520.E9 3520.F7	CONTROL ARM,WITH BUSHINGS,LEFT,UPPER,ALUMINUM	PEUGEOT	
8413	3521.G8 3521.K3 3521.P3 3521.Q1	CONTROL ARM,RIGHT	PEUGEOT	HOH
8414	3520.K8 3520.P3 3520.S2 3520.T0	CONTROL ARM,WITH BUSHINGS,LEFT,UPPER,ALUMINUM	PEUGEOT	
13507	3521.46 3521.49 3521.G5	CONTROL ARM,RIGHT	PEUGEOT	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
23268	3520.A6 3520.A7 3520.K4 3520.47	CONTROL ARM,LEFT	PEUGEOT	HOH
13508	3520.68 3520.65	CONTROL ARM,LEFT,D=13MM	PEUGEOT	HOH
8425	3521.64 3521.83 3521.85 3521.C9 3521.K4 3521.L0 3521.J9 1313084080 1317390080 1316736080	CONTROL ARM,WITH BUSHINGS,RIGHT,UPPER,ALUMINUM	PEUGEOT	
8424	3520.94 3520.C3 3520.C5 3520.G9 3520.P8 3520.P4 1313083080 1317389080 1316735080	CONTROL ARM,WITH BUSHINGS,LEFT,UPPER,ALUMINUM	PEUGEOT	
46847		CONTROL ARM KIT	PEUGEOT	HOH
31343	3521.H1 3521.K6 93501488 1346385080	CONTROL ARM,RIGHT	PEUGEOT	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31342	3521.H0 3520.P6 93501487 1346384080	CONTROL ARM,LEFT	PEUGEOT	HOH
54775	3521.P6 3521.T2 1356061080	CONTROL ARM,LEFT	PEUGEOT	HOH
31398	3520.10 3521.18 3521.20 91 504 359	CONTROL ARM	PEUGEOT	HOH
38820	2520.H7	CONTROL ARM	PEUGEOT	HOH
47514	3520.C8	CONTROL ARM	PEUGEOT	HOH
95019	3520.X5	CONTROL ARM	PEUGEOT	HOH
95020	3521.T6	CONTROL ARM	PEUGEOT	HOH
8422	3521.41 3521.38	CONTROL ARM,RIGHT	PEUGEOT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
13489	3520.93 3520.81	CONTROL ARM,RIGHT	PEUGEOT	
13493	3521.37 91 519 408	CONTROL ARM,RIGHT	PEUGEOT	HOH
13494	3520.79 95 658 979	CONTROL ARM,WITH BALL JOINT,WITH BUSH,RIGHT	PEUGEOT	
13500	3521.F3 3521.R4 3521.R5 3521.L4 3521.L5 3521.L6	CONTROL ARM,RIGHT	PEUGEOT	
13505	3520.71 3521.G6	CONTROL ARM,RIGHT	PEUGEOT	HOH
15928	3520.A2 3520.G5 3520.G3	CONTROL ARM,RIGHT	PEUGEOT	HOH
24663	3521.26	CONTROL ARM,RIGHT	PEUGEOT	HOH
24664	3521.72 3521.60	CONTROL ARM,RIGHT	PEUGEOT	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
24665	3521.80 3521.E1	CONTROL ARM,RIGHT	PEUGEOT	HOH
24666	3521.H6 3521.J1 3521.N3 3521.N7 3521.K1	CONTROL ARM,RIGHT	PEUGEOT	
31512	4391813 3521.28	CONTROL ARM,RIGHT	PEUGEOT	HOH
31764	3521.L2 3521.J6	CONTROL ARM,RIGHT	PEUGEOT	HOH
53417	352073	CONTROL ARM,RIGHT	PEUGEOT	HOH
54773	3521.45	CONTROL ARM,RIGHT	PEUGEOT	HOH
23436	3521.77 3521.76 3521.G4	CONTROL ARM,RIGHT D=15MM	PEUGEOT	HOH
8421	3520.60 3520.57	CONTROL ARM,WITH BUSHINGS,LEFT,UPPER,ALUMINUM	PEUGEOT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
11689	3521.90	CONTROL ARM,LEFT	PEUGEOT	HOH
13491	3520.80 3520.92	CONTROL ARM,LEFT	PEUGEOT	
13501	3520.J3 3520.J9 3520.H9 3520.Q3 3520.Q4 3520.Q5 3520.V3	CONTROL ARM,LEFT	PEUGEOT	
13506	3520.70 3520.K6	CONTROL ARM,LEFT	PEUGEOT	HOH
20802	3520.C0 3520.H1	CONTROL ARM,LEFT	PEUGEOT	HOH
24660	3520.37	CONTROL ARM,LEFT	PEUGEOT	
24661	3520.84	CONTROL ARM,LEFT	PEUGEOT	HOH
24662	3520.L4 3520.L9 3520.R5 3520.R2 3520.R6 3520.P1	CONTROL ARM,LEFT	PEUGEOT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31393	3520.N3 3812.E8 1331938080	CONTROL ARM,LEFT	PEUGEOT	
31403	3520.96 3520.L1 1308759080 1317238080	CONTROL ARM,LEFT	PEUGEOT	
31509	4391814 3520.41	CONTROL ARM,LEFT	PEUGEOT	
31765	3520.N6 3520.Q1	CONTROL ARM,LEFT	PEUGEOT	
53416	3520.72	CONTROL ARM,LEFT	PEUGEOT	
54772	3520.64	CONTROL ARM,LEFT	PEUGEOT	
94024	3520.H7	CONTROL ARM,BACK ARTICULATION,LEFT	PEUGEOT	
20801	3521.C3 3521.C5	CONTROL ARM,FRONT,RIGHT,WITH BUSHINGS	PEUGEOT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
20803	3521.C6	CONTROL ARM,RIGHT	PEUGEOT	HOH
78299	3520.R7 3520.Q9	CONTROL ARM,LEFT	PEUGEOT/CITRO EN	HOH
13492	3520.54 91 519 409	CONTROL ARM,LEFT	PEUGEOT/CITRO EN	HOH
13495	3520.78 95 658 978	CONTROL ARM WITH BALL JOINT,WITH BUSH,LEFT	PEUGEOT/CITRO EN	
31514	3521.52 7695190 7576731	CONTROL ARM,RIGHT	PEUGEOT/FIAT	HOH
31518	3521.53 7695185 7567282	CONTROL ARM,RIGHT	PEUGEOT/FIAT	HOH
31513	3520.76 7695191 7576732	CONTROL ARM,LEFT	PEUGEOT/FIAT	HOH
31517	3520.77 7695186 7567283	CONTROL ARM,LEFT	PEUGEOT/FIAT	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
54754	3521.P1 3521.P2 1352225080 1352226080	CONTROL ARM,RIGHT	PEUGEOT/FIAT	HOH
54753	3520.S0 3520.S1 1352227080 1352228080	CONTROL ARM,LEFT	PEUGEOT/FIAT	HOH
11686	3521.65 3521.H2 3520.N4 1339467080 1320787080	CONTROL ARM,RIGHT	PEUGEOT/FIAT/CITROEN	HOH
31356	3521.66 3521.H3 3521.J4 1317239080 1320756080 1308760080	CONTROL ARM,RIGHT	PEUGEOT/FIAT/CITROEN	HOH
31348	3520.95 3520.L0 1317240080 1308600080 1320786080	CONTROL ARM,LEFT	PEUGEOT/FIAT/CITROEN	HOH
46712	3521.L3 48068-0H010	CONTROL ARM,RIGHT	PEUGEOT/TOYOTA	HOH
46711	3520.Q2 48069-0H010	CONTROL ARM,LEFT	PEUGEOT/TOYOTA	HOH
8411	3521.E5 3521.E3 3521.55 3521.56 3521.68 3521.69 3521.A1 95658884 95668510	CONTROL ARM,RIGHT	PEUGEOT/CITROEN	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
13504	79 01 352 035 3520.34 91 504 358	CONTROL ARM,WITH BUSHINGS	PEUGEOTCITRO ENIRENAULT	HOH
36242	996 341 053 16 996 341 053 14 996 341 053 06 996 341 053 07	CONTROL ARM	PORSCHE	HOH
71058	970 341 051 03 970 341 051 10	CONTROL ARM	PORSCHE	HOH
71057	970 341 054 04	CONTROL ARM,RIGHT	PORSCHE	HOH
71056	970 341 053 04	CONTROL ARM,LEFT	PORSCHE	HOH
31217	7L0 407 151 C 7L0 407 151 D 7L0 407 151 E 7L0 407 151 H 955 341 017 32 955 341 017 31 955 341 017 30 955 341 017 33 JTC1060	CONTROL ARM,LEFT	PORSCHE/VW	
31666	01 497 393	CONTROL ARM	RENAULT	HOH
31695	77 01 497 393	CONTROL ARM	RENAULT	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31755	77 01 552 545	CONTROL ARM	RENAULT	HOH
31758	77 00 649 110	CONTROL ARM	RENAULT	HOH
31757	77 00 504 457	CONTROL ARM,REAR RIGHT	RENAULT	HOH
31756	77 00 504 459	CONTROL ARM,REAR LEFT	RENAULT	HOH
8432	82 00 273 729 82 00 452 716 82 00 026 655 82 00 389 135 82 00 602 613	CONTROL ARM,RIGHT	RENAULT	HOH
24637	60 01 538 336 77 00 783 458	CONTROL ARM,RIGHT	RENAULT	HOH
24643	77 00 436 303 77 00 781 035 77 00 831 369 77 00 818 052	CONTROL ARM,RIGHT	RENAULT	
24645	77 00 783 450 77 00 695 674	CONTROL ARM,RIGHT	RENAULT	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
24647	77 00 783 454 77 00 783 456	CONTROL ARM,RIGHT	RENAULT	
24649	77 00 794 387 60 01 025 842 77 00 794 778 77 00 794 834	CONTROL ARM,RIGHT	RENAULT	
24651	77 00 823 098 77 00 413 494	CONTROL ARM,RIGHT	RENAULT	
24653	82 00 255 761	CONTROL ARM,RIGHT	RENAULT	
24655	82 00 679 067 82 00 298 455 82 00 457 209 54 50 030 37R	CONTROL ARM,RIGHT	RENAULT	
24657	82 00 346 942 82 00 744 092 82 00 615 058	CONTROL ARM,RIGHT	RENAULT	
24659	82 00 565 079	CONTROL ARM,RIGHT	RENAULT	
31540	77 00 533 368	CONTROL ARM,RIGHT	RENAULT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31739	77 00 802 344 77 00 781 438	CONTROL ARM,RIGHT	RENAULT	
31745	60 25 307 650 60 25 305 573	CONTROL ARM,RIGHT	RENAULT	
31747	77 00 807 581 77 00 823 581	CONTROL ARM,RIGHT	RENAULT	
31749	77 00 781 037 77 00 818 054 77 00 829 842 77 00 430 832	CONTROL ARM,RIGHT	RENAULT	
31751	77 00 834 917 82 00 737 133 77 00 430 766	CONTROL ARM,RIGHT	RENAULT	
31754	77 00 676 325	CONTROL ARM,RIGHT	RENAULT	
31760	60 01 021 455 77 00 783 464	CONTROL ARM,RIGHT	RENAULT	
31762	77 00 820 029 82 00 737 126	CONTROL ARM,RIGHT	RENAULT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46714	82 00 266 041 82 00 423 382 82 00 484 811 82 00 602 617	CONTROL ARM,RIGHT	RENAULT	HOH
71892	54 50 003 99R 54 50 065 60R 54 50 092 07R	CONTROL ARM,RIGHT	RENAULT	HOH
78289	82 00 586 567	CONTROL ARM,RIGHT	RENAULT	HOH
85075	54 50 045 29R	CONTROL ARM,RIGHT	RENAULT	HOH
24636	60 01 538 335 77 00 783 457	CONTROL ARM,LEFT	RENAULT	HOH
24642	77 00 831 368 77 00 436 302 77 00 781 034 77 00 818 051	CONTROL ARM,LEFT	RENAULT	
24644	77 00 783 449 77 00 695 673	CONTROL ARM,LEFT	RENAULT	HOH
24646	77 00 783 455 77 00 783 453	CONTROL ARM,LEFT	RENAULT	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
24648	77 00 794 386 60 01 025 841 77 00 794 777 77 00 794 833	CONTROL ARM,LEFT	RENAULT	
24650	77 00 823 097 77 00 413 493	CONTROL ARM,LEFT	RENAULT	
24652	82 00 255 760	CONTROL ARM,LEFT	RENAULT	
24654	82 00 298 454 82 00 457 208 82 00 679 063 54 50 177 75R	CONTROL ARM,LEFT	RENAULT	
24656	82 00 346 941 82 00 744 091 82 00 615 057	CONTROL ARM,LEFT	RENAULT	
24658	82 00 565 072	CONTROL ARM,LEFT	RENAULT	
24669	82 00 026 654 82 00 389 134 82 00 452 715 82 00 273 728 82 00 602 612	CONTROL ARM,LEFT	RENAULT	
31538	77 00 533 367	CONTROL ARM,LEFT	RENAULT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31744	77 00 802 343	CONTROL ARM,LEFT	RENAULT	
31746	60 25 305 572 60 25 307 649	CONTROL ARM,LEFT	RENAULT	
31748	77 00 807 580 77 00 823 580	CONTROL ARM,LEFT	RENAULT	
31750	77 00 829 841 77 00 430 831 77 00 818 053	CONTROL ARM,LEFT	RENAULT	
31752	77 00 562 943 77 01 590 974	CONTROL ARM,LEFT	RENAULT	
31753	77 00 676 324 77 00 754 210	CONTROL ARM,LEFT	RENAULT	
31759	60 01 021 454 77 00 783 463	CONTROL ARM,LEFT	RENAULT	
31761	82 00 737 125 77 00 820 028	CONTROL ARM,LEFT	RENAULT	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46713	82 00 266 038 82 00 423 381 82 00 484 810 82 00 602 616	CONTROL ARM,LEFT	RENAULT	HOH
71891	54 50 140 55R 54 50 161 01R 54 50 168 38R	CONTROL ARM,LEFT	RENAULT	HOH
78255	77 00 834 916 77 00 430 765 82 00 737 132	CONTROL ARM,LEFT	RENAULT	HOH
78288	82 00 586 561	CONTROL ARM,LEFT	RENAULT	HOH
85074	54 50 102 94R	CONTROL ARM,LEFT	RENAULT	HOH
13135	77 00 571 172	CONTROL ARM,LEFT	RENAULT	HOH
24638	60 01 547 519 82 00 216 377 82 00 820 918 60 01 550 447 60 01 550 910 545004269R	CONTROL ARM,RIGHT	RENAULT/DACIA	
24639	60 01 547 520 60 01 550 446 82 00 820 930 82 00 216 376 60 01 550 909 54 50 117 27R	CONTROL ARM,LEFT	RENAULT/DACIA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
24641	77 00 313 945 77 00 425 228 82 00 197 187 54500-00QAH	CONTROL ARM,RIGHT	RENAULT/NISSAN	
24640	77 00 425 227 77 00 313 944 82 00 197 179 54501-00QAH	CONTROL ARM,LEFT	RENAULT/NISSAN	
36245	RBX 101770	CONTROL ARM	ROVER	HOH
36246	RBX 101760	CONTROL ARM	ROVER	HOH
36244	GSJ 1000 RBJ 102500 RBJ 000370	CONTROL ARM,RIGHT	ROVER	
36243	GSJ 1001 RBJ 102510	CONTROL ARM,LEFT	ROVER	
29333	4647012	CONTROL ARM	SAAB	HOH
25186	93185280	CONTROL ARM,RIGHT	SAAB	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25187	93185279	CONTROL ARM,LEFT	SAAB	HOH
8846	45 43 468	CONTROL ARM,RIGHT,UPPER,ALUMINUM	SAAB	
27633	42 48 449	CONTROL ARM,RIGHT,UPPER,ALUMINUM	SAAB	HOH
8847	45 43 450	CONTROL ARM,LEFT,UPPER,ALUMINUM	SAAB	
27632	42 48 431	CONTROL ARM,LEFT,UPPER,ALUMINUM	SAAB	HOH
46026	6RD 407 151 6R0 407 151 6R0 407 151 E	CONTROL ARM,LEFT	SEAT/SKODA/VW	
24548	3C0 407 151 E 3C0 407 151 A 3C0 407 151 B 3C0 407 151 H 0 3C0 407 151 G	CONTROL ARM,LEFT/RIGHT	SEAT/VW	
32980	4B3 498 500	CONTROL ARM	SKODA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31737	115-420022	CONTROL ARM	SKODA	
51560	113-420022	CONTROL ARM	SKODA	
51561	113-420023	CONTROL ARM	SKODA	
51562	113-420010	CONTROL ARM	SKODA	
51563	113-202431	CONTROL ARM	SKODA	
51564	007 304 443	CONTROL ARM	SKODA	
51565	1J0 407 151 CL	CONTROL ARM	SKODA	
51566	1J0 407 151 CR	CONTROL ARM	SKODA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
51568	6Q0 407 151 DL 6Q0 407 151 DR	CONTROL ARM	SKODA	
31738	115-420021	CONTROL ARM	SKODA	HOH
8472	6U0 407 152 6U0 407 152 A 007 304 448	CONTROL ARM,RIGHT	SKODA/VW	
8471	6U0 407 151 6U0 407 151 A 007 304 447	CONTROL ARM,LEFT	SKODA/VW	
46752	20202-SC010	CONTROL ARM	SUBARU	HOH
46753	20202-SC000	CONTROL ARM	SUBARU	HOH
62039	20202-SA000	CONTROL ARM, RIGHT	SUBARU	HOH
61207	20202-SA010 *BS-704	CONTROL ARM,LEFT	SUBARU	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
19711	45200-50E00 45200-69D00 45200-78000 45200-78002 45200-84000 45200-A70B00 45200-A78B00 45200-A78B01	CONTROL ARM,WITH BUSHINGS	SUZUKI	
25118	46200-56B00	CONTROL ARM	SUZUKI	HOH
31429	45200-85001 45200-85002	CONTROL ARM	SUZUKI	HOH
31931	45200-82000	CONTROL ARM	SUZUKI	HOH
32358	45200-80001	CONTROL ARM	SUZUKI	HOH
60111	45201-54G01	CONTROL ARM	SUZUKI	HOH
60112	45201-59J00	CONTROL ARM	SUZUKI	HOH
60113	45202-59J00	CONTROL ARM	SUZUKI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
82961	45200-81A10 45200-81A12 45200-81A11	CONTROL ARM	SUZUKI	
90218	46200-81A10 46200-81A11 46200-81A12 46200-81A13	CONTROL ARM	SUZUKI	
82963	45201-65J00 45201-78K00	CONTROL ARM,FRONT RIGHT	SUZUKI	
88993	45201-60860	CONTROL ARM,FRONT RIGHT	SUZUKI	
82962	45202-65J00 45202-78K00	CONTROL ARM,FRONT LEFT	SUZUKI	
88994	45200-60860	CONTROL ARM,FRONT LEFT	SUZUKI	
31440	45201-62J00 45201-63J00	CONTROL ARM,RIGHT	SUZUKI	
32356	45201-67D01 45201-65D01 45201-67D01-000	CONTROL ARM,RIGHT	SUZUKI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46749	45201-63G01	CONTROL ARM,RIGHT	SUZUKI	
46751	45201-85C00 45201-86C00	CONTROL ARM,RIGHT	SUZUKI	
70359	48066-29215	CONTROL ARM,RIGHT	SUZUKI	
23681	45202-54G01	CONTROL ARM,LEFT	SUZUKI	
32357	45202-67D01 45202-65D01 45202-67D01-000	CONTROL ARM,LEFT	SUZUKI	
46748	45202-63G01	CONTROL ARM,LEFT	SUZUKI	
46750	45202-85C00 45202-86C00	CONTROL ARM,LEFT	SUZUKI	
70360	48067-29215	CONTROL ARM,LEFT	SUZUKI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
54809	45201-79J00 71742731	CONTROL ARM,RIGHT	SUZUKI/FIAT	
54812	45202-79J00	CONTROL ARM,LEFT	SUZUKI/FIAT	
21739	48065-35120	CONTROL ARM,WITH BUSHINGS	TOYOTA	
7775	2901040-03L	CONTROL ARM ASSY,UPPER,RIGHT	TOYOTA	
7774	2901030-03L	CONTROL ARM ASSY,UPPER,LEFT	TOYOTA	
7773	2901040-03	CONTROL ARM,UPPER,RIGHT	TOYOTA	
7772	2901030-03	CONTROL ARM,UPPER,LEFT	TOYOTA	
7770	2901060-00	CONTROL ARM,LOWER,RIGHT	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
7771	2901050-00	CONTROL ARM,LOWER,LEFT	TOYOTA	
5913	45490-39365	CONTROL ARM	TOYOTA	
12356	45490-39315	CONTROL ARM	TOYOTA	
12358	45490-19215	CONTROL ARM	TOYOTA	
12382	48068-26020 48068-26H00	CONTROL ARM,FRONT,WITH BUSHINGS	TOYOTA	
12383	48069-26020 48069-26H00	CONTROL ARM,FRONT,WITH BUSHINGS	TOYOTA	
15959	45490-35130	CONTROL ARM	TOYOTA	
23228	48067-29225	CONTROL ARM	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
24134	45490-19225	CONTROL ARM	TOYOTA	HOH
24176	45490-39245 45490-39325 45490-39355	CONTROL ARM	TOYOTA	HOH
24206	45490-39445	CONTROL ARM	TOYOTA	HOH
24471	48066-29225	CONTROL ARM	TOYOTA	HOH
24667	48068-12290	CONTROL ARM	TOYOTA	HOH
24668	48069-12290	CONTROL ARM	TOYOTA	HOH
25567	48066-35080 48065-35030 48067-35030	CONTROL ARM	TOYOTA	
29514	48620-32040	CONTROL ARM	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
29515	48640-32040	CONTROL ARM	TOYOTA	
29516	48068-48041	CONTROL ARM	TOYOTA	
29517	48069-48040	CONTROL ARM	TOYOTA	
29518	48068-09110	CONTROL ARM	TOYOTA	
29519	48069-09100	CONTROL ARM	TOYOTA	
29520	48069-02180	CONTROL ARM	TOYOTA	
29521	48068-02180	CONTROL ARM	TOYOTA	
29655	48480-0N010	CONTROL ARM	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
29656	48620-30290	CONTROL ARM	TOYOTA	
31531	48068-48040	CONTROL ARM	TOYOTA	
32010	48066-28050 48066-28030	CONTROL ARM	TOYOTA	
32011	48067-28050	CONTROL ARM	TOYOTA	
32012	48066-29135	CONTROL ARM	TOYOTA	
32013	48067-29135	CONTROL ARM	TOYOTA	
32014	48066-35050	CONTROL ARM	TOYOTA	
32523	45490-39455 45490-39456	CONTROL ARM	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
38544	48710-60080	CONTROL ARM	TOYOTA	
38545	48720-60040	CONTROL ARM	TOYOTA	
41395	45490-39305	CONTROL ARM	TOYOTA	
41397	48068-35090	CONTROL ARM	TOYOTA	
41398	45490-29415	CONTROL ARM	TOYOTA	
41399	45040-69090	CONTROL ARM	TOYOTA	
43151	48068-09010	CONTROL ARM	TOYOTA	
43152	48069-09010	CONTROL ARM	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
46410	48068-08021	CONTROL ARM	TOYOTA	
46411	48069-08021	CONTROL ARM	TOYOTA	
47030	48068-0K050	CONTROL ARM	TOYOTA	
47885	54524-VX100	CONTROL ARM	TOYOTA	
52302	48710-35030	CONTROL ARM	TOYOTA	
52390	48770-24050	CONTROL ARM	TOYOTA	
52391	48790-24050	CONTROL ARM	TOYOTA	
52392	48068-14080	CONTROL ARM	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
52393	48069-14080	CONTROL ARM	TOYOTA	
59429	48069-20390	CONTROL ARM	TOYOTA	
59430	48068-20390	CONTROL ARM	TOYOTA	
60285	45046-59195	CONTROL ARM	TOYOTA	
61364	48069-20221	CONTROL ARM	TOYOTA	
61648	48069-10100	CONTROL ARM	TOYOTA	
61649	48605-35180 48605-35181	CONTROL ARM	TOYOTA	
61650	48606-35181 48606-35180	CONTROL ARM	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
62938	48770-30052	CONTROL ARM	TOYOTA	
62939	48790-30052	CONTROL ARM	TOYOTA	
62952	48068-97201 48068-97401	CONTROL ARM	TOYOTA	
62953	48069-97401 48069-97201	CONTROL ARM	TOYOTA	
62963	48630-60050	CONTROL ARM	TOYOTA	
62964	48610-60070 48630-60040	CONTROL ARM	TOYOTA	
68422	48630-39025	CONTROL ARM	TOYOTA	
70363	48067-35080	CONTROL ARM	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
73171	48730-33080	CONTROL ARM	TOYOTA	
75199	48632-26090	CONTROL ARM	TOYOTA	
87875	48069-58010	CONTROL ARM	TOYOTA	
88397	48710-35040	CONTROL ARM	TOYOTA	
88399	48730-12130	CONTROL ARM	TOYOTA	
88985	48070-0K010	CONTROL ARM	TOYOTA	
89602	48710-0R010 48710-42020	CONTROL ARM	TOYOTA	
89848	48068-26022	CONTROL ARM	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
90154	48640-59015	CONTROL ARM	TOYOTA	
90155	48620-59015	CONTROL ARM	TOYOTA	
90156	48640-50070	CONTROL ARM	TOYOTA	
90157	48620-50070	CONTROL ARM	TOYOTA	
90158	48610-59135 48610-59095	CONTROL ARM	TOYOTA	
90159	48610-59125 48610-59085	CONTROL ARM	TOYOTA	
90160	48630-59125 48630-59085	CONTROL ARM	TOYOTA	
94617	48069-0D081	CONTROL ARM	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
94618	48068-0D081	CONTROL ARM	TOYOTA	
24205	45490-35140	CONTROL ARM,L=202MM	TOYOTA	
87872	48066-29105 48066-29115 48066-29045	CONTROL ARM,REAR RIGHT	TOYOTA	
87871	48067-29115 48067-29105 48067-29045	CONTROL ARM,REAR LEFT	TOYOTA	
60282	48068-42040 48068-42041	CONTROL ARM,FRONT RIGHT	TOYOTA	
87874	48066-29165	CONTROL ARM,FRONT RIGHT	TOYOTA	
88986	48068-19065 48068-19125	CONTROL ARM,FRONT RIGHT	TOYOTA	
89282	48068-05050	CONTROL ARM,FRONT RIGHT	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
60283	48069-42040 48069-42041	CONTROL ARM,FRONT LEFT	TOYOTA	HOH
87873	48067-29165	CONTROL ARM,FRONT LEFT	TOYOTA	HOH
89281	48069-05050	CONTROL ARM,FRONT LEFT	TOYOTA	HOH
12367	48068-12171 48068-12181 48068-12191 48068-12180 48068-12170 48068-12190 48068-02010 48068-12160 210542	CONTROL ARM,RIGHT	TOYOTA	
12376	48068-12130 48068-12140	CONTROL ARM,RIGHT	TOYOTA	HOH
12378	48068-33010 48068-33020	CONTROL ARM,RIGHT	TOYOTA	HOH
12379	48605-35060	CONTROL ARM,RIGHT	TOYOTA	HOH
12380	48606-35060	CONTROL ARM,RIGHT	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
12385	48068-12110	CONTROL ARM,RIGHT	TOYOTA	HOH
18882	48069-12250 48069-12220	CONTROL ARM,FRONT,WITH BUSHINGS	TOYOTA	HOH
18968	48068-35050	CONTROL ARM,RIGHT	TOYOTA	HOH
19835	48068-20221	CONTROL ARM,RIGHT,WITH BUSHINGS	TOYOTA	HOH
19919	48068-59035	CONTROL ARM,RIGHT	TOYOTA	HOH
25547	48068-06090	CONTROL ARM,RIGHT	TOYOTA	HOH
25549	48066-29075 48066-29085	CONTROL ARM,RIGHT	TOYOTA	
25551	48068-28020	CONTROL ARM,RIGHT	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25553	48068-28040	CONTROL ARM,RIGHT	TOYOTA	
25555	48068-29045	CONTROL ARM,RIGHT	TOYOTA	
25557	48068-29095	CONTROL ARM,RIGHT	TOYOTA	
25558	48068-33050 48068-33070 48068-33060 48068-06070 48068-06080 48068-28120	CONTROL ARM,RIGHT	TOYOTA	
25560	48790-22010 48769-22010	CONTROL ARM,RIGHT	TOYOTA	
25564	48068-20260	CONTROL ARM,RIGHT	TOYOTA	
25566	48066-35060	CONTROL ARM,RIGHT	TOYOTA	
25568	48066-35030	CONTROL ARM,RIGHT	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25570	45201-60B01 45201-60E00 45201-60E01 45201-50G10 45201-60810 45201-70C00	CONTROL ARM,RIGHT	TOYOTA	HOH
25573	48068-BZ010	CONTROL ARM,RIGHT	TOYOTA	HOH
25580	48605-35030	CONTROL ARM,RIGHT	TOYOTA	HOH
25583	48605-35121 48605-35120	CONTROL ARM,RIGHT	TOYOTA	
25590	48068-87515	CONTROL ARM,RIGHT	TOYOTA	HOH
31367	48610-28012 48610-28013	CONTROL ARM,RIGHT	TOYOTA	HOH
31369	48068-13010 48068-02070 48068-02020 48068-02030 48068-02080 48068-12260 210552 48068-02021	CONTROL ARM,RIGHT	TOYOTA	
31371	48068-27020	CONTROL ARM,RIGHT	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31375	48610-26031	CONTROL ARM,RIGHT	TOYOTA	HOH
31377	48068-49036 48068-29115	CONTROL ARM,RIGHT	TOYOTA	HOH
31379	48610-0K020	CONTROL ARM,RIGHT	TOYOTA	HOH
31383	48068-59095 48068-09041 48068-09081 48068-59145 48068-59155 48068-09040	CONTROL ARM,RIGHT	TOYOTA	
31448	48068-87706	CONTROL ARM,RIGHT	TOYOTA	HOH
31721	48660-22090	CONTROL ARM,RIGHT	TOYOTA	HOH
31723	48660-30211	CONTROL ARM,RIGHT	TOYOTA	HOH
31725	48067-26050 48067-29025	CONTROL ARM,RIGHT	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31727	48610-35040	CONTROL ARM,RIGHT	TOYOTA	HOH
31729	48068-35081 48068-35080	CONTROL ARM,RIGHT	TOYOTA	
31731	48068-60010	CONTROL ARM,RIGHT	TOYOTA	HOH
31732	48610-60050	CONTROL ARM,RIGHT	TOYOTA	HOH
31735	48068-16040 48068-10051 48068-46011 48068-16120 48068-16060 48068-16100	CONTROL ARM,RIGHT	TOYOTA	HOH
31909	48620-60010	CONTROL ARM,RIGHT	TOYOTA	HOH
31911	48060-30150	CONTROL ARM,RIGHT	TOYOTA	HOH
31912	48640-30150	CONTROL ARM,RIGHT	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31913	48610-30110	CONTROL ARM,RIGHT	TOYOTA	HOH
32005	48068-42010 48068-42011 48068-42012 48068-42021 48068-42022	CONTROL ARM,RIGHT	TOYOTA	HOH
32015	48069-26011	CONTROL ARM,RIGHT	TOYOTA	HOH
32018	48068-33030 48068-33031	CONTROL ARM,RIGHT	TOYOTA	HOH
32024	48068-07030	CONTROL ARM,RIGHT	TOYOTA	HOH
32359	48068-87507	CONTROL ARM,RIGHT	TOYOTA	HOH
33070	48068-59055	CONTROL ARM,RIGHT	TOYOTA	
42189	48610-0K040	CONTROL ARM,RIGHT	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
42196	48068-0K040	CONTROL ARM,RIGHT	TOYOTA	
47864	48068-26160	CONTROL ARM,RIGHT	TOYOTA	HOH
47866	48068-26130 48068-26131 48068-26132	CONTROL ARM,RIGHT	TOYOTA	HOH
55396	48068-47050	CONTROL ARM,RIGHT	TOYOTA	HOH
61496	48068-12300 48068-02140 48068-02130 48068-0F030 48068-05080	CONTROL ARM,RIGHT	TOYOTA	
61499	48068-05070	CONTROL ARM,RIGHT	TOYOTA	HOH
61645	48068-0K010	CONTROL ARM,RIGHT	TOYOTA	
62956	48068-60030	CONTROL ARM,RIGHT	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
68421	48610-60030	CONTROL ARM,RIGHT	TOYOTA	HOH
73933	48068-19175 48068-19176	CONTROL ARM,RIGHT	TOYOTA	HOH
76515	54501-50Y12	CONTROL ARM,RIGHT	TOYOTA	HOH
78336	43201-0N010	CONTROL ARM,RIGHT	TOYOTA	HOH
81937	48068-42050 48068-42051	CONTROL ARM,RIGHT	TOYOTA	HOH
88396	48710-35060	CONTROL ARM,RIGHT	TOYOTA	HOH
2883	48069-33031 48069-33030	CONTROL ARM,LEFT	TOYOTA	HOH
12368	48069-12171 48069-12170 48069-12180 48069-12191 48069-12181 48069-12190 48069-02010 48069-12160	CONTROL ARM,LEFT	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
12375	48069-12130 48069-12140	CONTROL ARM,LEFT	TOYOTA	HOH
12377	48069-33010 48069-33020	CONTROL ARM,LEFT	TOYOTA	HOH
12384	48069-12110	CONTROL ARM,LEFT	TOYOTA	HOH
18883	48068-12250 48068-12220	CONTROL ARM,FRONT,WITH BUSHINGS	TOYOTA	HOH
18969	48069-35050	CONTROL ARM,LEFT	TOYOTA	HOH
19918	48069-59035	CONTROL ARM,LEFT	TOYOTA	HOH
25546	48069-06090	CONTROL ARM,LEFT	TOYOTA	HOH
25548	48069-79150 48067-29075 48067-29085	CONTROL ARM,LEFT	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25550	48069-28020	CONTROL ARM,LEFT	TOYOTA	
25552	48069-28040	CONTROL ARM,LEFT	TOYOTA	
25554	48069-29045	CONTROL ARM,LEFT	TOYOTA	
25556	48069-29095	CONTROL ARM,LEFT	TOYOTA	
25559	48069-33050 48069-33060 48069-33070 48069-06070 48069-06080 48069-28120	CONTROL ARM,LEFT	TOYOTA	
25561	48770-22010	CONTROL ARM,LEFT	TOYOTA	
25563	48069-20260	CONTROL ARM,LEFT	TOYOTA	
25565	48067-35060	CONTROL ARM,LEFT	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25569	45202-60B01 45202-60E00 45202-60E01 45202-50G10 45202-60820 45202-70C00	CONTROL ARM,LEFT	TOYOTA	HOH
25572	48606-35121 48606-35120	CONTROL ARM,LEFT	TOYOTA	
25575	54501-OE001	CONTROL ARM,LEFT	TOYOTA	HOH
25576	54501-18V01	CONTROL ARM,LEFT	TOYOTA	HOH
25581	48606-35030	CONTROL ARM,LEFT	TOYOTA	HOH
25582	48069-BZ010	CONTROL ARM,LEFT	TOYOTA	HOH
31366	48630-28012 48630-28013	CONTROL ARM,LEFT	TOYOTA	HOH
31368	48069-13010 48069-02070 48069-02020 48069-02030 48069-02080 48069-02100 48069-12260 48069-02021	CONTROL ARM,LEFT	TOYOTA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31370	48069-27020	CONTROL ARM,LEFT	TOYOTA	HOH
31374	48630-26031	CONTROL ARM,LEFT	TOYOTA	HOH
31376	48069-49036 48069-29115	CONTROL ARM,LEFT	TOYOTA	HOH
31378	48630-0K020	CONTROL ARM,LEFT	TOYOTA	HOH
31380	48069-0K010	CONTROL ARM,LEFT	TOYOTA	
31382	48069-59095 48069-09040 48069-09041 48069-09070 48069-09071 48069-59145	CONTROL ARM,LEFT	TOYOTA	
31720	48670-22090	CONTROL ARM,LEFT	TOYOTA	HOH
31722	48670-30211	CONTROL ARM,LEFT	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31724	48066-26050 48066-29025	CONTROL ARM,LEFT	TOYOTA	HOH
31726	48630-35020	CONTROL ARM,LEFT	TOYOTA	HOH
31728	48069-35081 48069-35080	CONTROL ARM,LEFT	TOYOTA	
31730	48069-60010	CONTROL ARM,LEFT	TOYOTA	HOH
31733	48630-60020	CONTROL ARM,LEFT	TOYOTA	HOH
31734	48069-16040 48069-10031 48069-46011 48069-16120 48069-16060 48069-16100	CONTROL ARM,LEFT	TOYOTA	HOH
31910	48069-30150	CONTROL ARM,LEFT	TOYOTA	HOH
32006	48069-42010 48069-42011 48069-42012 48069-42021 48069-42022	CONTROL ARM,LEFT	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
32017	48068-26011	CONTROL ARM,LEFT	TOYOTA	HOH
32025	48069-07030	CONTROL ARM,LEFT	TOYOTA	HOH
33071	48069-59055	CONTROL ARM,LEFT	TOYOTA	
42187	48630-0K040	CONTROL ARM,LEFT	TOYOTA	
42194	48069-0K040	CONTROL ARM,LEFT	TOYOTA	
47865	48069-26160	CONTROL ARM,LEFT	TOYOTA	HOH
47867	48069-26130 48069-26131 48069-26132	CONTROL ARM,LEFT	TOYOTA	HOH
55397	48069-47050	CONTROL ARM,LEFT	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
61497	48069-02140 48069-12300 48069-05080 48069-0F030 48069-02130	CONTROL ARM,LEFT	TOYOTA	
61498	48069-05070	CONTROL ARM,LEFT	TOYOTA	HOH
62957	48069-60030	CONTROL ARM,LEFT	TOYOTA	HOH
63217	48640-60010	CONTROL ARM,LEFT	TOYOTA	HOH
73932	48069-19155 48069-19156	CONTROL ARM,LEFT	TOYOTA	HOH
76514	54500-50Y12	CONTROL ARM,LEFT	TOYOTA	HOH
78335	43202-0N010	CONTROL ARM,LEFT	TOYOTA	HOH
81936	48069-42050 48069-42051	CONTROL ARM,LEFT	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
81938	48630-60010	CONTROL ARM,LEFT	TOYOTA	HOH
88395	48710-35070	CONTROL ARM,LEFT	TOYOTA	HOH
25562	48068-19095	CONTROL ARM,LEFT RIGHT	TOYOTA	
25571	45200-79001 45200-79002	CONTROL ARM,LEFT RIGHT	TOYOTA	HOH
33048	48068-06140	CONTROL ARM	TOYOTA	HOH
94626	48710-20270	CONTROL ARM	TOYOTA	HOH
47830	48630-59025	CONTROL ARM	TOYOTA	HOH
52297	48069-53010 48069 59025	CONTROL ARM	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
3200	48610-29015R	CONTROL ARM,WITH BUSHINGS,RIGHT,UPPER,ALUMINUM	TOYOTA	
21809	48610-39085	CONTROL ARM,WITH BUSHINGS,RIGHT,UPPER,ALUMINUM	TOYOTA	HOH
21810	48630-39055	CONTROL ARM,UPPER,FIXED BALL JOINT,LEFT	TOYOTA	HOH
89804	45490-29175	STEERING ARM	TOYOTA	HOH
31373	48610-59015	CONTROL ARM,RIGHT	TOYOTA	HOH
3198	48611-26040	CONTROL ARM,WITH BUSHINGS,RIGHT,UPPER,ALUMINUM	TOYOTA	
3197	48612-26040	CONTROL ARM,UPPER,FIXED BALL JOINT,LEFT	TOYOTA	
3199	48630-29015 48630-29075	CONTROL ARM,UPPER,LOOSE BALL JOINT,LEFT	TOYOTA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
58617	8-97028-972-0	CONTROL ARM	TOYOTA	HOH
3189	48621-26050	CONTROL ARM,LOWER,WITH RUBBER,RIGHT	TOYOTA	
3188	48622-26050	CONTROL ARM,LOWER,WITH RUBBER,LEFT	TOYOTA	
47831	48610-59025	CONTROL ARM	TOYOTA/LEXUS	HOH
31372	48630-59015	CONTROL ARM,LEFT	TOYOTA/LEXUS	HOH
29332	4543476 4647004	CONTROL ARM	VOLVO	HOH
8845	271902 271629 8628496 9492531 9492915	CONTROL ARM,RIGHT	VOLVO	
15268	272337 8628498 9492917 272274	CONTROL ARM,RIGHT	VOLVO	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
20407	30635232	CONTROL ARM,RIGHT	VOLVO	HOH
27630	8649542 30635228 9492106 8623956	CONTROL ARM,RIGHT	VOLVO	
31580	31201005 30681615 30645846 30639781	CONTROL ARM,RIGHT	VOLVO	HOH
51432	8628500	CONTROL ARM,RIGHT	VOLVO	HOH
8844	271901 271628 8628495 9492914	CONTROL ARM,LEFT	VOLVO	
15267	272336 8628497 9492916 272273 9492532	CONTROL ARM,LEFT	VOLVO	
20403	8649543 8623957 30736378 30635229	CONTROL ARM,LEFT	VOLVO	HOH
20406	30635231 8649545	CONTROL ARM,LEFT	VOLVO	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
25420	8628499	CONTROL ARM,LEFT	VOLVO	HOH
27628	8649541 9492105 30635227 8623955	CONTROL ARM,LEFT	VOLVO	
31579	30639780 31201004 30681614 30645845	CONTROL ARM,LEFT	VOLVO	HOH
20405	8649544 8623958 30736379 30635230	CONTROL ARM,WITH BUSHINGS,ALUMINUM,RIGHT	VOLVO	HOH
2768	171 407 153 D	CONTROL ARM	VW	
853	437 407 152 A 437 407 156 A 443 407 152 B	CONTROL ARM,FRONT RIGHT,WITH BUSHING,D=φ18MM	VW	
851	437 407 151 A 437 407 155 A 441 404 155 S 443 407 151 B	CONTROL ARM,WITH BUSHING,FRONT LEFT,D=φ18MM	VW	
32656	305 407 153 3C	CONTROL ARM	VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
852	4A0 407 152	CONTROL ARM,WITH BUSHING,FRONT RIGHT,D=φ19MM d=φ15MM	VW	
850	4A0 407 151	CONTROL ARM,WITH BUSHINGS,FRONT LEFT,D=φ19MM d=φ15MM	VW	
881	4D0 407 505 B 4D0 407 505 D 4D0 407 505 F 4D0 407 505 H	CONTROL ARM WITH BUSHINGS,FRONT,UPPER,ALUMINU M	VW	
19844	4E0 407 694 C 4E0 407 694 F 4E0 407 694 N 4E0 407 694 E 4E0 407 694 M	CONTROL ARM,RIGHT,UPPER,ALUMINUM	VW	
19842	4E0 407 693 C 4E0 407 693 F 4E0 407 693 N 4E0 407 693 E 4E0 407 693 M	CONTROL ARM,LEFT,UPPER,ALUMINUM	VW	
19840	4E0 407 151 G 4E0 407 151 L	CONTROL ARM,LEFT/RIGHT,UPPER,ALUMINUM	VW	
80265	8KD 407 152 B	CONTROL ARM,RIGHT	VW	
80264	8KD 407 151 B	CONTROL ARM,LEFT	VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
2423	4D0 407 151 J 4D0 407 151 4D0 407 151 A 4D0 407 151 B 4D0 407 151 C 4D0 407 151 E 4D0 407 151 G 4D0 407 151 H 4D0 407 151 P 8D0 407 151 E	CONTROL ARM,FRONT,WITH BUSHING,ALUMINUM,LEFT/RIGHT	VW	
11898	4B3 407 151 A 4B0 407 151 4B3 407 151 C 4B3 407 151 E 4B3 407 151 F 4B3 407 151 K JTC980	CONTROL ARM,WITH BUSHING,FRONT UPPER,ALUMINUM,LEFT/RIGHT	VW	
14657	8E0 407 506 A 8E0 407 506 C 8E0 407 506 P 8E0 407 506 D 8D0 407 506 D JTC119 4Z7 407 506 A 4Z7 407 506	CONTROL ARM,RIGHT,UPPER,ALUMINUM	VW	
2426	4D0 407 694 N 4D0 407 694 4D0 407 505 A 4D0 407 694 E 4D0 407 694 AC 4D0 407 694 H 4D0 407 694 K 4D0 407 694 M 8E0 407 694 8E0 407 694 E 8E0 407 694 H 8E0 407 694 K 8E0 407 694 Q 8E0 407 694 AG JTC350	CONTROL ARM,RIGHT,UPPER,ALUMINUM	VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
2425	4D0 407 693 N 8E0 407 693 4D0 407 693 4D0 407 693 E 4D0 407 693 G 4D0 407 693 H 4D0 407 693 K 4D0 407 693 M 4D0 407 693 AC 4D0 407 693 AD 8E0 407 693 E 8E0 407 693 H 8E0 407 693 K 8E0 407 693 Q 8E0 407 693 P 8E0 407 693 AG JTC348	CONTROL ARM,LEFT,UPPER,ALUMINUM	VW	
62997	4F0 498 998 S1	CONTROL ARM KIT,WITH CONNECTING RODS,WITH BOLT KIT	VW	
32220	3CD 407 151 C	CONTROL ARM,LEFT/RIGHT	VW	
72727	7L8 407 152 F 7L8 407 152 K	CONTROL ARM	VW	HOH
46808	8B0 498 998	CONTROL ARM KIT	VW	HOH
93226	2H0 407 051 A	CONTROL ARM,	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
93227	2H0 407 052 A	CONTROL ARM	VW	HOH
61494	2H0 407 022 B	CONTROL ARM,RIGHT	VW	
57565	2H0 407 021 B	CONTROL ARM,LEFT	VW	
34394	8K0 510 530 N	CONTROL ARM	VW	HOH
34395	8K0 510 529 N	CONTROL ARM	VW	HOH
32073	357 407 151 B	CONTROL ARM	VW	HOH
27519	4E0 498 998	CONTROL ARM KIT	VW	
48245	JTC1058.TRW	CONTROL ARM,RIGHT	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
48247	JTC1060.TRW	CONTROL ARM,LEFT	VW	HOH
22315	4Z7 407 693 D 4Z7 407 693 C 4Z7 407 693	CONTROL ARM	VW	HOH
19830	437 407 152 437 407 156	CONTROL ARM,RIGHT,WITH BUSHING	VW	
82396	8KD 407 694	CONTROL ARM,RIGHT	VW	HOH
19829	437 407 151 437 407 155	CONTROL ARM,LEFT	VW	
82395	8KD 407 693	CONTROL ARM,LEFT	VW	HOH
19841	4E0 407 151 J 4E0 407 151 K	CONTROL ARM,FRONT,WITH BUSHINGS,LEFT/RIGHT,LOWER,ALU MINUM	VW	HOH
22316	4Z7 407 694 D 4Z7 407 694 C 4Z7 407 694	CONTROL ARM	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
48246	JTC350.TRW	CONTROL ARM,RIGHT,ALUMINUM	VW	
48248	JTC347.TRW	CONTROL ARM,RIGHT,ALUMINUM	VW	
48249	JTC119.TRW	CONTROL ARM,RIGHT,ALUMINUM	VW	
2424	4D0 407 510 D 4D0 407 510 B 4D0 407 510 K	CONTROL ARM,RIGHT,UPPER,ALUMINUM	VW	
48250	JTC348.TRW	CONTROL ARM,LEFT,ALUMINUM	VW	
48251	JTC345.TRW	CONTROL ARM,LEFT,ALUMINUM	VW	
48252	JTC421.TRW	CONTROL ARM,LEFT,ALUMINUM	VW	
882	4D0 407 509 D 4D0 407 509 B 4D0 407 509 K	CONTROL ARM,LEFT,UPPER,ALUMINUM	VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
3703	861 407 151 B	CONTROL ARM,FRONT,LEFE/RIGHT	VW	
5914	171 407 124	CONTROL ARM,WITH BUSHINGS	VW	HOH
5989	357 407 153 357 407 151	WISHBONE,WITH BUSHING	VW	
8076	895 407 147 A	WISHBONE,WITH BUSHING,LEFT	VW	
8077	895 407 148 A	WISHBONE,WITH BUSHING,RIGHT	VW	
8325	251 407 047 B	CONTROL ARM	VW	
9254	823 407 147	CONTROL ARM	VW	
18752	895 407 147 D	CONTROL ARM,WITH BUSHINGS	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
18753	895 407 148 D	CONTROL ARM,WITH BUSHINGS	VW	HOH
19111	305 407 155 305 407 155.3 305 407 155.3C	CONTROL ARM	VW	
20862	4Z7 407 151 C 4Z7 407 151	CONTROL ARM	VW	HOH
30058	6Q0 407 152 DF	CONTROL ARM,RIGHT	VW	HOH
31709	021 156 110 A	CONTROL ARM	VW	HOH
32221	3CD 407 151 E	CONTROL ARM,LEFT/RIGHT	VW	HOH
32499	8D0 505 311	CONTROL ARM	VW	HOH
32500	8D0 505 312	CONTROL ARM	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
32501	8D0 505 323 B	CONTROL ARM	VW	HOH
32534	6Q0 407 151	CONTROL ARM	VW	
43363	1K0 505 226 E	CONTROL ARM	VW	HOH
44823	171 407 151 171 407 151 A	CONTROL ARM	VW	HOH
46657	1R0 407 151 A	CONTROL ARM	VW	HOH
46658	1R0 407 152 A	CONTROL ARM	VW	HOH
47789	7L0 505 376 A	CONTROL ARM	VW	HOH
47790	7L0 505 375 A	CONTROL ARM	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
53523	1K0 407 151 BB 1K0 407 151 BE 1K0 407 151 BG	CONTROL ARM	VW	
59559	8E0 501 529 G 8E0 501 529 K	CONTROL ARM	VW	
66465	305 407 155 A	CONTROL ARM	VW	
74348	1J0 407 151 BR	CONTROL ARM	VW	
74349	1J0 407 151 BL	CONTROL ARM	VW	
76503	1K0 501 311	CONTROL ARM	VW	
82387	3CD 505 223	CONTROL ARM	VW	
82388	3CD 505 224	CONTROL ARM	VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
82389	5C0 407 151	CONTROL ARM	VW	
82390	5C0 407 152	CONTROL ARM	VW	
86064	1S0 407 151		VW	
87732	4GD 407 693 A	CONTROL ARM,WITH BUSHINGS	VW	
87733	4GD 407 694 A	CONTROL ARM,WITH BUSHINGS	VW	
91703	3C0 505 224 D	CONTROL ARM	VW	
91704	3C0 505 223 D	CONTROL ARM	VW	
91705	1T0 505 223 F	CONTROL ARM	VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
91706	1T0 505 224 F	CONTROL ARM	VW	HOH
30048	191 407 151 A	CONTROL ARM,FRONT LEFT	VW	HOH
13375	1H0 407 152	CONTROL ARM,RIGHT	VW	
16983	893 407 148 E	CONTROL ARM,RIGHT	VW	
21634	8N0 407 152 A 8N0 407 152 D	CONTROL ARM,RIGHT	VW	HOH
25584	115 420 024	CONTROL ARM,RIGHT	VW	HOH
31290	8Z0 407 152 L	CONTROL ARM,RIGHT	VW	HOH
37937	701 407 152 A	CONTROL ARM,RIGHT	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
37938	7D0 407 152 A	WISHBONE,RIGHT	VW	HOH
42217	7H0 407 152 E 7H0 407 152 F 7H0 407 152 G	CONTROL ARM,RIGHT	VW	
57568	2H0 407 152 A	CONTROL ARM	VW	
68905	5U0 407 152 B	CONTROL ARM,RIGHT	VW	HOH
70746	5N0 407 152	CONTROL ARM	VW	
78301	357 407 152	CONTROL ARM,RIGHT	VW	HOH
78303	561 407 152 A 561 407 152 C	CONTROL ARM,RIGHT	VW	HOH
82457	8KD 407 152 A	CONTROL ARM,RIGHT	VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
84746	115-420026	CONTROL ARM,RIGHT	VW	HOH
86093	5C0 407 152 B 5C0 407 152 A	CONTROL ARM,RIGHT	VW	HOH
93758	5Q0 407 152 J 5Q0 407 152 G 5Q0 407 154 E 5Q0 407 152 L	WISHBONE,WITH BUSHING,RIGHT	VW	HOH
93760	5Q0 407 152 P	WISHBONE,WITH BUSHING,RIGHT	VW	HOH
3318	1H0 407 151 A	CONTROL ARM,LEFT	VW	
11296	893 407 147 E	CONTROL ARM,LEFT	VW	
11838	7M0 407 151 B 1 007 602 95VW 3079 AC	CONTROL ARM,LEFT	VW	HOH
21633	8N0 407 151 A 8N0 407 151 D	CONTROL ARM,LEFT	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31291	8Z0 407 151 L	CONTROL ARM,LEFT	VW	HOH
37936	701 407 151 A	CONTROL ARM,LEFT	VW	HOH
37939	7D0 407 151 A	CONTROL ARM,LEFT	VW	HOH
42215	7H0 407 151 E 7H0 407 151 F 7H0 407 151 G	CONTROL ARM,LEFT	VW	
54371	5C0 407 151 B 5C0 407 151 A	CONTROL ARM,LEFT	VW	HOH
57567	2H0 407 151 A	CONTROL ARM	VW	
68904	5U0 407 151 B	CONTROL ARM,LEFT	VW	HOH
70747	5N0 407 151	CONTROL ARM	VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
78302	561 407 151 A 561 407 151 C	CONTROL ARM,LEFT	VW	HOH
84745	115-420025	CONTROL ARM,LEFT	VW	
93751	5Q0 407 151 G 5Q0 407 151 J 5Q0 407 153 E 5Q0 407 151 L	WISHBONE,WITH BUSHING,LEFT	VW	HOH
93759	5Q0 407 151 P	WISHBONE,WITH BUSHING,LEFT	VW	HOH
31523	1H0 407 153	CONTROL ARM,LEFT/RIGHT	VW	HOH
5849	6N0 407 151 6N0 407 151 B	WISHBONE,LEFT/RIGHT,WITH BUSHING	VW	
9253	6N0 407 151 A 6X0 407 151 6X0 407 151 A	CONTROL ARM	VW	
46806		CONTROL ARM KIT	VW	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
848	1H0 407 151	CONTROL ARM,WITH BUSHINGS,FRONT LEFT	VW	
21546	1H0 407 151.OE	CONTROL ARM,WITH BUSHINGS	VW	HOH
26729	357 407 151 A	CONTROL ARM,LEFT	VW	HOH
95052	7L0 505 311 B 7L0 505 311 A	CONTROL ARM LEFT	VW	HOH
48260	JTC980.TRW	CONTROL ARM,ALUMINUM	VW	HOH
2280	8D0 407 506 A 8D0 407 506 B 8D0 407 506 E 8D0 407 506 F 8D0 407 506 H 8D0 407 506 L 8D0 407 506 K 8D0 407 506 C	CONTROL ARM,RIGHT,UPPER,ALUMINUM	VW	
2279	8D0 407 505 A 8D0 407 505 B 8D0 407 505 E 8D0 407 505 F 8D0 407 505 H 8D0 407 505 L 8D0 407 505 K 8D0 407 505 C	CONTROL ARM,LEFT,UPPER,ALUMINUM	VW	
82386	1K0 407 153 G	CONTROL ARM	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
31705	8D0 498 998 S2	CONTROL ARM KIT,WITHOUT BOLT KIT	VW	
15949	8D0 498 998 S1T 404903-101	CONTROL ARM KIT,WITH CONNECTING RODS,WITH BOLT KIT,WITH TOOLS	VW	
48261	JTC343.TRW	CONTROL ARM,ALUMINUM	VW	HOH
5833	893 407 148 C 893 407 148 A 857 407 148 A 857 407 148 C	WISHBONE,RIGHT	VW	
2902	893 407 147 C 893 407 147 A 857 407 147 A 857 407 147 C	CONTROL ARM,LEFT	VW	
847	893 407 147 G 811 407 147 811 407 147 A 811 407 147 B	CONTROL ARM,LEFT/RIGHT	VW	
30057	6Q0 407 151 DF	CONTROL ARM,LEFT	VW	HOH
41162	6Q0 407 151 AC	CONTROL ARM	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
21715	1K0 407 152 N 1K0 407 152 P 1K0 407 152 AA 1K0 407 152 AB 1K0 407 152 AE 1K0 407 152 BC	CONTROL ARM,RIGHT	VW	
21716	1K0 407 151 N 1K0 407 151 P 1K0 407 151 Q 1K0 407 151 AA 1K0 407 151 AB 1K0 407 151 AE 1K0 407 151 BC	CONTROL ARM,LEFT	VW	
3106	1J0 407 151 A 1J0 407 151 1J0 407 151 B 1J0 407 151 C 1JD 407 151 A	WISHBONE,WITH BUSHING	VW	
93229	1K0 505 224	CONTROL ARM,REAR RIGHT	VW	HOH
93196	1K0 505 223		VW	HOH
54083	1K0 505 311 AA	CONTROL ARM	VW	HOH
53430	7L0 407 047 B	CONTROL ARM	VW	HOH
36515	307 407 155.1 307 407 155.3	CONTROL ARM	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
53276	7P0 407 151 C	CONTROL ARM	VW	HOH
53277	7P0 407 152 C	CONTROL ARM	VW	HOH
77558	56D 407 152	CONTROL ARM,RIGHT	VW	
77557	56D 407 151	CONTROL ARM,LEFT	VW	
77560	16D 407 152	CONTROL ARM,RIGHT	VW	HOH
77559	16D 407 151	CONTROL ARM,LEFT	VW	HOH
53739	3CD 407 151 B	STEERING CONTROL ARM	VW	HOH
23030	1KD 505 311 C	CONTROL ARM	VW	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
93187	115-420020	CONTROL ARM,RIGHT	VW	HOH
93193	6UO 407 151 B	CONTROL ARM,RIGHT	VW	HOH
93194	6UO 407 152 B	CONTROL ARM,RIGHT	VW	HOH
68825	4H0 407 506 E	CONTROL ARM,RIGHT	VW/AUDI	
68827	4H0 407 510 E	CONTROL ARM,RIGHT	VW/AUDI	
68824	4H0 407 505 E	CONTROL ARM,LEFT	VW/AUDI	
68826	4H0 407 509 E	CONTROL ARM,LEFT	VW/AUDI	
68831	4H0 407 694 E 4H0 407 694 C 4H0 407 694 D 4H0 407 694 F	CONTROL ARM,RIGHT	VW/AUDI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
68830	4H0 407 693 E 4H0 407 693 C 4H0 407 693 F 4H0 407 693 D	CONTROL ARM,LEFT	VW/AUDI	
68829	4H0 407 152 B	CONTROL ARM,RIGHT	VW/AUDI	
68828	4H0 407 151 B	CONTROL ARM,LEFT	VW/AUDI	
82394	8KD 407 694 C	CONTROL ARM,RIGHT	VW/AUDI	
82393	8KD 407 693 C	CONTROL ARM,LEFT	VW/AUDI	
34406	8K0 501 530 N 8K0 501 530 K	CONTROL ARM,RIGHT	VW/AUDI	
34405	8K0 501 529 N 8K0 501 529 K	CONTROL ARM,LEFT	VW/AUDI	
76281	8K0 407 152 A	CONTROL ARM,RIGHT	VW/AUDI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
76280	8K0 407 151 A	CONTROL ARM,LEFT	VW/AUDI	HOH
34396	8K0 407 694 E 8KD 407 694 A 8K0 407 694 C	CONTROL ARM,RIGHT	VW/AUDI	
34404	8K0 407 693 E 8KD 407 693 A 8K0 407 693 C	CONTROL ARM,LEFT	VW/AUDI	
4055	4D0 407 510 G 4D0 407 510 4D0 407 510 F 4D0 407 510 H 4D0 407 510 J 8D0 407 510 8E0 407 510 A 8D0 407 510 C 8D0 407 510 E 8D0 407 510 G 8E0 407 510 C 4D0 407 510 B 4D0 407 510 D 4D0 407 510 K 8E0 407 510 P JTC347	CONTROL ARM,RIGHT,UPPER,ALUMINUM	VW/AUDI	
4108	4D0 407 509 G 4D0 407 509 4D0 407 509 F 4D0 407 509 H 4D0 407 509 J 8D0 407 509 8E0 407 509 A 8D0 407 509 C 8D0 407 509 E 8D0 407 509 G 8E0 407 509 C 4D0 407 509 B 4D0 407 509 D 4D0 407 509 K 8E0 407 509 P JTC345	CONTROL ARM,LEFT,UPPER,ALUMINUM	VW/AUDI	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
72726	7L8 407 151 F 7L8 407 151 K	CONTROL ARM	VW/AUDI	HOH
64079	4F0 407 693 B S3 4F0 407 151 A S3	CONTROL ARM KIT	VW/AUDI	HOH
23836	4G0 407 694 D 8K0 407 694 Q 8K0 407 694 T 4G0 407 694 H 4G0 407 694 J 8K0 407 694 S 4G0 407 694 F	CONTROL ARM	VW/AUDI	HOH
31825	4G0 407 693 D 8K0 407 693 Q 8K0 407 693 T 4G0 407 693 H 4G0 407 693 J 8K0 407 693 S 4G0 407 693 F	CONTROL ARM	VW/AUDI	HOH
68423	7L8 407 021	CONTROL ARM	VW/AUDI	
73134	5Q0 407 152 M	CONTROL ARM,FRONT RIGHT	VW/AUDI	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
73133	5Q0 407 151 M	CONTROL ARM,FRONT LEFT	VW/AUDI	HOH
53275	7P0 407 021	CONTROL ARM	VW/AUDI	HOH
62633	7L0 407 152 F 7L0 407 152 J 7L0 407 152 K	CONTROL ARM,RIGHT	VW/AUDI	
62632	7L0 407 151 F 7L0 407 151 J 7L0 407 151 K	CONTROL ARM,LEFT	VW/AUDI	
64080	8E0 407 693 AL S3	CONTROL ARM KIT	VW/AUDI/SEAT	HOH
64081	8E0 407 151 R S3	CONTROL ARM KIT	VW/AUDI/SEAT	
54367	3C0 407 151 H	CONTROL ARM	VW/AUDI/SEAT	HOH
14656	8E0 407 505 A 8E0 407 505 C 8E0 407 505 P 8E0 407 505 D 8D0 407 505 D JTC421 4Z7 407 505 4Z7 407 505 A	CONTROL ARM,LEFT,UPPER,ALUMINUM	VW/AUDI/SKODA	

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
73054	4D0 407 506 B	CONTROL ARM	VW/AUDI/SKODA	HOH
40117	906 338 02 27 906 330 41 07 2E0 407 152 M 2E0 407 152 L 68012 164 AA	CONTROL ARM,RIGHT	VW/MERCEDES-BENZ	HOH
48269	JTC1059.TRW	CONTROL ARM,ALUMINUM	VW/PORSCHE	HOH
42226	6R0 407 152 A 6R0 407 152 F 6R0 407 152 B 6R0 407 152 C	CONTROL ARM,RIGHT	VW/SEAT	
42225	6R0 407 151 A 6R0 407 151 F 6R0 407 151 B 6R0 407 151 C	CONTROL ARM,LEFT	VW/SEAT	HOH
21545	191 407 151 B.OE	WISHBONE,WITH BUSHING	VW/SEAT	HOH
46025	6RD 407 152 6R0 407 152 6R0 407 152 E	CONTROL ARM,RIGHT	VW/SEAT/SKODA	
53524	1K0 407 152 BB 1K0 407 152 BE 1K0 407 152 BG	CONTROL ARM	VW/SKODA	HOH

ID	REPL NO.	DESCRIPTION	APPLICATION	PICTURE
73609	6RF 407 152 B 6RD 407 152 A	CONTROL ARM,RIGHT	VW/SKODA	HOH
73058	6RF 407 151 B 6RD 407 151 A	CONTROL ARM,LEFT	VW/SKODA	HOH
9252	6Q0 407 151 D 6Q0 407 151 E 6Q0 407 151 L	WISHBONE,LEFT/RIGHT,WITH BUSHING	VW/SKODA	
23120	6Q0 407 151 D.OE	CONTROL ARM	VW/SKODA	HOH
84748	6U0 407 152 B	CONTROL ARM,RIGHT	VW/SKODA	HOH
84747	6U0 407 151 B	CONTROL ARM,LEFT	VW/SKODA	HOH